

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GOLDCHAMP](#) /
- › [GOLDCHAMP T0-TS58 Digital Insulation Resistance Tester User Manual](#)

GOLDCHAMP T0-TS58

GOLDCHAMP T0-TS58 Digital Insulation Resistance Tester User Manual

Model: T0-TS58

- [Introduction](#)
- [Safety Information](#)
- [Product Overview](#)
- [Setup](#)
- [Operation](#)
- [Data Management](#)
- [Display & Indicators](#)
- [Maintenance](#)
- [Troubleshooting](#)
- [Specifications](#)
- [What's in the Box](#)

1. INTRODUCTION

Thank you for choosing the GOLDCHAMP T0-TS58 Digital Insulation Resistance Tester. This instrument is designed for accurate measurement of insulation resistance, AC/DC voltage, and features data storage capabilities. Its robust, dustproof, and moisture-proof design makes it suitable for various indoor and outdoor electrical testing applications. Please read this manual thoroughly before operation to ensure safe and correct usage.



Figure 1: Front view of the GOLDCHAMP T0-TS58 Digital Insulation Resistance Tester.

2. SAFETY INFORMATION

Always adhere to the following safety precautions to prevent electric shock, injury, or damage to the instrument:

- Do not operate the instrument if it appears damaged or if the test leads are compromised.
- Ensure proper battery installation and replacement. Observe correct polarity.
- Do not use the instrument in wet environments or during electrical storms.
- Always disconnect power to the circuit under test before connecting or disconnecting test leads for insulation resistance measurements.
- Be aware of high voltage output during insulation resistance testing. Avoid contact with test leads and the circuit under test.
- Do not exceed the maximum input ratings for voltage and resistance.
- Refer to local and national safety codes for electrical work.
- This device is intended for professional use or by individuals with adequate electrical knowledge.

3. PRODUCT OVERVIEW

3.1 Key Features

- **Insulation Resistance Measurement:** Range from 0.1M Ω to 20G Ω .
- **DC/AC Voltage Measurement:** Range from 10V to 600V.
- **High-Definition LCD Display:** Maximum display of 2000 counts with backlight.
- **Data Storage:** Stores up to 100 sets of measurement data.
- **Auto Range:** Simplifies measurement selection.
- **Low Battery Indication:** Alerts when battery replacement is needed.
- **Dustproof and Moisture-proof Structure:** Suitable for outdoor use.
- **Automatic Power Off:** Conserves battery life.

3.2 Components and Controls

Familiarize yourself with the various parts of the GOLDCHAMP T0-TS58 tester:



Figure 2: Labeled diagram of the tester's components.

1. Insulation resistance measurement high voltage output jack L

2. Positive terminal of AC/DC voltage measurement
3. Voltage measurement input negative shielding end G (shielding end)
4. Insulation resistance measurement sampling jack E
5. Display LCD screen
6. Insulation resistance measurement high voltage start button (TEST)
7. Insulation resistance voltage selection button "▲" (Up)
8. Insulation resistance voltage selection button "▼" (Down)
9. Data hold/backlight button (HOLD / ☆)
10. Data read/save button (MEM / READ)
11. Function selection button (SELECT) - for Insulation Resistance, AC/DC voltage
12. Polarization index DAR and absorption ratio PI buttons (PI/DAR)
13. Power switch button ()

4. SETUP

4.1 Unpacking and Inspection

Carefully unpack the GOLDCHAMP T0-TS58 tester and all accessories. Inspect for any signs of damage. If any components are missing or damaged, contact your supplier immediately.

4.2 Battery Installation

The instrument requires 8 x 1.5V AA batteries (not included). To install:

1. Locate the battery compartment on the back of the device.
2. Open the battery compartment cover.
3. Insert 8 x 1.5V AA batteries, ensuring correct polarity as indicated inside the compartment.
4. Close the battery compartment cover securely.

4.3 Connecting Test Leads

Connect the test leads to the appropriate jacks on the top of the instrument based on the measurement type:

- For Insulation Resistance: Connect leads to L and E jacks.
- For AC/DC Voltage: Connect leads to AC/DC 600V and G jacks.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on, press the **Power Switch Button ()**.
- To power off, press the **Power Switch Button ()** again. The device also features automatic power-off to conserve battery.

5.2 Function Selection

Press the **SELECT** button to cycle through measurement functions: Insulation Resistance, AC Voltage, and DC Voltage.

5.3 Insulation Resistance Measurement

This function measures the resistance of insulating materials in electrical equipment.

1. Ensure the circuit under test is de-energized and safely discharged.
2. Connect the test leads to the L and E jacks on the tester.
3. Connect the other ends of the test leads to the appliance or circuit under test.
4. Use the ▲ and ▼ buttons to select the desired output test voltage (e.g., 100V, 250V, 500V, 1000V).
5. Press and hold the **TEST** button for approximately 1 second to initiate the measurement. The instrument will automatically discharge after the test.
6. Read the insulation resistance value on the LCD display.


STORAGE BAG DISPLAY



Internal Display



Portable Tote Bag



Nylon Zipper

Figure 3: Example of insulation resistance measurement in progress.

5.4 AC/DC Voltage Measurement

This function measures AC or DC voltage.

1. Press the **SELECT** button until the ACV or DCV mode is displayed.
2. Connect the test leads to the AC/DC 600V and G jacks on the tester.
3. Connect the other ends of the test leads to the circuit where voltage is to be measured.
4. Read the voltage value on the LCD display. The instrument features auto-ranging.

6. DATA MANAGEMENT

The GOLDCHAMP T0-TS58 can store up to 100 sets of measurement data.

6.1 Data Storage

After a measurement is completed and the reading is stable:

- Press the **MEM** button (part of the HOLD/MEM button) to save the current measurement data.
- The display will indicate successful storage.

6.2 Data Recall and Deletion

To review or delete stored data:

- Press the **READ** button (part of the MEM/READ button) to enter data recall mode.
- Use the **▲** and **▼** buttons to navigate through stored data sets.
- To delete a specific data set or all data, refer to the detailed instructions in the included user manual for specific key combinations.

1. Insulation resistance measurement high voltage output jack L

2. Positive terminal of AC/DC voltage measurement

3. Voltage measurement input negative shielding end G (shielding end)

4. Insulation resistance measurement sampling jack E



5. Display LCD screen

6. Insulation resistance measurement high voltage start button

7. Insulation resistance voltage selection button "▲"

8. Insulation resistance voltage selection button "▼"

9. Data hold/backlight button,

10. Data read/save button

11. Function selection button (insulation resistance, AC/DC voltage)

12. Polarization index DAR and absorption ratio PI buttons

13. Power switch button

Figure 4: The display indicating data storage functionality.

7. DISPLAY AND INDICATORS

7.1 LCD Backlight

The LCD display features a backlight for improved visibility in low-light conditions.

- Press the ☆ button (part of the HOLD/☆ button) to turn the backlight on or off.

7.2 Low Battery Indicator

A low battery indicator icon will appear in the upper right corner of the display when the battery level is low. When this indicator appears, replace all 8 x 1.5V AA batteries promptly to ensure accurate measurements and proper operation.

8. MAINTENANCE

8.1 Cleaning

Wipe the instrument's casing with a damp cloth and mild detergent. Do not use abrasive cleaners or solvents. Ensure the instrument is completely dry before use.

8.2 Storage

When not in use for extended periods, remove the batteries to prevent leakage. Store the instrument in a cool, dry place, away from direct sunlight and extreme temperatures. The included storage bag is ideal for protection.

100 Sets of Data Storage

After measurement, press the HOLD key to keep the data, "MEM" to save the data, and "READ" to read the data.



Figure 5: The GOLDCHAMP T0-TS58 stored in its protective bag.

8.3 Battery Replacement

Replace batteries as described in Section 4.2 when the low battery indicator appears. Always replace all batteries simultaneously with new ones of the same type.

9. TROUBLESHOOTING

If you encounter issues with your GOLDCHAMP T0-TS58, refer to the following common problems and solutions:

- **No Display/Power:** Check battery installation and ensure batteries are not depleted. Replace if necessary.
- **Inaccurate Readings:** Ensure test leads are properly connected and not damaged. Verify the correct measurement function is selected. Check battery level.
- **No Insulation Resistance Measurement:** Ensure the TEST button is pressed and held correctly. Verify the circuit under test is properly connected and de-energized.
- **Data Storage Issues:** Ensure there is available memory. Follow the data storage procedure carefully.

If the problem persists, contact customer support for assistance.

10. SPECIFICATIONS

Parameter	Value
Max Display	2000 counts
Working Temperature	0~40°C
Weight	800g (including battery)
DC/AC Voltage Range	10 to 600V
AC Voltage Frequency	40Hz~70Hz
Resistance Range	0.1MΩ to 20GΩ
Insulation Resistance (1000V)	≥500MΩ
Dimensions	180 x 140 x 70mm (7.1 x 5.5 x 2.7in)
Power Source	Battery Powered (8 x 1.5V AA)
Data Storage	100 sets
Safety Compliance	CE, IP 67, UL (as per product information)

11. WHAT'S IN THE BOX

The GOLDCHAMP T0-TS58 package includes the following items:

Insulation Resistance Measurement Multi-level High Voltage Output

Connect the test leads to both ends of the test appliance. After selecting the output voltage, press the TEST button to automatically discharge and measure whether the appliance is normal or short-circuited.



Figure 6: All items included in the product package.

- 1 x GOLDCHAMP T0-TS58 Digital Insulation Resistance Tester
- 2 x Test Leads
- 2 x Alligator Clips
- 1 x Storage Bag
- 1 x User Manual
- 1 x Screwdriver
- 8 x 1.5V Batteries (as per product description, though specifications state 'No' for included batteries, please verify upon receipt)

12. WARRANTY AND SUPPORT

Specific warranty information for the GOLDCHAMP T0-TS58 is not provided in the available product details. For warranty claims, technical support, or service inquiries, please contact your retailer or the manufacturer directly using the contact information provided at the point of purchase.

