

**Jocca 63627**

## **Jocca 3.8L Digital Air Fryer Instruction Manual**

Model: 63627

### **INTRODUCTION**

Welcome to the world of healthier cooking with your new Jocca 3.8L Digital Air Fryer. This appliance allows you to fry, roast, grill, and bake your favorite foods with little to no oil, providing delicious and crispy results. Its intuitive digital touch screen and pre-set programs make cooking simple and efficient. Please read this manual thoroughly before first use to ensure safe and optimal operation of your air fryer.

### **IMPORTANT SAFETY INSTRUCTIONS**

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

### **PRODUCT OVERVIEW**

Familiarize yourself with the components of your Jocca Air Fryer:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital LED touch screen for setting temperature, time, and selecting programs.
- **Frying Basket:** Removable non-stick basket for holding food.
- **Basket Handle:** Ergonomically designed for safe removal of the basket.
- **Air Inlet:** Located at the top of the unit.
- **Air Outlet Vents:** Located at the back of the unit.



Image: The Jocca Air Fryer main unit shown alongside its removable frying basket, highlighting the separate components for easy cleaning and use.

## SETUP AND FIRST USE

1. **Unpack:** Carefully remove all packaging materials and stickers from the air fryer.
2. **Clean:** Wash the frying basket and any removable parts with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Dry:** Ensure all parts are thoroughly dry before use.
4. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface, ensuring there is at least 10 cm (4 inches) of free space around the back and sides for proper ventilation.
5. **Pre-heat (Optional):** For the first use, it is recommended to run the air fryer for about 10-15 minutes at 180°C (350°F) without food to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal.

## OPERATING INSTRUCTIONS

Your Jocca Air Fryer features a user-friendly digital touch screen for precise control.



Image: The Jocca Air Fryer from the front, showcasing its sleek design and the digital control panel on top.

### Basic Operation:

- Plug In:** Connect the power cord to a grounded wall outlet. The display will light up.
- Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket to ensure even cooking.
- Insert Basket:** Slide the frying basket back into the main unit until it clicks into place.

4. **Power On:** Press the Power button on the touch screen to turn on the appliance.
5. **Set Temperature and Time:**
  - Use the temperature control buttons (usually + and - icons) to adjust the temperature between 80°C and 200°C.
  - Use the timer control buttons (usually + and - icons) to set the cooking time up to 60 minutes.
6. **Select Pre-set Program (Optional):** Your air fryer comes with 12 pre-set programs for common dishes. Press the Menu/Program button to cycle through the options. Once selected, the air fryer will automatically set the optimal temperature and time. You can still manually adjust these settings if desired.
7. **Start Cooking:** Press the Start/Pause button to begin the cooking process.
8. **Shake Reminder:** For some recipes, the air fryer may emit an acoustic signal to remind you to shake or turn the food halfway through cooking. Carefully remove the basket, shake or flip the food, and reinsert the basket. The cooking will resume automatically.
9. **End of Cooking:** Once the timer reaches zero, the air fryer will beep and automatically shut off.
10. **Remove Food:** Carefully pull out the frying basket using the handle. Place it on a heat-resistant surface. Do not touch the hot basket or the inside of the air fryer.
11. **Serve:** Empty the cooked food into a serving dish.
12. **Power Off:** Press the Power button to turn off the appliance completely, or it will enter standby mode after a period of inactivity. Unplug the appliance from the wall outlet after use.

## COOKING GUIDE AND TIPS

---

- **Oil Usage:** While the air fryer cooks without oil, a small amount of oil (1 tablespoon or less) can be added to some foods for extra crispiness and flavor. Toss food with oil before placing it in the basket.
- **Even Cooking:** For best results, shake the basket or flip food halfway through cooking, especially for larger quantities or items like fries and chicken wings.
- **Batch Cooking:** If cooking large amounts of food, cook in smaller batches to ensure even air circulation and crispiness.
- **Preheating:** Preheating the air fryer for 3-5 minutes before adding food can improve cooking results and reduce overall cooking time.
- **Food Doneness:** Cooking times and temperatures are approximate. Always check food for doneness, especially meats and poultry, using a food thermometer if necessary.
- **Versatility:** This air fryer can fry, gratinate, roast, heat, and defrost. Experiment with different recipes beyond traditional frying.

## MAINTENANCE AND CLEANING

---

Regular cleaning will extend the life of your air fryer and ensure optimal performance.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Basket and Pan:** The frying basket and pan are non-stick. Wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes. Do not use metal utensils or abrasive cleaning materials. These parts are generally not dishwasher safe; refer to specific product instructions if available.
3. **Clean Interior:** Wipe the inside of the appliance with a damp cloth. For baked-on food residue, use a soft brush and warm soapy water.

- Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

## TROUBLESHOOTING

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; appliance malfunction.	Ensure the plug is securely inserted into a working outlet. Check your home's circuit breaker.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped; incorrect temperature/time.	Cook in smaller batches. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from the appliance.	Greasy food; oil residue from previous use; food with high fat content.	Clean the basket and pan thoroughly. For high-fat foods, place a piece of aluminum foil at the bottom of the basket to catch excess oil.
Appliance turns off unexpectedly.	Overheating protection activated; basket not fully inserted.	Unplug the appliance and let it cool down for 30 minutes. Ensure the basket is fully pushed in until it clicks.
Food is not crispy.	Too much moisture; not enough oil (if desired); basket overcrowded.	Pat food dry before air frying. Lightly coat with oil if desired. Do not overcrowd the basket.

## SPECIFICATIONS

Feature	Detail
<b>Brand</b>	Jocca
<b>Model Number</b>	63627
<b>Color</b>	White
<b>Capacity</b>	3.8 Liters
<b>Power</b>	1450 Watts
<b>Voltage</b>	220 Volts (AC)
<b>Material</b>	Polypropylene (PP)
<b>Product Dimensions (L x W x H)</b>	31.7 x 25.5 x 31.6 cm
<b>Product Weight</b>	3.2 kg

Feature	Detail
<b>Special Features</b>	Programmable, Digital LED Touch Screen, 12 Pre-set Programs, Adjustable Temperature (80-200°C), Adjustable Timer (up to 60 min), Acoustic Signal, Automatic Shut-off

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Jocca website. Keep your purchase receipt as proof of purchase for any warranty claims.

If you require further assistance or have questions not covered in this manual, please contact Jocca customer service.

## ADDITIONAL PRODUCT IMAGES

---



Image: A slightly angled front view of the Jocca Air Fryer, showcasing its elegant white finish and wooden effect handle.



Image: The Jocca Air Fryer with its frying basket partially pulled out, demonstrating easy access to the cooking compartment.



Image: The Jocca Air Fryer positioned on a modern kitchen counter, ready for use, blending seamlessly with kitchen decor.



Image: The retail packaging box for the Jocca Air Fryer, displaying product branding and key features.

## OFFICIAL PRODUCT VIDEOS

Based on the provided information, there are no official product videos from the seller available for embedding in this manual.