

[Manuals.plus](#) /

› [TP Toys](#) /

› TP Toys Foldaway Baby Swing Model 526 Instruction Manual

TP Toys 526

TP Toys Foldaway Baby Swing Model 526 Instruction Manual

For Babies Aged 6 Months+

1. INTRODUCTION

This manual provides essential information for the safe assembly, setup, operation, and maintenance of your TP Toys Foldaway Baby Swing, Model 526. Designed for babies aged 6 months and up, this swing offers a versatile solution for both indoor and outdoor use.



Image 1.1: The TP Toys Foldaway Baby Swing, Model 526, in its assembled state.

2. SAFETY INFORMATION

WARNING: Adult supervision is required at all times. Failure to follow these instructions may result in serious injury.

- **Age and Weight Limit:** Suitable for babies aged 6 months and up. Maximum user weight is 30 kg (66 lbs). Do not exceed this limit.
- **Assembly:** Ensure all components are correctly assembled and securely fastened before use. Regularly check all bolts and connections.
- **Harness:** Always secure your child with the provided safety harness. Adjust straps snugly to prevent falling.
- **Placement:** Place the swing on a flat, level surface. Ensure a clear area around the swing, free from obstacles, walls, or other play equipment.
- **Indoor Use:** Utilize the rubber non-slip feet to ensure stability and protect flooring.
- **Outdoor Use:** Use the provided ground stakes to anchor the swing securely to the ground.
- **Inspection:** Before each use, inspect the swing for any signs of wear, damage, or loose parts. Discontinue

use if any damage is found.

- **Weather Conditions:** Do not use the swing in strong winds or adverse weather conditions.
- **Modifications:** Do not modify the swing in any way. Use only original replacement parts if needed.

3. PACKAGE CONTENTS

Verify that all the following components are present before beginning assembly:

- Main Metal Frame (pre-assembled sections)
- Foldaway Baby Swing Seat with Harness
- Connecting Pins/Knobs for folding mechanism
- Ground Stakes (for outdoor use)
- Instruction Manual



Image 3.1: Detail of the comfortable baby swing seat with its integrated safety harness.

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires one adult and takes approximately 15-30 minutes. No special tools are required beyond what may be included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Check against the 'Package Contents' list.
2. **Assemble Frame Legs:** Extend the pre-assembled metal frame sections. The legs should click into place or be secured with the provided connecting pins/knobs. Ensure all four legs are fully extended and locked.
3. **Attach Crossbars:** Secure any horizontal crossbars between the legs using the designated fasteners. These provide additional stability.
4. **Connect Swing Seat:** Locate the hanging hooks on the top bar of the frame. Attach the straps of the baby swing seat to these hooks, ensuring they are securely clipped.
5. **Final Check:** Once assembled, gently shake the frame to ensure all connections are tight and stable. Verify the swing seat is properly attached and the harness functions correctly.



Image 4.1: Detail of a secure frame connection point, illustrating how sections are joined.



Image 4.2: The folding mechanism knob, used to secure or release the frame for folding.

5. SETUP

5.1. Indoor Setup

For indoor use, ensure the swing is placed on a flat, non-slip surface. The integrated rubber non-slip feet will protect your flooring and provide stability. Keep the swing away from furniture, walls, and other objects to prevent collisions.



Image 5.1: The baby swing set up for indoor use on a carpeted surface.

5.2. Outdoor Setup

When using the swing outdoors, select a level patch of grass or soft ground. Use the provided ground stakes to firmly anchor the swing's legs into the earth. This ensures maximum stability and safety during outdoor play. Clear the area of any debris, rocks, or other hazards.



Image 5.2: The baby swing set up for outdoor use in a garden environment.

6. OPERATING INSTRUCTIONS

- **Placing Your Child:** Gently place your child into the swing seat. Ensure their back is against the seat back and their legs are comfortably positioned.
- **Securing the Harness:** Fasten the safety harness securely around your child. Adjust the straps so they are snug but not too tight, allowing for comfortable movement while preventing them from slipping out.
- **Initiating Swing:** With your child safely secured, gently push the swing to initiate a smooth, controlled swinging motion. Avoid excessive force or high swinging.
- **Supervision:** Always maintain direct adult supervision while the swing is in use. Never leave a child unattended in the swing.
- **Stopping Swing:** Gradually slow the swing's motion until it comes to a complete stop before removing your child.

7. MAINTENANCE

- **Cleaning:** The fabric swing seat can be spot cleaned with mild soap and water. The metal frame can be wiped down with a damp cloth. Avoid abrasive cleaners.
- **Storage:** The swing features a fold-away design for easy storage. To fold, release the connecting pins/knobs on the frame legs and carefully collapse the frame. Store in a dry place, away from direct sunlight and extreme temperatures, especially during winter months if used outdoors.
- **Regular Checks:** Periodically check all nuts, bolts, and connections for tightness. Inspect the swing seat fabric and harness for any tears, fraying, or damage.
- **Rust Prevention:** The metal frame is powder-coated for durability. However, if used outdoors, ensure it is dried thoroughly after rain to prevent rust.

8. TROUBLESHOOTING

- **Swing feels unstable:**
Solution: Ensure the swing is on a completely flat and level surface. For outdoor use, verify ground stakes are fully inserted. For indoor use, check that rubber feet are intact and making full contact with the floor. Re-check all frame connections for tightness.
- **Difficulty folding the swing:**
Solution: Ensure all connecting pins/knobs are fully disengaged or loosened as per assembly instructions. Do not force the frame; check for any obstructions.
- **Harness not securing properly:**
Solution: Inspect the buckle and straps for any damage or debris. Ensure straps are threaded correctly through the adjusters.
- **Squeaking noise during use:**
Solution: Check the hanging hooks and frame joints. A small amount of silicone-based lubricant (avoid oil-based near fabric) can be applied to metal-on-metal contact points if necessary.

9. SPECIFICATIONS

Feature	Detail
Brand	TP Toys
Model Number	526
Color	Blue frame, Green seat
Product Dimensions (Assembled)	58"D x 50"W x 43"H (147cm D x 127cm W x 109cm H)
Frame Material	Powder-Coated Metal (Steel)
Item Weight	11 pounds (5 kg)
Minimum Age	6 Months+
Maximum User Weight	30 kg (66 lbs)
Assembly Required	Yes



Image 9.1: Front view dimension diagram of the swing.




Image 9.2: Side view dimension diagram of the swing.

10. WARRANTY AND SUPPORT

The TP Toys Foldaway Baby Swing, Model 526, comes with **one-year warranty** against manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, replacement parts, or warranty inquiries, please contact TP Toys customer service through their official website or the retailer where the product was purchased. Provide your model number (526) and date of purchase for efficient assistance.

