

PSIDE PTBM 550 A1

Parkside PTBM 550 A1 Bench Drill Press User Manual

Model: PTBM 550 A1 | Brand: PSIDE

1. INTRODUCTION

This manual provides essential information for the safe and effective operation of your Parkside PTBM 550 A1 Bench Drill Press. Please read these instructions carefully before initial use and keep them for future reference. This drill press is designed for precise drilling in wood, metal, and plastic.

Key features include:

- Continuously variable speed control from 450 to 2600 RPM.
- Digital display for drilling speed.
- High-quality drill chuck.
- Comfortable lowering lever with spring return.
- Continuously adjustable drilling depth with a practical scale.
- Integrated work light and switchable laser cross for adjustable marking.
- Durable induction motor with continuous V-belt drive.
- Height-adjustable drill table, inclinable 45° on both sides.
- Robust steel base for workbench mounting (mounting hardware not included).
- Foldable chip guard made of transparent material.

2. GENERAL SAFETY INSTRUCTIONS

WARNING: Read all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

2.1. Work Area Safety

- Keep the work area clean and well-lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2.2. Electrical Safety

- Power tool plugs must match the outlet. Never modify the plug in any way.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges, and refrigerators.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

2.3. Personal Safety

- Always wear eye protection. Use appropriate personal protective equipment such as dust masks, non-skid safety shoes, hard hats, or hearing protection.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair and clothing away from moving parts.
- Do not overreach. Keep proper footing and balance at all times.

3. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your Parkside PTBM 550 A1 Bench Drill Press:

1. Drill Chuck (1-13 mm)
2. Lowering Lever with Spring Return
3. Digital Speed Display
4. Work Light
5. Laser Cross (Switchable)
6. Drill Table (Height-adjustable, 45° inclinable)
7. Depth Scale
8. V-belt Drive Cover
9. Robust Steel Base
10. Foldable Chip Guard
11. Power Cable (3m length)



Figure 1: Overview of the Parkside PTBM 550 A1 Bench Drill Press. This image shows the complete drill press unit, highlighting its main components such as the drill head, work table, and base.

4. SETUP AND ASSEMBLY

Before operating the drill press, ensure it is properly assembled and securely mounted.

4.1. Unpacking

- Carefully remove all components from the packaging.
- Check for any damage during transit. If any parts are damaged or missing, contact customer support.
- Ensure all included accessories, such as the assembly tool, are present.

4.2. Mounting the Drill Press

1. Place the robust steel base of the drill press on a stable and level workbench.
2. Secure the drill press to the workbench using appropriate mounting hardware (not included). Ensure it is firmly bolted down to prevent movement during operation.
3. Connect the power cable to a suitable 230V AC power outlet.

4.3. Attaching the Chip Guard

Attach the foldable transparent chip guard to the designated position on the drill press. This guard helps protect against flying debris during drilling operations.

5. OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation of your drill press.

5.1. Preparing for Drilling

1. **Select the Right Drill Bit:** Choose a drill bit appropriate for the material (wood, metal, plastic) and desired hole size. Insert it securely into the 1-13 mm drill chuck using the provided assembly tool.
2. **Adjust Work Table Height and Angle:** Loosen the locking mechanism for the drill table. Adjust the table to the desired height and angle (up to 45° on both sides) for your workpiece. Securely tighten the locking mechanism.
3. **Secure the Workpiece:** Always clamp your workpiece firmly to the drill table using appropriate clamps. Never hold the workpiece by hand during drilling.
4. **Set Drilling Depth:** Use the continuously adjustable depth scale to set the desired drilling depth. This prevents drilling too deep.
5. **Activate Laser Cross and Work Light:** Switch on the integrated work light for better visibility and the laser cross for precise marking of the drilling point. Adjust the laser cross as needed.

5.2. Adjusting Speed

The drill press features continuously variable speed control from 450 to 2600 RPM. Adjust the speed according to the material and drill bit size. The digital display will show the current drilling speed.

- Lower speeds are generally suitable for harder materials (e.g., metal) and larger drill bits.
- Higher speeds are suitable for softer materials (e.g., wood, plastic) and smaller drill bits.

5.3. Drilling Operation

1. Ensure the chip guard is in place.
2. Switch on the drill press.
3. Using the lowering lever, slowly and steadily bring the drill bit down into the workpiece. Apply even pressure.
4. Allow the drill bit to cut through the material. Do not force the drill.
5. Once the desired depth is reached, retract the drill bit slowly using the lowering lever. The spring return will assist.

6. Switch off the drill press after completing the operation.

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your drill press.

6.1. Cleaning

- Always disconnect the drill press from the power supply before cleaning.
- Clean the machine regularly, especially after use, to remove dust, chips, and debris. Use a brush or compressed air.
- Wipe down external surfaces with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Keep the ventilation openings clear to prevent overheating.

6.2. Lubrication

Periodically lubricate moving parts as recommended in the full manufacturer's manual (if available) to ensure smooth operation.

6.3. Inspection

- Inspect the power cable for any signs of damage. Replace damaged cables immediately.
- Check the drill chuck for wear and ensure it grips drill bits securely.
- Ensure all bolts and fasteners are tight.
- Check the V-belt for tension and wear. Adjust or replace if necessary.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your drill press.

Problem	Possible Cause	Solution
Drill press does not start.	No power supply. Power switch off. Faulty cable.	Check power connection and outlet. Turn on power switch. Inspect and replace damaged cable.
Excessive vibration during operation.	Loose mounting. Unbalanced drill bit. Worn V-belt.	Ensure drill press is securely mounted. Check drill bit for damage or proper insertion. Inspect and replace V-belt if worn.
Drill bit not cutting effectively.	Dull drill bit. Incorrect speed setting. Insufficient pressure.	Replace or sharpen drill bit. Adjust speed according to material. Apply steady, even pressure.
Laser cross not visible or misaligned.	Laser switched off. Laser needs adjustment.	Ensure laser is switched on. Refer to the full manual for laser adjustment procedures.

8. TECHNICAL SPECIFICATIONS

Model	PTBM 550 A1
Brand	PSIDE
Power Input	550 W (S6 15%) / 350 W (S1)
No-load Speed	450 - 2600 min ⁻¹ (RPM)
Drilling Stroke	0 - 60 mm
Chuck Capacity	1 - 13 mm
Drill Table Angle	-45° to +45°
Max. Drilling Diameter (Wood)	25 mm
Max. Drilling Diameter (Steel)	16 mm
Material	Plastic, Cast Iron
Dimensions (L x W x H)	Approx. 52 x 35 x 78.5 cm
Work Table Dimensions	Approx. 22 x 19.5 cm
Base Plate Dimensions	Approx. 20 x 25.5 cm
Weight	Approx. 23.5 kg
Power Cable Length	3 m
Voltage	230 Volts (AC)
Special Features	Switchable laser cross for adjustable marking, integrated work light

9. WARRANTY AND SUPPORT

For warranty information, technical support, or spare parts inquiries, please refer to the documentation provided with your purchase or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CRPL68GN>

More documents and user manuals: <https://manuals.plus/>