

Manuals.plus /

- › VOCOO /
- › VOCOO Digital Kitchen Timer User Manual

VOCOO 5285W

VOCOO Digital Kitchen Timer User Manual

Model: 5285W | Brand: VOCOO

1. PRODUCT OVERVIEW

The VOCOO Digital Kitchen Timer is a versatile and user-friendly device designed for precise time management in various settings, including kitchens, classrooms, home gyms, and offices. It features an extra-large LED display, multiple alarm options, adjustable volume and brightness, and convenient placement options.



Figure 1: Front view of the VOCOO Digital Kitchen Timer displaying 99 hours and 59 minutes.

2. KEY FEATURES

- **Extra Large LED Display:** A 7.8-inch digital white LED display with 2.3-inch tall numbers for easy readability from a distance.
- **Adjustable Brightness:** Three levels of brightness (Dim/Medium/Bright) to suit different environments.
- **Multiple Alarms & Volume Levels:** Four distinct alarm options (Beep, Melody 1, Melody 2, Melody 3) and three volume settings (Loud: 80-95dB, Medium: 70-85dB, Soft: 60-75dB).
- **Versatile Timing Modes:** Supports both countdown (up to 99 hours 59 minutes) and count-up (stopwatch, up to 99 hours 59 minutes 59 seconds) functions. Includes Minute/Second and Hour/Minute modes.
- **Rechargeable Battery:** Powered by a rechargeable battery, reducing the need for frequent battery replacements. Features a low power indicator.
- **Flexible Placement:** Equipped with two strong, silicone-covered magnets for direct attachment to metal surfaces, a hanging hole, and a built-in stand for desktop use.
- **Intuitive Controls:** Dedicated buttons for setting time, reset, and start/pause, ensuring ease of use for all ages.

Extra Large Display Digital Timer



Large LED Display

Easy to read even from across a room



Longer Count Range

Countdown: 99 Hours 59 Minutes to 00:00
Count Up: 00:00 to 99:59:59



1 Minute Countdown Reminder

All numbers turn red



Custom Function

Set a regular countdown time for quick access to it



3. SETUP

3.1. Unboxing and Initial Charge

Upon unboxing, locate the VOCOO Digital Timer, USB-C plug, USB-C charging cable, and user manual. It is recommended to fully charge the device before first use.

1. Connect the provided USB-C charging cable to the timer's USB-C port (located on the side).
2. Plug the USB-C plug into a standard 5V (OUTPUT VOLTAGE) power outlet.
3. The low power icon on the display will indicate charging status. Charge until the icon disappears or indicates full charge.
4. **NOTE:** Using a power plug higher than 5V may lead to battery damage.

3.2. Placement Options

The timer offers multiple convenient placement methods:

- **Magnetic Attachment:** Utilize the two strong, silicone-covered magnets on the back to securely attach the timer to any metal surface, such as a refrigerator or whiteboard. The silicone covers prevent scratches.
- **Built-in Stand:** Flip out the integrated stand on the back to place the timer upright on a desktop, countertop, or any flat surface.
- **Hanging Hole:** Use the hanging hole on the back to suspend the timer from a hook or nail.

3 Ways to Place the Digital Timer



Figure 3: The three versatile ways to place the digital timer.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

Press the **Power button** () located on the side of the timer to turn it on or off.

4.2. Setting Time (Countdown Mode)

The timer supports two main modes for setting time: Minute/Second and Hour/Minute.

1. Minute/Second Mode:

- Press the **1M** button to add 1 minute.
- Press the **5M** button to add 5 minutes.
- Press the **1S** button to add 1 second.
- The maximum time in this mode is 59 minutes 59 seconds.

2. Hour/Minute Mode:

- Press the **1H** button to add 1 hour.
- Press the **5M** button to add 5 minutes.
- The maximum time in this mode is 99 hours 59 minutes.

3. **Custom Presets:** Use the **CUSTOM** button to quickly access pre-set countdown times.

4. **Reset:** Press the **RESET** button to clear the current time setting and return to 00:00.



Figure 4: Illustration of the timer's countdown capabilities in different time formats.

4.3. Starting and Stopping the Timer

- Once the desired time is set, press the **STOP/START** button to begin the countdown.
- To pause the timer, press the **STOP/START** button again.
- To resume, press **STOP/START** once more.
- When the countdown reaches 00:00, the alarm will sound. The digits will turn red when the countdown passes 1 minute.

4.4. Stopwatch (Count-Up Mode)

To use the timer as a stopwatch:

- Ensure the timer is reset to 00:00.
- Press the **STOP/START** button to begin counting up from zero.
- Press **STOP/START** to pause, and again to resume.
- The maximum count-up time is 99 hours 59 minutes 59 seconds.

4.5. Adjusting Brightness

The display brightness can be adjusted to three levels:

- Press the **Power button** () repeatedly to cycle through Dim, Medium, and Bright settings.



Figure 5: The three adjustable brightness levels and the low battery indicator.

4.6. Adjusting Alarm Sound and Volume

The timer offers 4 alarm sounds and 3 volume levels:

- **Alarm Sound:** Press the **Music Note button** (🎵) on the side to cycle through the 4 alarm options (Beep, Melody 1, Melody 2, Melody 3).
- **Volume Level:** Press the **Volume button** (🔊) on the side to cycle through Loud (L03), Medium (L02), and Soft (L01) volume levels.

4 Alarms with 3 Levels of Volume

The image shows a kitchen scene with a man in a white shirt and apron and a young girl with braids. In the foreground, a digital timer displays 00:58 in red LEDs. Below the timer, there are four circular icons representing different alarm sounds: a buzzer, a guitar (Melody 1), a piano (Melody 2), and a stringed instrument (Melody 3). To the right of these icons, there are three volume level settings: L01 (60-75dB), L02 (70-85dB), and L03 (80-95dB). The timer has buttons for 1H, 5M, 1M, 1S, CUSTOM, RESET, and STOP/START.

Figure 6: Overview of the available alarm sounds and volume settings.

5. MAINTENANCE

5.1. Charging

The timer is powered by a rechargeable battery. When the low power icon appears on the display, connect the USB-C charging cable to recharge. The timer can be used while charging.

5.2. Cleaning

Wipe the timer with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.

6. TROUBLESHOOTING

6.1. Display Not Lighting Up

- Ensure the timer is powered on by pressing the Power button.
- Check if the battery is low. Connect the USB-C charging cable and allow it to charge.

6.2. Alarm Not Audible Enough

- Press the Volume button () on the side to cycle through the three volume levels (L01, L02, L03) until the desired loudness is achieved.

6.3. Timer Not Responding to Button Presses

- Try resetting the timer by pressing the **RESET** button.
- Ensure the battery is not completely drained. Charge the device if necessary.

7. SPECIFICATIONS

| Feature | Detail |
|------------------------|---|
| Model Number | 5285W |
| Display Type | 7.8-inch LED Digital Display |
| Brightness Levels | 3 (Dim, Medium, Bright) |
| Alarm Options | 4 (Beep, Melody 1, Melody 2, Melody 3) |
| Volume Levels | 3 (Loud: 80-95dB, Medium: 70-85dB, Soft: 60-75dB) |
| Max Countdown Time | 99 Hours 59 Minutes |
| Max Count-Up Time | 99 Hours 59 Minutes 59 Seconds |
| Power Source | Rechargeable Battery (USB-C) |
| Material | Silicone (for magnet covers) |
| Dimensions (D x W x H) | 1.38" x 8.27" x 4.13" |
| Item Weight | 9.8 ounces (278 Grams) |



Figure 7: Detailed dimensions of the VOCOO Digital Kitchen Timer.

8. WARRANTY AND SUPPORT

For any questions or support regarding your VOCOO Digital Kitchen Timer, please contact us directly:

- **Email:** support@vocoo.vip

Please refer to the original product packaging or purchase documentation for specific warranty details.