

[manuals.plus](#) /› [BESTHERM](#) /› [BESTHERM ARIA 2000W Electric Ceramic Dry Inertia Radiator User Manual](#)**BESTHERM ARIA HT20PDC**

BESTHERM ARIA 2000W Electric Ceramic Dry Inertia Radiator User Manual

Model: ARIA HT20PDC

1. INTRODUCTION

Thank you for choosing the BESTHERM ARIA 2000W Electric Ceramic Dry Inertia Radiator. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new heating appliance. Please read these instructions carefully before use and retain them for future reference.

1.1. Product Overview

The BESTHERM ARIA radiator features a ceramic heating core that provides optimal heating comfort through dry inertia technology. It ensures a gentle, even, and lasting heat distribution, even after the unit is turned off, contributing to daily energy savings. The intuitive digital touch panel and LCD screen allow for easy programming and control.

INSTALLATION & PROGRAMMATION



Scannez ce QR CODE

Découvrez nos vidéos de programmation & d'installation !

Image 1.1: The BESTHERM ARIA 2000W radiator, highlighting its ceramic heating core and 2-year warranty.

1.2. Safety Information

Always adhere to local electrical codes and safety regulations during installation and operation. Ensure the appliance is properly grounded. Do not cover the radiator, as this can lead to overheating. Keep children away from the appliance and utilize the child lock feature. Disconnect power before any maintenance or cleaning.

2. INSTALLATION AND SETUP

The BESTHERM ARIA radiator is designed for wall mounting. Ensure the mounting surface is stable and capable of supporting the appliance's weight (approximately 8.1 kg).

2.1. Dimensions and Placement

The radiator measures 86.4 cm (width) x 45 cm (height) x 11 cm (depth). It is suitable for heating areas of 15 to 20 m². Ensure adequate clearance around the radiator for proper heat circulation.

RACCORDEMENT

Cet appareil se branche en triphasé.

Toujours brancher le Neutre et la Phase.

Fil Marron
(ou rouge)
= Phase

Fil Bleu
= Neutre

!

Raccorder le fil Noir uniquement pour un contrôle via un thermostat central.

Ne pas connecter à la terre !




Image 2.1: Radiator dimensions and recommended heating area.

2.2. Electrical Connection

This appliance requires a 240 Volts AC electrical supply. It is designed for connection to a three-phase system. A qualified electrician should perform the installation to ensure compliance with all electrical standards.

- Always connect the **Neutral** (Blue wire) and **Phase** (Brown or Red wire).
- The Black wire should only be connected for control via a central thermostat.
- **Do not connect the Black wire to ground.**



Image 2.2: Electrical wiring instructions for the radiator.

2.3. Installation and Programming Videos

For detailed visual guides on installation and programming, please refer to the official BESTHERM YouTube channel. Scan the QR code below or visit the provided link:



Image 2.3: Scan this QR code for video tutorials.

Official YouTube Channel: youtube.com/channel/UC-sOfckFt_UyYxoDYUZ95Ew

3. OPERATION AND PROGRAMMING

The BESTHERM ARIA radiator features an intuitive digital touch panel and LCD screen for easy control and programming.

3.1. Control Interface

Navigate the digital touch panel to access various settings and modes. The LCD screen displays current temperature, mode, and programming information.

3.2. Heating Modes

The radiator offers 6 distinct modes, which can be selected via the pilot wire (if connected to a central thermostat) or directly through the interface:

- **Comfort:** Maintains your desired comfort temperature.
- **Comfort -1°C:** Maintains temperature 1°C below comfort setting.
- **Comfort -2°C:** Maintains temperature 2°C below comfort setting.
- **Eco:** Energy-saving mode, typically a few degrees below comfort.
- **Off-Gel (Frost Protection):** Prevents freezing by maintaining a minimum temperature (e.g., 7°C).
- **Off:** Turns the heating off.

3.3. Weekly Programming

Customize your heating schedule to match your lifestyle and optimize energy consumption. You can choose from three pre-recorded weekly programs (P1/P2/P3) or create your own personalized weekly program.

- **Pre-recorded Programs (P1/P2/P3):** Select one of the factory-set programs designed for common usage patterns.
- **Custom Program:** Define specific temperature settings for different times of day and days of the week.

3.4. Advanced Features

- **Automatic Window Opening Detector:** The radiator can detect open windows and temporarily reduce heating to save energy.
- **Child Lock:** Prevents accidental changes to settings, ensuring safety.
- **Overheat Protection:** Automatically shuts off the unit if it detects excessive temperatures.
- **Silent Operation:** Designed to operate quietly for minimal disturbance.

4. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your radiator.

4.1. Cleaning

- Always disconnect the radiator from the power supply before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- Ensure no liquid enters the appliance.
- Dust accumulation can affect efficiency. Periodically clean dust from the air vents using a soft brush or vacuum cleaner.

5. TROUBLESHOOTING

If you encounter issues with your BESTHERM ARIA radiator, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Radiator does not heat	No power supply Incorrect mode selected Overheat protection activated	Check power connection and circuit breaker Select a heating mode (Comfort, Eco) Unplug, wait 30 minutes, then plug back in
Display is off or unresponsive	Power issue Child lock activated	Check power supply Deactivate child lock as per manual instructions
Inconsistent heating	Window open detector activated Incorrect programming	Close windows or disable detector Review and adjust weekly program settings

If the problem persists after attempting these solutions, please contact customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	BESTHERM
Model Number	HT20PDC
Color	White
Product Dimensions (D x W x H)	11 x 86.4 x 45 cm
Item Weight	8.1 Kilograms
Voltage	240 Volts (AC)
Number of Modes	6
Special Features	Overheat protection, Silent operation, Programmable thermostat, Electronic thermostat, Child lock
Power Source	Electric cable
Heating Method	Convection (Ceramic Dry Inertia)
Mounting Type	Wall mount
Indoor/Outdoor Use	Indoor

7. WARRANTY INFORMATION

The BESTHERM ARIA radiator comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for

warranty claims. The warranty does not cover damage resulting from improper installation, misuse, neglect, or unauthorized repairs.

8. SUPPORT

For any questions, technical assistance, or warranty claims, please contact our customer service. Our French-based after-sales service is dedicated to ensuring your satisfaction.

Image 8.1: BESTHERM customer support details.

Online FAQ: Visit our website for frequently asked questions: www.bestherm.fr/pages/faq

Phone Support: 03 20 47 05 37

Email Support: sav@hom-y.fr

© 2025 BESTHERM. All rights reserved.

Related Documents - ARIA HT20PDC

 <p>Bestherm® MANUEL D'INSTRUCTIONS ARIA Modèle : HT5PDC Traduction de la version originale du manuel d'instructions CE</p>	<p><u>Manuel d'instructions Bestherm ARIA HT5PDC</u></p> <p>Ce manuel d'instructions fournit des informations détaillées sur l'installation, l'utilisation et la sécurité du radiateur Bestherm ARIA, modèle HT5PDC. Découvrez ses fonctionnalités, modes et réglages pour un chauffage optimal.</p>
 <p>Bestherm® MANUEL D'INSTRUCTIONS LEA Modèles : HT10-24AEF, HT15-24AEF, HT20-24AEF Traduction de la version originale du manuel d'instructions CE</p>	<p><u>Bestherm LEA Electric Heater: Installation, Operation, and Safety Manual</u></p> <p>Comprehensive user manual and technical specifications for the Bestherm LEA electric heater (models HT10-24AEF, HT15-24AEF, HT20-24AEF), covering safety guidelines, installation procedures, operation, technical specifications, and maintenance.</p>
 <p>Bestherm® MANUEL D'INSTRUCTIONS Lucca Modèles : HR10-T13H, HR15-T13H, HR20-T13H Traduction de la version originale du manuel d'instructions NF CE</p>	<p><u>Bestherm Lucca Heater Instruction Manual</u></p> <p>Comprehensive instruction manual for the Bestherm Lucca heater, covering safety guidelines, installation, electrical connection, and operational modes. Learn how to set up and use your Lucca heater efficiently.</p>

 Bestherm Hanae Radiateur Électrique - Manuel d'Instructions <p>Ce manuel d'instructions fournit des informations détaillées sur l'installation, l'utilisation et la maintenance des radiateurs électriques Bestherm Hanae, modèles HJ5EDBF et HJ8EDBF.</p>	
 Bestherm NESSA CONNECT: Manuel d'instructions pour radiateur électrique HT10-23AEW, HT15-23AEW, HT20-23AEW <p>Manuel d'instructions complet pour le radiateur électrique Bestherm NESSA CONNECT. Découvrez comment installer, utiliser et entretenir votre appareil en toute sécurité. Inclut les modèles HT10-23AEW, HT15-23AEW, HT20-23AEW.</p>	
 Manuel d'instructions Bestherm ARIA HT5PDC <p>Ce manuel d'instructions fournit des informations détaillées sur l'installation, l'utilisation et la sécurité du radiateur Bestherm ARIA, modèle HT5PDC. Découvrez ses fonctionnalités, modes et réglages pour un chauffage optimal.</p>	