

CakCity 2093

CakCity Model 2093 Digital Sport Watch Instruction Manual

Model: 2093

INTRODUCTION

Thank you for choosing the CakCity Model 2093 Digital Sport Watch. This manual provides detailed instructions for setting up and operating your watch, ensuring you can fully utilize its features, including time display, alarm, stopwatch, countdown timer, and EL backlight. Designed for durability and functionality, this watch is 5ATM water-resistant, making it suitable for various sports and daily activities.



This image highlights the key features of the CakCity digital sport watch, including its alarm clock, stopwatch, week and date display, luminous backlight, 12/24 hour time format, and 5ATM water resistance. The watch face shows the time 12:32 PM and the date WED 8-20.

WATCH COMPONENTS AND BUTTONS

Your CakCity Model 2093 watch features a clear digital display and four control buttons located on the sides of the watch case. Familiarize yourself with these buttons for easy operation:

- **Button A (Top Left):** Used for EL backlight activation.
- **Button B (Top Right):** Used for starting/stopping functions and setting adjustments.
- **Button C (Bottom Left):** Used to cycle through different modes (Time, Alarm, Stopwatch, Countdown).
- **Button D (Bottom Right):** Used for resetting values and selecting items during setting.



Alarm Clock



Stopwatch



Week&Date



Luminous
Display



12/24 Hour
Format



5ATM
Waterproof

A clear front view of the CakCity Model 2093 digital sport watch. The watch features a blue camouflage strap and a large, easy-to-read digital display. The four control buttons are visible on the sides of the watch case.

SETUP

Setting Time and Date

1. From the Timekeeping Mode, press **Button C** three times to enter the Time Setting Mode. The

seconds digits will flash.

2. Press **Button D** to reset the seconds to 00.
3. Press **Button C** to move the flashing selection to the hour digits.
4. Press **Button B** to adjust the hour. Note the 'A' (AM) or 'P' (PM) indicator for 12-hour format.
5. Press **Button C** to move the flashing selection to the minute digits.
6. Press **Button B** to adjust the minutes.
7. Continue pressing **Button C** to cycle through year, month, and day settings, adjusting each with **Button B**.
8. Once all settings are correct, press **Button C** again to exit the Time Setting Mode.

12/24 Hour Format Selection

In Timekeeping Mode, press **Button B** to toggle between 12-hour and 24-hour time formats. The 'A' or 'P' indicator will disappear in 24-hour format.

OPERATING MODES

Timekeeping Mode

This is the default mode, displaying the current time, day of the week, and date. Press **Button A** to activate the EL backlight.

Alarm Mode

1. From Timekeeping Mode, press **Button C** once to enter Alarm Mode. The alarm time will be displayed.
2. Press **Button B** to toggle the alarm ON/OFF. An alarm icon will appear when activated.
3. To set the alarm time, press **Button D**. The hour digits will flash.
4. Press **Button B** to adjust the hour.
5. Press **Button C** to move to the minute digits.
6. Press **Button B** to adjust the minutes.
7. Press **Button D** to confirm and exit alarm setting.
8. Press **Button C** to return to Timekeeping Mode.

Stopwatch Mode

1. From Timekeeping Mode, press **Button C** twice to enter Stopwatch Mode.
2. Press **Button B** to start the stopwatch.
3. Press **Button B** again to stop the stopwatch.
4. Press **Button D** to reset the stopwatch to zero.
5. Press **Button C** to return to Timekeeping Mode.

Countdown Timer Mode

1. From Timekeeping Mode, press **Button C** three times to enter Countdown Timer Mode.
2. To set the countdown time, press and hold **Button D** until the digits flash.
3. Press **Button C** to select hours, minutes, or seconds.
4. Press **Button B** to adjust the selected value.

5. Press **Button D** to confirm the setting.
6. Press **Button B** to start the countdown.
7. Press **Button B** again to pause/resume the countdown.
8. When paused, press **Button D** to reset the timer to its initial set value.
9. Press **Button C** to return to Timekeeping Mode.

EL Backlight

Press **Button A** (Top Left) at any time to illuminate the watch display for a few seconds, allowing for clear visibility in low-light conditions.



This image demonstrates the watch's EL backlight feature. One watch shows the normal display, while the other shows the display brightly illuminated by the EL lamp, making it easy to read the time in low-light conditions.

WATER RESISTANCE (5ATM / 50M)

Your CakCity Model 2093 watch is rated for 5ATM (50 meters) water resistance. This means it is suitable for:

- Washing hands
- Swimming in shallow water
- Exposure to rain
- Cold showering

Important Precautions:

- **Do NOT press any buttons while the watch is submerged in water.** This can compromise the water seal.
- Avoid wearing the watch in hot water baths, saunas, or hot springs. Extreme temperatures can damage the watch's seals and reduce its lifespan.

- After swimming or exercising, promptly clean the outer shell to prevent damage from seawater or sweat corrosion.



The image shows the CakCity digital watch in a swimming pool, emphasizing its 50-meter water resistance. Icons below the watch indicate suitability for washing hands, swimming, use in rain, and bathing.

MAINTENANCE

Cleaning

To keep your watch in good condition, wipe it regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying. Avoid harsh chemicals or abrasive cleaners.

Battery Replacement

The watch uses one CR2032 battery (included). When the display becomes dim or the watch stops functioning, it may be time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure the water resistance seal is properly maintained.

TROUBLESHOOTING

- **Display is blank or dim:** The battery may be low or depleted. Replace the CR2032 battery.
- **Time is incorrect:** Re-enter the Time Setting Mode and adjust the time, date, and year as per the 'Setting Time and Date' instructions.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not specify one). If the issue persists, a battery reset (removing and reinserting the battery) might be necessary, but this should be done by a professional to preserve water resistance.
- **Water inside the watch:** Immediately stop using the watch and seek professional service. Do not attempt to open the watch yourself, as this will void any potential warranty and further damage the watch.

SPECIFICATIONS



This graphic provides a comprehensive list of the watch's product parameters, including brand, model, weight, movement type, and water resistance.

Feature	Specification
Brand	CakCity
Model Number	2093
Movement	Digital
Case Material	ABS
Crystal Material	Resin
Band Material	TPU
Clasp Type	Buckle (Stainless Steel)
Water Resistance	5ATM (50 Meters / 164 Feet)
Functions	Dual Time, Chronograph (Stopwatch), Alarm, Date, Week, EL Light, 12/24 Hour Clock, Countdown Timer
Battery Type	CR2032 (included)
Net Weight	46 grams (1.62 ounces)
Case Width	46mm
Case Thickness	11.9mm
Band Width	22mm

Watch Length	255mm
--------------	-------



This diagram helps users determine the right watch fit by showing two wrist circumference examples: 220mm and 150mm.

WARRANTY AND SUPPORT

CakCity is committed to providing quality products. While specific warranty details are not provided in this manual, if you encounter any issues or have questions regarding your CakCity Model 2093 watch, please do not hesitate to contact the seller or CakCity customer support. Refer to your purchase documentation for contact information.