

Jocca 2157RF

JOCCA 7L Air Fryer User Manual

Model: 2157RF

1. INTRODUCTION

Thank you for choosing the JOCCA 7L Air Fryer. This appliance is designed to help you prepare delicious and healthy meals with significantly less oil. Its advanced features, including a transparent viewing window, intuitive touchscreen, and multiple preset programs, make cooking convenient and enjoyable. Please read this manual thoroughly before first use to ensure safe and optimal operation of your new air fryer.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs. The cool-touch handle is designed for safe handling of the basket.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Ensure adequate ventilation around the appliance during use.
- This appliance is for household use only.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your JOCCA 7L Air Fryer.



Figure 3.1: Front view of the JOCCA 7L Air Fryer, showing the main unit, handle, and transparent viewing window.



Figure 3.2: The air fryer with its cooking basket partially pulled out, revealing the interior cooking space and removable drip tray.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Intuitive touchscreen for setting temperature, time, and selecting preset programs.
- **Cooking Basket:** The main cooking compartment for food.
- **Removable Drip Tray:** Sits at the bottom of the basket to collect excess oil and fat.
- **Cool-Touch Handle:** For safe removal and insertion of the cooking basket.
- **Transparent Viewing Window:** Allows you to monitor the cooking process without opening the basket.

Control Panel Overview:



Figure 3.3: Detailed view of the digital touchscreen control panel, showing various icons for preset programs, temperature, and timer controls.

The digital touchscreen allows for easy control of all functions. It features icons for 8 preset cooking programs, temperature adjustment buttons (up/down), timer adjustment buttons (up/down), a power button, and a start/pause button.

4. SETUP

4.1 Unpacking

- Carefully remove all packaging materials from the air fryer.
- Check that all components are present and undamaged.
- Keep packaging materials out of reach of children.

4.2 Before First Use

- Wipe the exterior of the appliance with a damp cloth.

- Wash the cooking basket and drip tray thoroughly with warm, soapy water. Rinse and dry completely.
- Do not use abrasive cleaning agents or scouring pads, as this may damage the non-stick coating.

4.3 Placement

- Place the air fryer on a stable, heat-resistant, and level surface.
- Ensure there is at least 10 cm (4 inches) of clear space on all sides of the appliance to allow for proper air circulation.
- Do not place the air fryer near flammable materials or heat sources.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. Plug the power cord into a grounded wall outlet. The air fryer will beep, and the display will light up.
2. Pull out the cooking basket using the cool-touch handle. Place food inside the basket, ensuring not to overfill. The maximum capacity is 7.4 liters.
3. Slide the cooking basket back into the air fryer until it clicks into place.
4. **Setting Temperature and Time:**
 - Press the power button to turn on the display.
 - Use the temperature adjustment buttons (up/down arrows with °C icon) to set the desired temperature between 80°C and 200°C.
 - Use the timer adjustment buttons (up/down arrows with clock icon) to set the cooking time, up to 60 minutes.
 - Press the start/pause button to begin cooking.
5. **Using Preset Programs:**
 - After turning on the display, select one of the 8 preset programs by touching the corresponding icon. Each program has a default temperature and time.
 - You can adjust the temperature and time of a preset program if needed, before pressing start.
 - Press the start/pause button to begin cooking.
6. **Monitoring Cooking:** The transparent viewing window allows you to check on your food without interrupting the cooking cycle. The internal light can be activated to improve visibility.
7. **Shaking Food:** For some recipes, it is recommended to shake the basket halfway through cooking to ensure even crisping. Pull out the basket, shake gently, and reinsert. The air fryer will automatically resume cooking.
8. **Completion:** Once the timer reaches zero, the air fryer will emit an acoustic signal and automatically shut off.
9. Carefully pull out the basket and transfer the cooked food to a serving dish. Use heat-resistant tongs or utensils.
10. Unplug the appliance after use.

6. COOKING GUIDE

The JOCCA 7L Air Fryer is incredibly versatile, allowing you to fry, bake, grill, reheat, and defrost a wide variety of foods with minimal oil.

- **Oil Usage:** While the air fryer cooks with hot air, a small amount of oil (1 tablespoon or less) can enhance crispiness and flavor for certain foods, especially fresh vegetables or homemade fries.
- **Food Preparation:** Ensure food is cut into uniform pieces for even cooking. Pat dry any moist foods to achieve a

crispier result.

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired cooking temperature before adding food.
- **Batch Cooking:** Avoid overcrowding the basket. Cook in smaller batches if necessary to ensure proper air circulation and even cooking.
- **Temperature and Time:** Cooking times and temperatures may vary based on food type, quantity, and desired crispiness. Refer to specific recipes or adjust as needed.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Cleaning the Basket and Drip Tray:**
 - Remove the cooking basket and drip tray.
 - Wash them in warm, soapy water. The non-stick coating makes cleaning easy.
 - For stubborn residue, soak them in warm water for about 10 minutes before cleaning.
 - Rinse thoroughly and dry completely before reassembling.
3. **Cleaning the Interior:** Wipe the interior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or steel wool.
4. **Cleaning the Exterior:** Wipe the exterior surface with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure the air fryer is clean and dry before storing. Store it in a cool, dry place.

8. TROUBLESHOOTING

If you encounter any issues with your air fryer, please refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; basket not properly inserted.	Ensure the power cord is securely plugged into a working outlet. Check if the cooking basket is fully pushed in until it clicks.
Food is not cooked evenly.	Basket is overcrowded; food pieces are too large or unevenly cut; not shaking the basket.	Cook in smaller batches. Cut food into uniform sizes. Shake the basket halfway through cooking.
Food is not crispy.	Too much moisture in food; not enough oil (for certain foods); temperature too low.	Pat food dry before cooking. Lightly brush or spray with oil. Increase temperature or cooking time slightly.
White smoke coming from the appliance.	Grease residue from previous use; cooking fatty foods.	Clean the basket and drip tray thoroughly after each use. For fatty foods, add a small amount of water to the drip tray to prevent smoke.

If the problem persists after trying these solutions, please contact customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	Jocca
Model Number	2157RF
Capacity	7.4 Liters
Power	1800 Watts
Voltage	220 Volt
Product Dimensions (L x W x H)	25.8 x 29.1 x 31.8 cm
Item Weight	5.1 Kilograms
Material	Polypropylene (PP)
Temperature Range	80°C - 200°C
Timer Range	Up to 60 minutes
Special Features	Programmable, Automatic Shut-off, Transparent Viewing Window, Cool-Touch Handle, BPA/PFOA Free

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your purchase or contact the retailer where the product was purchased. You may also visit the official Jocca website for further assistance and contact details.

For more information about JOCCA products, visit the official store:[Jocca Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question