

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WILSON](#) /

› [Wilson Rush Pro 4.0 Men's Tennis Shoes User Manual](#)

WILSON Rush Pro 4.0

Wilson Rush Pro 4.0 Men's Tennis Shoes User Manual

Model: Rush Pro 4.0 (WRS330630-B)

INTRODUCTION

The Wilson Rush Pro 4.0 tennis shoes are engineered to enhance dynamic court movement. This model features advancements in both midsole and outsole construction, building upon the Rush Pro 3.5 chassis. The design integrates a sleek silhouette with performance-driven technology to support players during intense racquet sports.

PRODUCT FEATURES

- **4D Support Chassis 2.0:** This evolved chassis construction is split into two distinct pieces. One piece is positioned under the foot to provide enhanced support and facilitate forward propulsion. The second piece runs laterally, contributing to additional stability and control during quick movements.
- **Energy Cell:** Located in the forefoot of the midsole, Energy Cell utilizes a lightweight EVA foam. This material is designed to optimize the transfer of body weight upon impact, resulting in more explosive propulsion for agile court play.
- **Durable Outsole:** The rubber sole provides reliable traction and durability on various court surfaces.
- **Breathable Upper:** Constructed with mesh outer material for ventilation and comfort during extended play.



Image: Side view of the Wilson Rush Pro 4.0 shoe, highlighting the 4D Support Chassis 2.0 technology in the midsole.

SETUP AND INITIAL USE

1. **Unboxing:** Remove the shoes from their packaging. Inspect for any visible defects or damage.
2. **Initial Fit:** Wear the shoes with your preferred athletic socks. Lace them up securely but not overly tight. Ensure your toes have adequate space at the front without excessive movement. The fit should be snug around the midfoot and heel.
3. **Break-in Period:** While designed for comfort out of the box, a short break-in period during light activities is recommended to allow the shoes to conform to your foot shape.



Image: Front-side view of the Wilson Rush Pro 4.0, illustrating the lacing system and overall shoe structure.

OPERATING AND USAGE GUIDELINES

The Wilson Rush Pro 4.0 shoes are specifically designed for tennis and other racquet sports, providing stability and responsiveness for court-specific movements.

- **Court Surface:** These shoes are suitable for various court surfaces, including hard courts, clay courts, and grass courts, offering appropriate traction.
- **Movement Support:** The 4D Support Chassis 2.0 assists in lateral stability during quick changes in direction and provides support for forward propulsion during sprints and lunges.
- **Energy Return:** The Energy Cell in the forefoot is engineered to enhance energy return, aiding in explosive push-offs and agile footwork.
- **Lacing:** Ensure laces are tied securely before play to prevent slippage and provide optimal foot lockdown.

MAINTENANCE AND CARE

Proper care extends the lifespan and maintains the performance of your Wilson Rush Pro 4.0 tennis shoes.

- **Cleaning:**

- For mesh and outer material: Use a soft brush or cloth with mild soap and cold water to gently clean dirt and debris. Avoid harsh chemicals.
- For soles: Use a stiff brush to remove dirt and clay from the rubber outsole to maintain traction.
- Do not machine wash or machine dry, as this can damage materials and adhesives.

- **Drying:** Allow shoes to air dry naturally at room temperature. Avoid direct sunlight or heat sources, which can cause material degradation.

- **Storage:** Store shoes in a cool, dry place away from direct sunlight when not in use. Consider using shoe trees to help maintain their shape.

- **Odor Control:** If odors develop, remove insoles and allow them to air out. Shoe deodorizers can also be used.



Image: Top-down view of the Wilson Rush Pro 4.0, illustrating the mesh upper for breathability.

TROUBLESHOOTING

- **Discomfort or Rubbing:**

- Ensure correct sizing. Foot swelling can occur during play, so try shoes on after activity.

- Adjust lacing tension. Experiment with different lacing patterns to alleviate pressure points.
- Consider different socks or aftermarket insoles for additional cushioning or arch support.

- **Reduced Traction:**

- Clean the outsole regularly to remove accumulated dirt and debris.
- Inspect the sole for excessive wear. Worn-out treads will reduce grip and indicate it's time for replacement.

- **Excessive Wear:**

- The lifespan of tennis shoes varies based on frequency and intensity of play, court surface, and individual movement patterns.
- Look for signs of wear such as worn-through outsoles, collapsed cushioning, or upper material damage.

SPECIFICATIONS

Model Name	Rush Pro 4.0
Item Model Number	WRS330630-B
Brand	WILSON
Department	Mens
Sport Type	Tennis, Running
Outer Material	Mesh
Sole Material	Rubber
Insole Material	Ethylene Vinyl Acetate
Closure Type	Lace-Up
Heel Type	Flat
Toe Style	Round Toe
Item Weight	2 Pounds
Origin	Imported
UPC	097512563680



Image: Close-up side view of the Wilson Rush Pro 4.0 heel, detailing the RUSH PRO and ENERGY CELL branding.

WARRANTY INFORMATION

For detailed warranty information regarding your Wilson Rush Pro 4.0 tennis shoes, please refer to the official WILSON website or contact their customer service directly. Warranty terms and conditions may vary by region and purchase location.

SUPPORT AND CONTACT

Should you require further assistance, have questions about your product, or need to report an issue, please contact WILSON customer support.

- **Official Website:** Visit the [WILSON official website](#) for product information, FAQs, and support resources.
- **Customer Service:** Refer to the contact section on the WILSON website for phone numbers or email support options specific to your region.