

2198585

Os-ter 2198585 Pro Series Kitchen System XL Blender and Food Processor Combo 1000W User Manual

Model: 2198585 | Brand: Generic

1. INTRODUCTION

The Generic Pro Series Kitchen System XL is a versatile appliance designed to simplify your food preparation tasks. This powerful 1000-watt system combines the functionality of a blender and a food processor, allowing you to blend, crush, puree, liquify, slice, and chop a wide range of ingredients. Its intuitive touchscreen controls and robust design ensure efficient and consistent results for various recipes, from smooth beverages to chunky salsas.

Important Safety Information

- Always read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender.
- Ensure the appliance is unplugged from the outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.

2. COMPONENTS

The Pro Series Kitchen System XL includes the following main components:

- **Motor Base:** The main unit housing the 1000-watt motor and touchscreen controls.
- **XL 9-Cup Tritan Blender Jar:** A large capacity jar for blending liquids and soft ingredients.
- **Blender Blade Assembly:** The blade unit that attaches to the blender jar.
- **Blender Jar Lid:** For covering the blender jar during operation.
- **5-Cup Food Processor Attachment:** A bowl and lid assembly for food processing tasks.
- **Slicing Disk:** For slicing and shredding ingredients in the food processor.
- **Chopping Blade:** For chopping and mincing ingredients in the food processor.
- **Tamper Tool:** Used to push ingredients towards the blade in the blender jar.



Figure 2.1: Overview of the Oster Pro Series Kitchen System XL, showing the motor base, XL 9-cup blender jar with lid, 5-cup food processor attachment, slicing disk, chopping blade, and tamper tool.

3. SETUP AND ASSEMBLY

3.1 Assembling the Blender

1. Place the motor base on a clean, dry, and stable surface.
2. Ensure the blender blade assembly is securely attached to the bottom of the XL 9-cup Tritan blender jar.
3. Add your ingredients to the blender jar. Do not exceed the maximum fill line.
4. Place the lid securely on the blender jar.
5. Align the blender jar with the motor base and twist clockwise until it locks into place.
6. Plug the appliance into a standard electrical outlet.

3.2 Assembling the Food Processor

1. Place the motor base on a clean, dry, and stable surface.
2. Attach the food processor bowl to the motor base by aligning it and twisting clockwise until it locks.
3. Insert either the chopping blade or the slicing disk onto the central spindle within the food processor bowl.

4. Add your ingredients to the food processor bowl.
5. Secure the food processor lid onto the bowl, ensuring it clicks into place.
6. Plug the appliance into a standard electrical outlet.

4. OPERATING INSTRUCTIONS

The Pro Series Kitchen System XL features a modern touchscreen interface for easy operation.

4.1 Controls and Programs

- **Power Button:** Turns the appliance on/off.
- **Speed Settings (1-7):** Manually adjust the blending/processing speed for precise control.
- **Pulse Button:** Provides short bursts of power for chopping or quick blending.
- **Auto Programs:** The system includes 3 pre-programmed settings for common tasks:
 - **Smoothie:** Optimized for blending fruits and liquids into smooth beverages.
 - **Salsa:** Designed for chopping and mixing ingredients to a chunky consistency.
 - **Puree:** For creating smooth purees from cooked vegetables or fruits.

4.2 Using the Blender

1. Ensure the blender jar is properly assembled and locked onto the motor base.
2. Add ingredients. For best results, add liquids first, then soft ingredients, then hard ingredients, and finally ice.
3. Select your desired speed or an auto program (Smoothie, Puree).
4. Press the Power button to start.
5. Use the tamper tool if needed to push ingredients towards the blade, but only through the lid opening and never when the appliance is running without the lid.
6. Once blending is complete, press the Power button to stop and unplug the appliance before removing the jar.

4.3 Using the Food Processor

1. Ensure the food processor attachment is properly assembled with the desired blade (chopping or slicing disk) and locked onto the motor base.
2. Add ingredients to the food processor bowl. For chopping, cut large ingredients into smaller, uniform pieces.
3. Secure the lid.
4. Select a speed or the Salsa auto program. Use the Pulse function for controlled chopping.
5. Press the Power button to start.
6. For slicing, feed ingredients through the feed tube in the lid.
7. Once processing is complete, press the Power button to stop and unplug the appliance before disassembling.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

- **Unplug Before Cleaning:** Always ensure the appliance is unplugged from the power outlet before cleaning.
- **Dishwasher Safe Parts:** The BPA-free Tritan blender jar and food processor attachment are dishwasher safe for easy cleaning. Place them on the top rack of your dishwasher.
- **Hand Washing:** For hand washing, use warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry immediately. Be cautious when handling sharp blades.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
- **Storage:** Store the appliance in a clean, dry place, ensuring all parts are completely dry before storage.

6. TROUBLESHOOTING

If you encounter issues with your Pro Series Kitchen System XL, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; jar/bowl not properly locked; power outage.	Ensure appliance is securely plugged in. Check that the blender jar or food processor bowl is correctly assembled and locked onto the base. Verify power supply.
Ingredients are not blending/processing smoothly.	Too little liquid; too many ingredients; ingredients are too large or hard.	Add more liquid. Reduce the amount of ingredients. Cut hard ingredients into smaller pieces. Use the tamper tool to push ingredients towards the blade. Increase speed or use Pulse.
Motor smells or overheats.	Overloading; continuous operation for too long.	Unplug the appliance and allow it to cool down for at least 15-20 minutes. Reduce the load of ingredients. Avoid continuous operation for extended periods.
Loud noise during operation.	Jar/bowl not seated correctly; foreign object in jar/bowl; worn blade.	Ensure the jar or bowl is securely locked onto the base. Check for any foreign objects. If noise persists and performance degrades, the blade assembly may need replacement.

7. SPECIFICATIONS

- **Model Name:** Pro Series Kitchen System XL Blender and Food Processor Combo 1000W
- **Model Number:** 2198585
- **Brand:** Generic
- **Power:** 1000 Watts
- **Blender Jar Capacity:** XL 9-Cup (Tritan, BPA-free)
- **Food Processor Bowl Capacity:** 5 Cups
- **Number of Speeds:** 7
- **Auto Programs:** 3 (Smoothie, Salsa, Puree) + Pulse
- **Product Dimensions:** 16"D x 16"W x 16"H
- **Color:** Silver
- **Blade Material:** Metal
- **Care Instructions:** Dishwasher Safe (jar and attachment)
- **Item Weight:** Approximately 12.07 pounds
- **Power Source:** AC Adapter
- **UPC:** 053891167666

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or contact the manufacturer's customer service.

You may also visit the official brand website for frequently asked questions and additional support resources.



