

Creality Creality Falcon 2 Pro 40W

Creality Falcon2 Pro 40W Laser Engraver User Manual

Comprehensive Guide for Operation and Maintenance

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your Creality Falcon2 Pro 40W Laser Engraver. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage or injury.

The Creality Falcon2 Pro 40W is an enclosed laser engraving and cutting machine designed for precision work on a variety of materials, including wood, metal, and acrylic. It features a 40W laser output, high-speed engraving capabilities, an integrated air assist system, automatic fan, LED work light, and camera positioning for enhanced accuracy and user experience.

2. SAFETY INFORMATION

WARNING: Laser radiation can cause eye and skin damage. Always follow safety precautions. This device is a Class 1 laser product when the enclosure is closed, but the internal laser module is Class 4. Never operate with the enclosure open or bypass safety interlocks.

- Always wear appropriate laser safety goggles when the laser is active and visible.
- Ensure the machine is placed on a stable, level, and fire-resistant surface.
- Do not leave the machine unattended during operation.
- Keep flammable materials away from the working area.
- Ensure proper ventilation to dissipate fumes and smoke generated during engraving/cutting. The integrated air assist and fan help, but additional room ventilation may be required.
- Do not attempt to modify the laser module or any part of the machine.
- In case of emergency, immediately press the emergency stop button.
- The machine is equipped with safety features such as automatic stopping when the lid is opened or the tray is pulled out, and an alarm for tipping or accidental movement.

Safe and FDA Safety Certification




Image: Overview of the Creality Falcon2 Pro 40W highlighting its safety features, including the visible body to prevent laser exposure, automatic fan and air assist, laser module indicator lights (Air, Fire, Lens), emergency stop button, and automatic stopping mechanisms for lid and tray.

3. PRODUCT OVERVIEW

3.1 Components

- **Main Unit:** Enclosed laser engraver with integrated controls.
- **Laser Module:** 40W output laser, with a 1.6W module included for finer tasks.
- **Protective Enclosure:** Fully transparent, Class 1 certified when closed.
- **Air Assist System:** Built-in, automatically activated with operation.
- **Built-in Fan:** Automatically activated for smoke extraction.
- **LED Work Light:** Illuminates the working area.
- **Camera:** For precise positioning and batch engraving.
- **Metal Steel Bar Support and Tray:** For material placement.

- **Emergency Stop Button:** For immediate shutdown.
- **Safety Lock:** Prevents unauthorized operation.

3.2 Key Features

- **Powerful 40W Laser Output:** Capable of cutting 20mm basswood, 30mm black acrylic, or 0.15mm stainless steel in a single pass.
- **High-Speed Engraving:** Up to 25000mm/min for efficient project completion.
- **Precision Engraving & Cutting:** 0.06*0.1mm super fine spot focus for accuracy within 0.003 inches.
- **Integrated Safety Features:** Enclosed design, automatic fan/air assist, multi-sensor monitoring (airflow, lens, flame), lid/tray interlocks, emergency stop, and safety lock.
- **Camera Positioning:** Enables precise pattern alignment and batch engraving/cutting (requires computer connection and software setup).
- **Wide Material Compatibility:** Engraves and cuts various materials including wood, metal, acrylic, leather, ceramics, glass, and more.
- **User-Friendly Software Compatibility:** Supports LightBurn (for experienced users) and LaserGRBL (for new users). Data transfer via TF card.



Image: The Creality Falcon2 Pro 40W laser engraver shown with examples of engraved and cut materials, including wood, a small wooden airplane, a cutting board, and a baseball bat, demonstrating its versatility.

Cleaner Cut and More Precise Engrave




Image: A detailed view of the laser module in action, illustrating its cutting capabilities: 0.15mm stainless steel, 20mm basswood, and 30mm opaque acrylic, all in a single pass.

Faster and More Accurate



Image: This graphic compares the engraving speed of the Falcon2 Pro 40W (25000mm/min) to other machines (15000mm/min), and highlights its fine laser spot size of 0.1mm/0.15mm for precise results.

4. SETUP

4.1 Unpacking and Inspection

1. Carefully remove all components from the packaging.
2. Verify that all parts listed in the packing list are present and undamaged.
3. Report any missing or damaged parts to Creality customer support immediately.

4.2 Assembly

The Creality Falcon2 Pro 40W comes largely pre-assembled as an enclosed unit. Minor assembly may be required for external components such as the air assist pump connection and the metal steel bar support/tray. Refer to the quick start guide included in your packaging for specific assembly steps.

4.3 Placement

- Place the engraver on a sturdy, level, and non-flammable surface.
- Ensure adequate clearance around the machine for ventilation and access.
- Position the machine in a well-ventilated area, or connect it to an external exhaust system if necessary, to manage fumes.

4.4 Software Installation and Connection

1. Download and install the recommended software:
 - **LightBurn:** Compatible with Windows, Mac, and Linux systems. Recommended for experienced laser users.
 - **LaserGRBL:** Compatible with Windows 7/8/10/XP. Suitable for new laser users.
2. Connect the engraver to your computer via USB cable.
3. For camera positioning functionality, ensure the machine is connected to the computer and follow the software's calibration steps to set up camera parameters.
4. Alternatively, transfer engraving files via TF card for offline operation.

5. OPERATING INSTRUCTIONS

5.1 Preparing for Engraving/Cutting


1. **Material Placement:** Place your material securely on the metal tray inside the enclosure. Ensure it is flat and stable.
2. **Close Enclosure:** Close the transparent lid completely. The built-in fan and air assist will automatically activate.
3. **Software Setup:** Open your chosen software (LightBurn or LaserGRBL).
4. **Import Design:** Import or create your design within the software.
5. **Parameter Settings:** Adjust laser power, speed, and passes according to the material type and desired effect. Refer to material testing guides for optimal settings.
6. **Focus Adjustment:** Ensure the laser is properly focused on the material surface. The camera can assist with precise positioning.

Smarter Camera, Easier Operations

Better for alignment and support for batch engraving or cutting




Camera



Get What U See

No Camera



Get What U Guess

Image: The Creality Falcon2 Pro 40W demonstrating its smart camera feature, which allows for better alignment and supports batch engraving or cutting, ensuring "What U See Is What U Get" results.



Available for More Materials




Image: A display of diverse materials that can be processed by the Creality Falcon2 Pro 40W, including ceramics, leather, glass, food, plywood, cobblestones, solid wood, cardboard, round objects, stainless steel, coated metal, and acrylic.

5.2 Starting Operation

1. Once settings are confirmed, initiate the engraving/cutting process from the software.
2. Monitor the laser module's indicator lights (Airflow, Lens, Flame) to ensure normal operation.
3. Observe the process through the transparent enclosure. Do not open the lid or pull out the tray during operation, as this will automatically stop the machine.

5.3 Using the 1.6W Module

The included 1.6W laser module is ideal for finer engraving tasks where less power and more detail are required. Consult the specific instructions for swapping laser modules and adjusting software settings for the 1.6W module.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Creality Falcon2 Pro 40W.

6.1 Cleaning the Laser Lens

- The laser module has a lens monitor indicator. If it lights up, the lens may be dirty.
- Power off the machine and disconnect it from the power source.
- Carefully clean the laser lens using a lint-free cloth and lens cleaning solution specifically designed for optics.
- Avoid touching the lens with bare hands.

6.2 Cleaning the Enclosure and Tray

- Regularly wipe down the interior of the enclosure and the metal tray to remove debris and residue from engraving/cutting.
- Use a damp cloth; avoid abrasive cleaners.

6.3 Air Assist System Maintenance

- Ensure the air assist nozzle is clear of any blockages.
- Check the air hose for kinks or damage.
- The airflow monitor indicator will alert you to potential issues with the air assist.

6.4 General Inspection

- Periodically inspect all cables and connections for wear or damage.
- Check the gantry and rails for smooth movement and cleanliness.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not power on.	Power cable disconnected, power switch off, faulty power supply.	Check power connections, ensure switch is ON. Test power outlet.
Laser not firing or weak output.	Dirty laser lens, incorrect focus, low power setting, laser module issue.	Clean laser lens. Adjust focus. Increase power setting in software. Contact support if module is faulty.
Engraving/cutting results are inconsistent or inaccurate.	Material not flat, incorrect speed/power settings, loose belts/gantry, dirty rails.	Ensure material is flat and secured. Adjust settings. Check and tighten belts. Clean rails.
Machine stops unexpectedly during operation.	Lid opened, tray pulled out, machine tipped, emergency stop pressed, software error.	Ensure lid is closed and tray is fully inserted. Check machine stability. Reset emergency stop. Restart software/machine.
Airflow monitor light is on.	Air assist hose blocked or disconnected, air pump issue.	Check air assist hose for blockages or disconnections. Ensure air pump is functioning.
Camera positioning is inaccurate.	Improper camera calibration in software.	Recalibrate the camera within the software (LightBurn or LaserGRBL).

8. SPECIFICATIONS

Feature	Detail
Model	Creality Falcon 2 Pro 40W
Laser Output Power	40W (also includes 1.6W module)
Machine Power	Max 240W
Engraving Speed	Up to 25000mm/min
Laser Spot Size	0.06*0.1mm (super fine)
Engraving Accuracy	Within 0.003 inches
Working Area	15.75 x 16.34 inches (approx. 400 x 415 mm)
Product Dimensions	18 x 18 x 8 inches
Product Weight	53.6 Pounds
Laser Class	Class 1 (enclosed), Class 4 (internal laser module)
Software Compatibility	LightBurn, LaserGRBL
Operating Systems	Windows (7/8/10/XP), Mac, Linux
Data Transfer	USB, TF Card

Large Working Area

Upgraded curved cover and built-in camera for precise, compatibility with extensive processing.




Image: Illustration of the Creality Falcon2 Pro's large working area, measuring 15.75 x 16.34 inches, and an internal height of 10.4 inches, allowing for extensive processing of various materials.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Creality website or contact Creality customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Creality Official Website: www.creality.com

Customer Support: Refer to the contact information provided on the Creality website or in your product packaging for assistance with setup, operation, or troubleshooting.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question