

## WDZP PH-12+EL

# WDZP Universal Replacement Remote Control for Philips TV (Model PH-12+EL) User Manual

Model: PH-12+EL

## 1. INTRODUCTION

This manual provides instructions for the WDZP Universal Replacement Remote Control, model PH-12+EL, designed for Philips televisions. This remote control is engineered for immediate use without complex programming or setup. Simply install the batteries, and it is ready to operate your compatible Philips TV. The remote features advanced infrared technology for a strong signal and long-distance control, ensuring a responsive user experience.

## 2. SETUP

To begin using your WDZP Universal Replacement Remote Control, follow these simple steps:

- Unpack:** Carefully remove the remote control from its packaging.
- Install Batteries:** Locate the battery compartment on the back of the remote. Open the compartment cover. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment. Close the battery compartment cover securely.
- Ready for Use:** Once batteries are installed, the remote control is ready to operate your Philips TV. No additional programming or pairing is required.

# No Setup • No App • No Stress

(Advanced infrared technology: Strong signal & Long distance)



Figure 2.1: Battery Installation Guide. This image demonstrates the simple three-step process for setting up the remote control, primarily focusing on battery insertion.

## 3. OPERATING INSTRUCTIONS

The WDZP Universal Replacement Remote Control provides full functionality for your Philips TV. Below is a general guide to its buttons and their functions:

## Compatibility

# PH-12+EL TV Remote Control



Figure 3.1: Remote Control in Use. This image illustrates the remote control's compatibility with Philips TVs and its ergonomic design during operation.

- **Power Button ( ):** Turns the TV on or off.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (CH+/CH-):** Changes TV channels.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select options on the TV screen. The OK button confirms selections.
- **Source Button:** Cycles through input sources (HDMI, AV, etc.).
- **Number Buttons (0-9):** For direct channel input.
- **Mute Button:** Mutes or unmutes the TV audio.
- **Menu/Options Button:** Accesses the TV's main menu or contextual options.
- **Back/Return Button:** Returns to the previous screen or menu.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback if supported by the TV.

Point the remote control directly at your Philips TV's infrared receiver for optimal performance. The remote has a maximum range of 40 feet and a 180-degree control angle.

# Premium ABS Material Matte/Smooth Finish

**40** Feet **180°** **38** Khz+  
Control Distance Control Angle Reaction Rate

✓ Durable & Shockproof

✓ Lightweight & Comfortable



Figure 3.2: Remote Control Features. This image details the operational range, angle, and physical characteristics of the remote.

## 4. MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Protection:** The remote is designed to be durable and shockproof, but avoid dropping it from significant heights or exposing it to excessive force.

## 5. TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following troubleshooting steps:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Make sure you are within the operational range (up to 40 feet) and pointing the remote directly at the TV.
- **Limited Range or Intermittent Functionality:**
  - This could indicate low battery power. Replace the batteries.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the infrared signal.
  - Clean the infrared emitter on the front of the remote and the receiver on the TV with a soft cloth.
- **Specific Buttons Not Working:**
  - If only certain buttons are unresponsive, try replacing the batteries first.
  - Ensure the remote is clean and there is no debris lodged under the buttons.

If the problem persists after trying these steps, please contact customer support as detailed in the Warranty and Support section.

## 6. SPECIFICATIONS

Feature	Detail
Model	PH-12+EL
Brand	WDZP
Compatible Devices	Philips Televisions
Connectivity Technology	Infrared (IR3.0 Advanced Technology)
Maximum Range	40 Feet
Control Angle	180 Degrees
Reaction Rate	38khz+
Battery Type	2 x AAA (not included)
Material	Premium ABS (Matte/Smooth Finish)
Special Features	Ergonomic, Durable & Shockproof, Lightweight & Comfortable
Dimensions (Approx.)	6.69 inches (Length) x 2.36 inches (Width) x 0.82 inches (Thickness)



Figure 6.1: Remote Control Dimensions. This image provides a visual representation of the remote's physical measurements.

# UPGRADE CHIP

## Advanced IR3.0 Technology




Figure 6.2: Advanced IR3.0 Technology. This image highlights the internal technology contributing to the remote's performance.

## 7. WARRANTY AND SUPPORT

WDZP stands firmly behind its products and customers.

- **Warranty:** This product comes with a 6-month warranty.
- **Returns:** Returns are accepted within the warranty period.
- **Customer Service:** If you encounter any quality issues or require assistance, please do not hesitate to contact our dedicated customer support team. We are available to assist you promptly.
- **Contact Information:** Please refer to your purchase documentation or the seller's information on the platform where you purchased the product for specific contact details.