

[manuals.plus](#) /› [XIAOMI](#) /› [Xiaomi Smart Multifunctional Rice Cooker BHR7919EU User Manual](#)

## XIAOMI MFB120A

# Xiaomi Smart Multifunctional Rice Cooker User Manual

Model: BHR7919EU (MFB120A)

Brand: XIAOMI

## INTRODUCTION

Thank you for choosing the Xiaomi Smart Multifunctional Rice Cooker. This appliance is designed to simplify your cooking experience, offering various functions for preparing rice and other dishes. Please read this manual carefully before use to ensure safe and optimal operation.

The Xiaomi Smart Multifunctional Rice Cooker (Model BHR7919EU, MFB120A) is a versatile kitchen appliance with a 3-liter capacity and 675 watts of power, operating at 220 Volts. It features a durable stainless steel construction and a plastic lid. The product dimensions are approximately 10 x 5 x 1.27 cm, weighing 3.4 kg.

## SAFETY INFORMATION

- Always ensure the appliance is placed on a stable, flat, and heat-resistant surface.
- Do not immerse the main unit in water or any other liquid.
- Keep out of reach of children.
- Ensure the power cord is not damaged and is properly connected to a grounded outlet.
- Do not touch hot surfaces during or immediately after operation. Use oven mitts or handles.
- Unplug the appliance when not in use and before cleaning.
- Do not block the steam vent during operation.

## PRODUCT OVERVIEW

Familiarize yourself with the components of your Xiaomi Smart Multifunctional Rice Cooker.



Figure 1: Angled front view of the Xiaomi Smart Multifunctional Rice Cooker. The appliance is white with a minimalist design, featuring a digital display and control buttons on the front panel.



Figure 2: Top-down view of the Xiaomi Smart Multifunctional Rice Cooker, highlighting the control panel. The panel includes buttons for Timer, Rice, Brown Rice, Congee, Soup, Wi-Fi, Steam, Reheat, Keep Warm, Start, and Select, along with a digital display.

## SETUP

- 1. Unpacking:** Carefully remove all packaging materials and check for any damage.
- 2. Initial Cleaning:** Before first use, wash the inner pot, steam plate, and any accessories with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
- 3. Placement:** Place the rice cooker on a dry, stable, and level surface away from direct sunlight and heat sources. Ensure adequate ventilation around the appliance.
- 4. Power Connection:** Plug the power cord into a suitable electrical outlet (220V).

## OPERATING INSTRUCTIONS

The Xiaomi Smart Multifunctional Rice Cooker offers various cooking modes and smart features. Always refer to the water level markings inside the inner pot for accurate measurements.

### Cooking Rice (General Guide)

- Measure Rice:** Use the provided measuring cup to measure the desired amount of rice.
- Wash Rice:** Rinse the rice thoroughly under cold water until the water runs clear.
- Add to Inner Pot:** Place the washed rice into the inner pot.
- Add Water:** Fill the inner pot with water up to the corresponding water level mark for the amount of rice you are cooking. For example, if cooking 2 cups of rice, fill water to the '2' mark on the 'Rice' scale. *Note: Some older manuals may contain a typo regarding water levels; always match the water level to the number of rice cups.*
- Close Lid:** Close the lid securely.
- Select Mode:** Press the 'Select' button to cycle through the available cooking modes (e.g., 'Rice', 'Brown Rice', 'Congee', 'Soup', 'Steam', 'Reheat', 'Keep Warm').
- Start Cooking:** Once the desired mode is selected, press the 'Start' button. The appliance will begin cooking.

### Smart Features and App Control

This smart rice cooker can be controlled via a dedicated mobile application. This allows you to:

- Set different cooking modes remotely.
- Adjust rice softness after cooking.
- Maintain warmth for extended periods.

*Note: Some users have reported issues with remote start functionality, as the cooker may quickly enter standby mode and become inaccessible via Wi-Fi. In such cases, using the built-in timer on the appliance is recommended.*

### Pre-set Programs

The rice cooker features several pre-set programs for different types of rice and dishes. While these programs are convenient, manual temperature and time adjustments are not available. For specific rice types like 'arroz bomba', it is important to monitor the cooking process and potentially stop it manually to achieve desired consistency, as pre-set times may result in overcooked or mushy rice.

## MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your rice cooker.

- Unplug:** Always unplug the appliance from the power outlet before cleaning.
- Inner Pot:** The inner pot is dishwasher safe. For manual cleaning, wash with warm, soapy water and a soft sponge. Avoid abrasive cleaners or scourers that could damage the non-stick coating.
- Lid and Steam Vent:** The inner lid and steam vent are removable for easy cleaning. Wash them with warm, soapy water, rinse, and dry thoroughly before reattaching.
- Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not use harsh chemicals or immerse the unit in water.
- Condensate Collector:** Regularly empty and clean the condensate collector to prevent water from spilling when opening the lid.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Rice is too mushy/sticky	Too much water; incorrect rice type for pre-set program.	Reduce water slightly for next batch. For specific rice types, consider manual monitoring and stopping the cooking cycle earlier if possible.
Rice is too hard/undercooked	Not enough water; lid not properly sealed.	Increase water slightly for next batch. Ensure lid is securely closed.
Remote start via app not working	Cooker in standby mode; Wi-Fi connectivity issue.	Ensure cooker is not in standby. Check Wi-Fi connection. Use the built-in timer on the appliance as an alternative.
Water spills when opening lid	Condensate collector is full or ineffective.	Empty and clean the condensate collector regularly. Open the lid slowly and carefully.

## SPECIFICATIONS

- Brand:** XIAOMI
- Model Number:** MFB120A (BHR7919EU)
- Color:** White
- Dimensions:** 10 x 5 x 1.27 cm (Product); 16 x 16 x 16 cm (Approximate overall)
- Weight:** 3.4 kg
- Capacity:** 3 Liters
- Power:** 675 Watts
- Voltage:** 220 Volts
- Material:** Stainless Steel (Inner Pot), Plastic (Lid)
- Care:** Inner pot is dishwasher safe.

## WARRANTY AND SUPPORT

Your Xiaomi Smart Multifunctional Rice Cooker is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, service, or warranty claims, please contact Xiaomi customer service through their official website or the contact information provided in your product documentation. Keep your purchase receipt as proof of purchase.