



[Manuals.plus](#) /

› [Panana](#) /

› Panana Compact Airfryer Toaster Oven KSOT-001 User Manual

Panana KSOT-001

Panana Compact Airfryer Toaster Oven User Manual

Model: KSOT-001 | Brand: Panana

1. INTRODUCTION

Thank you for choosing the Panana Compact Airfryer Toaster Oven. This versatile 21-quart appliance combines the functions of an air fryer, toaster, and oven, offering multiple cooking modes for a wide range of dishes. Designed for convenience and efficiency, it features a 1400W heating element, a wide temperature range, and a 60-minute timer with an automatic shut-off function. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Figure 1: Panana Compact Airfryer Toaster Oven (Model KSOT-001)

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- A fire may occur if the oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not place any materials other than manufacturer's recommended accessories in the oven when not in use.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.
- Exercise extreme caution when removing tray or disposing of hot grease.

3. PRODUCT OVERVIEW

Components and Controls

Familiarize yourself with the main components and control panel of your Panana Airfryer Toaster Oven.



Figure 2: Labeled Components of the Airfryer Toaster Oven

- **Temperature Knob:** Adjusts cooking temperature (OFF to 450°F).
- **Function Knob:** Selects cooking mode (e.g., Air Fry, Bake, Toast, Broil).
- **Timer Knob:** Sets cooking time (0-60 minutes) with auto-off.
- **Power Indicator:** Illuminates when the oven is operating.
- **Control Panel:** Houses all knobs and indicators.
- **Glass Door:** Allows viewing of food during cooking. Features a double-glass design for safety.
- **Door Handle:** For opening and closing the oven door.
- **Internal Cavity:** The cooking chamber with 21-quart capacity.

Included Accessories

Your appliance comes with the following accessories:

- **1 x Baking Pan:** For baking, roasting, or catching drips.
- **1 x Air Fryer Basket:** Designed for air frying, allowing hot air to circulate around food for crispy results.
- **1 x Oven Wire Rack:** For toasting, baking, and general oven use.
- **1 x Tray Handle:** For safely inserting and removing hot accessories.

4. SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the oven and all accessories from the packaging. Remove any packing materials, stickers, or labels.
2. **Initial Cleaning:** Wash all accessories (baking pan, air fryer basket, oven wire rack, tray handle) in warm, soapy water. Rinse thoroughly and dry completely. Wipe the interior and exterior of the oven with a damp cloth.
3. **Placement:** Place the oven on a stable, level, heat-resistant surface. Ensure there is at least 4 inches (10 cm) of clearance on all sides (back, sides, and top) to allow for proper ventilation. Do not place the oven near flammable materials.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **First Use Burn-Off:** Before cooking food, operate the oven empty for approximately 15 minutes at 400°F (200°C) on the "Bake" function. This will burn off any manufacturing residues and odors. A slight smoke or odor is normal during this process. Ensure the area is well-ventilated.
6. **Cool Down:** Allow the oven to cool completely after the burn-off cycle before proceeding with cooking.

EXTRA-LARGE CAPACITY

Please ensure to leave a clearance on each side



2 LBS
french fries



5-6 LBS
Chicken



10 INCH
Pizza



20 PCS
Chicken Wings



6 SLICES
Bread



2 PIECES
Steak

Figure 3: Appliance Dimensions and Recommended Clearance

5. OPERATING INSTRUCTIONS

Your Panana Air Fryer Toaster Oven offers multiple cooking functions. Follow these steps for general operation:

General Operation

- 1. Prepare Food:** Place your food on the appropriate accessory (baking pan, air fryer basket, or wire rack).
- 2. Insert Accessory:** Carefully slide the accessory with food into the desired rack position inside the oven.
- 3. Select Function:** Turn the **Function Knob** to select your desired cooking mode (e.g., Air Fry, Bake, Toast, Broil).
- 4. Set Temperature:** Turn the **Temperature Knob** to the desired temperature setting (e.g., 350°F, 400°F).
- 5. Set Time:** Turn the **Timer Knob** to the desired cooking time. The oven will begin heating. The power indicator light will illuminate.
- 6. Monitor Cooking:** You can observe the cooking process through the glass door.
- 7. Completion:** When the set time elapses, the oven will automatically shut off, and a bell will sound. The power indicator light will turn off.
- 8. Remove Food:** Using oven mitts and the tray handle, carefully remove the hot accessory and cooked food from the oven.

Cooking Functions and Examples

The oven features 6-in-1 multifunctionality, including Air Fry, Bake, Broil, Toast, Warm, and more. The function knob allows selection of various heating elements for optimal cooking.

FULL MENU WITH 10 SETTINGS, cooking can't's be easier with joy



AIR FRY



ROTISSERIE



TOAST



ROAST



BROIL



BAKE



SLOW COOK



GRILL



REHEAT



PIZZA



Figure 4: Available Cooking Functions

- **Air Fry:** Ideal for achieving crispy results with little to no oil. Use the air fryer basket.
- **Bake:** For cakes, cookies, casseroles, and other baked goods. Use the baking pan or an oven-safe dish on the wire rack.
- **Broil:** For quick browning or cooking thin cuts of meat. Place food on the wire rack closer to the top heating element.
- **Toast:** For bread, bagels, and waffles. Use the wire rack.
- **Roast:** For larger items like chicken or vegetables. Use the baking pan or wire rack.
- **Warm:** To keep food warm without further cooking.
- **Rotisserie:** For roasting whole chickens or other meats evenly (requires rotisserie accessory, if included with your model).
- **Grill:** For grilling various foods.
- **Reheat:** To warm up leftovers.
- **Pizza:** Optimized setting for cooking pizzas.

Air Frying Guide

For best air frying results, preheat the oven for 5 minutes. Turn the function knob to "Air Fry" and set the temperature to 450°F (230°C) unless otherwise specified.



Figure 5: Air Frying Menu Suggestions

Suggested Air Frying Times and Temperatures

Food Item	Quantity	Temperature	Time
Chips (French Fries)	500g	400°F	18-20 Mins
Drumsticks	4 pcs	450°F	25 Mins
Toast	4 pcs	450°F	3-5 Mins
Steak	8 pcs	450°F	10-15 Mins
Chicken (Whole)	1kg	400-450°F	45-50 Mins
Egg Tart	9 pcs	450°F	13-18 Mins
Chicken Wings	8 pcs	450°F	15-20 Mins

Note: Cooking times and temperatures are approximate and may vary based on food quantity, starting temperature, and desired crispness. Always ensure food is cooked to a safe internal temperature.

Official Product Video

Your browser does not support the video tag.

Video 1: Panana Air Fryer Toaster Oven Overview. This video demonstrates the various cooking functions and ease of use of the Panana Air Fryer Toaster Oven, including preparing pizza, drumsticks, bread, and a whole chicken.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your appliance and ensure optimal performance.

- 1. Always Unplug:** Before cleaning, always unplug the oven from the power outlet and allow it to cool completely.
- 2. Crumb Tray:** The crumb tray should be removed and cleaned regularly to prevent grease buildup. Slide out the crumb tray, discard crumbs, and wash it in warm, soapy water. Rinse and dry thoroughly before replacing.
- 3. Interior Cleaning:** Wipe the interior walls, bottom, and glass door with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive sponge or brush. Do not use harsh abrasives or metal scouring pads, as they can damage the non-stick coating or stainless steel surfaces.
- 4. Exterior Cleaning:** Wipe the exterior of the oven with a damp cloth. Dry thoroughly.
- 5. Accessories:** All removable accessories (baking pan, air fryer basket, oven wire rack, tray handle) can be washed in warm, soapy water. They are generally not dishwasher safe unless specified. Rinse and dry completely.
- 6. Avoid Water Immersion:** Never immerse the main body of the oven, power cord, or plug in water or any other liquid.

7. TROUBLESHOOTING

If you encounter issues with your appliance, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; power outlet malfunction; timer not set.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Turn the Timer Knob past the 10-minute mark and then back to the desired time.
Food is not cooking evenly.	Overcrowding the basket/rack; incorrect temperature/time; food not turned.	Avoid overcrowding; cook in smaller batches. Adjust temperature and time as needed. Turn or shake food halfway through cooking for even results.
Excessive smoke during cooking.	Grease buildup; fatty food; initial burn-off.	Clean the oven interior and crumb tray thoroughly. Use a baking pan under the air fryer basket to catch drips from fatty foods. A small amount of smoke during first use is normal.
Food is not crispy when air frying.	Too much oil; overcrowding; insufficient cooking time/temperature.	Use minimal oil. Do not overcrowd the air fryer basket. Increase cooking time or temperature slightly. Ensure food is dry before air frying.

8. SPECIFICATIONS

Feature	Detail
Brand	Panana
Model Number	KSOT-001
Power Rating	1400W
Capacity	21 Quarts
Product Dimensions (D x W x H)	14.5" x 14.1" x 13.6" (36.8cm x 35.8cm x 34.5cm)
Color	Black
Material	Stainless Steel
Control Type	Knob
Special Features	Automatic Shut-Off, Temperature Control, Timer, Stain Resistant
Timer Range	0-60 Minutes
Temperature Range	OFF to 450°F

Feature	Detail
Item Weight	16.96 pounds (7.69 kg)
UPC	710917470024

9. WARRANTY AND SUPPORT

Warranty Information

Panana products are manufactured to the highest quality standards. This product is covered by a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, neglect, accident, alteration, or unauthorized repair.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Panana customer support. Refer to the product packaging or the official Panana website for the most current contact information.

Online Support: Visit the [Panana Store on Amazon](#) for FAQs and product information.

