

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sharp](#) /

› Sharp EP-C251 Digital Signage Display User Manual

## Sharp EP-C251

# Sharp EP-C251 Digital Signage Display User Manual

Model: EP-C251

## INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Sharp EP-C251 Digital Signage Display. The EP-C251 is an always-on 25.3-inch ePaper display designed for digital signage applications, offering remarkably brilliant images with low power consumption, even in brightly lit environments. Its paper-like view, wide viewing angle, and lack of backlight ensure comfortable viewing. Content updates are facilitated through PC, USB-C thumb drive, Wireless, or Bluetooth connections.




Figure 1: Sharp EP-C251 Digital Signage Display showcasing an airport gate information display.

## PACKAGE CONTENTS

Before proceeding with installation, please verify that all items listed below are present in your package:

- EP-C251 Digital Signage Display
- Power Cord
- AC Adapter
- Clamp
- Operation Manual (this document)
- Setting Tool Manual
- Warranty Card
- Hanging Hook
- Paper Stand
- Stand Attention Instructions

## SETUP AND INSTALLATION

The EP-C251 display features a thin and lightweight design, allowing for flexible installation in various environments. Refer to the "Setting Tool Manual" and "Stand Attention Instructions" for detailed guidance on specific mounting options.

1. **Unpacking:** Carefully remove the display and all accessories from the packaging. Retain packaging materials for future transport or storage.
2. **Physical Placement:** Choose a suitable location for the display. Consider visibility, environmental conditions (avoiding extreme temperatures or direct moisture), and proximity to a power source. The display is designed for excellent visibility in bright and semi-outdoor settings.
3. **Mounting Options:**
  - **Using the Paper Stand:** Attach the provided Paper Stand according to the "Stand Attention Instructions" for desktop or counter placement.
  - **Using the Hanging Hook/Clamp:** For wall or ceiling mounting, utilize the Hanging Hook and Clamp as detailed in the "Setting Tool Manual." Ensure the mounting surface can support the display's weight (approximately 8.8 pounds).
4. **Power Connection:** Connect the AC Adapter to the display's power input, then plug the Power Cord into the AC Adapter and a standard electrical outlet. The display is designed for low power consumption, as low as 0W from the panel.




Figure 2: Physical dimensions of the Sharp EP-C251 Digital Signage Display, measuring 23.5 inches wide, 13.9 inches high, and 1.2 inches deep.

## OPERATING INSTRUCTIONS

The Sharp EP-C251 is an always-on display, meaning it maintains its image even without continuous power, making it highly energy efficient.

### Content Provisioning

The display supports flexible content updates through multiple methods:

- **PC Connection:** Connect the display to a computer via USB-C for direct content transfer.
- **USB-C Thumb Drive:** Insert a USB-C thumb drive containing your content directly into the display.
- **Wireless LAN:** Connect the display to your local Wi-Fi network for remote content updates.
- **Bluetooth:** Pair the display with a mobile device via Bluetooth to transfer content.

### Display Controls

The display features dedicated buttons for control:

- **Mode Button:** Use this button to switch between manually or automatically switching images. Refer to the "Setting Tool Manual" for detailed configuration of image switching modes.
- **Pairing Button:** This button facilitates connection to mobile devices for content updates via Bluetooth.



Figure 3: Sharp EP-C251 Digital Signage Display used in a retail environment to display a "Fresh Vegetable" advertisement.

## MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Sharp EP-C251 Digital Signage Display.

- **Cleaning the Display:** Use a soft, lint-free cloth slightly dampened with water or a non-abrasive screen cleaner. Avoid harsh chemicals, solvents, or abrasive materials, as these can damage the screen surface.
- **Environmental Conditions:** Ensure the display is operated within its specified temperature and humidity ranges. Avoid exposing the display to direct sunlight for prolonged periods, as this can affect performance and lifespan.
- **Power Management:** While the display has very low power consumption, it is recommended to disconnect power during extended periods of non-use or during electrical storms.

## TROUBLESHOOTING

If you encounter issues with your Sharp EP-C251 display, refer to the following common troubleshooting steps:

- **Display Not Powering On:**
  - Verify that the power cord is securely connected to both the display and a working electrical outlet.
  - Check the AC adapter for any visible damage.
  - Test the electrical outlet with another device to ensure it is functional.
- **Content Not Updating:**
  - **USB-C:** Ensure the USB-C thumb drive is properly inserted and contains compatible content files.
  - **Wireless/Bluetooth:** Verify that the display is correctly connected to the network or paired with the mobile device. Check network connectivity and device pairing status.
  - Refer to the "Setting Tool Manual" for detailed instructions on content transfer protocols and file formats.

#### • **Image Quality Issues:**

- Ensure the content resolution matches the display's native resolution (8192 x 6144 pixels) for optimal clarity.
- Clean the screen surface as described in the Maintenance section.

If the issue persists after attempting these steps, please contact Sharp customer support for further assistance.

## SPECIFICATIONS

Key technical specifications for the Sharp EP-C251 Digital Signage Display:

Feature	Specification
Brand	Sharp
Model Number	EP-C251
Screen Display Size	25.3 Inches
Max Screen Resolution	8192 x 6144 Pixels (8K UHD)
Aspect Ratio	16:9
Product Dimensions (LxWxH)	1.2 x 23.5 x 13.9 inches
Item Weight	8.8 pounds
Power Consumption	As low as 0W (panel)
Connectivity	PC (USB-C), USB-C Thumb Drive, Wireless LAN, Bluetooth
Screen Surface Description	Glossy

## WARRANTY AND SUPPORT

Your Sharp EP-C251 Digital Signage Display comes with a limited warranty. Please refer to the included **Warranty Card** for detailed information regarding warranty terms, conditions, and duration.

For technical support, service inquiries, or to report any issues not covered in this manual, please contact Sharp customer support. Contact information can typically be found on the Warranty Card or on the official Sharp website.

When contacting support, please have your product model number (EP-C251) and serial number readily available.