

[Manuals.plus](#) /

› [CakCity](#) /

› CakCity Men's Waterproof Sport Watch Model 2192 Instruction Manual

CakCity 2192

CakCity Men's Waterproof Sport Watch Model 2192 Instruction Manual

Model: 2192

1. PRODUCT OVERVIEW

The CakCity Model 2192 is a multifunction digital sport watch designed for durability and ease of use. It features a large display, EL backlight, and is water-resistant up to 50 meters. Key functions include time display (12/24 hour format), stopwatch, countdown timer, alarm, and date/week display.

FUNCTION OVERVIEW

EACH FUNCTIONAL DESIGN, ALL FOR YOUR CARING SERVICE, RECORDING EVERY MOMENT OF LIFE.

12/24 12/24 HOUR

 TIME

 STOPWATCH

 COUNTDOWN

 ALARM

 DATE / WEEK

 EL LIGHT

 WR 50M



Image 1.1: Overview of the CakCity Model 2192 watch and its primary functions. The watch features a digital display showing time, day, and date. Icons indicate functions such as 12/24 hour format, time, stopwatch, countdown, alarm, date/week, EL light, and 50M water resistance.

Button Functions:

- **LIGHT (Top Left):** Activates the EL backlight for visibility in low-light conditions.
- **MODE (Bottom Left):** Cycles through different modes: Time, Stopwatch, Countdown, Alarm, and Dual Time.
- **ST/SP (Top Right):** Start/Stop button for stopwatch and countdown functions. Used to adjust settings in setup mode.
- **RESET (Bottom Right):** Resets stopwatch and countdown. Used to select items or confirm settings in setup mode.

2. SETUP AND BASIC OPERATION

2.1 Setting Time and Date:

1. In Time Mode, press and hold the **MODE** button until the seconds begin to flash.
2. Press the **RESET** button to cycle through the settings: Seconds > Hour > Minute > Year > Month > Day > 12/24 Hour Format.

3. Use the **ST/SP** button to adjust the flashing value.
4. Once all settings are correct, press the **MODE** button to exit setup mode.

2.2 Setting the Alarm:

1. From Time Mode, press the **MODE** button repeatedly until you reach Alarm Mode (indicated by 'AL' or a bell icon).
2. Press and hold the **RESET** button until the alarm hour flashes.
3. Use the **ST/SP** button to adjust the hour.
4. Press **RESET** to move to the minute setting, then use **ST/SP** to adjust.
5. Press **RESET** again to activate/deactivate the alarm (a bell icon will appear when active).
6. Press **MODE** to exit alarm setup.

2.3 Using the EL Backlight:

Press the **LIGHT** button (top left) to illuminate the display. The backlight will remain active for a few seconds. This feature is particularly useful in dark environments.



Image 2.1: Comparison of the watch display in normal conditions versus with the EL backlight activated. The EL backlight illuminates the digits for clear readability in low light.

3. ADVANCED FUNCTIONS

3.1 Stopwatch Function:

1. From Time Mode, press the **MODE** button until you reach Stopwatch Mode (indicated by 'ST' or 'CHRO').
2. Press **ST/SP** to start the stopwatch.
3. Press **ST/SP** again to pause the stopwatch.
4. While paused, press **RESET** to clear the stopwatch to zero.
5. To record lap times, press **RESET** while the stopwatch is running to display the lap time. Press **RESET** again to return to the running stopwatch.

3.2 Countdown Timer:

1. From Time Mode, press the **MODE** button until you reach Countdown Mode (indicated by 'TR' or 'CD').
2. Press and hold the **RESET** button until the countdown hour flashes.
3. Use the **ST/SP** button to adjust the hour. Press **RESET** to move to minutes, then seconds, adjusting each with **ST/SP**.
4. Once the desired countdown time is set, press **MODE** to exit setup.
5. Press **ST/SP** to start the countdown.
6. Press **ST/SP** again to pause the countdown. Press **RESET** to reset the timer to its initial set value.

3.3 Dual Time Zone (2TIME):

1. From Time Mode, press the **MODE** button until you reach Dual Time Mode (indicated by '2TIME' or 'DT').
2. Press and hold the **RESET** button until the hour flashes.
3. Use the **ST/SP** button to adjust the hour.
4. Press **RESET** to move to the minute setting, then use **ST/SP** to adjust.
5. Press **MODE** to exit dual time setup.

4. MAINTENANCE AND WATER RESISTANCE

4.1 Water Resistance (50M / 5 ATM):

The CakCity Model 2192 watch is water-resistant up to 50 meters (5 ATM). This means it is suitable for light swimming, showering with cold water, and general daily use where it may be exposed to splashes or rain.

- **Do NOT** press any buttons while the watch is submerged in water.
- **Avoid** exposure to hot water, steam, or saunas, as this can compromise the watch's seals.
- After exposure to saltwater, rinse the watch with fresh water and dry thoroughly.



Image 4.1: Illustration of the 50M water resistance of the CakCity Model 2192 watch. It is suitable for washing hands, showering, and swimming, but not for diving or hot water activities.

4.2 Cleaning:

Wipe the watch case and strap regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the watch's finish.

4.3 Battery Replacement:

The watch uses a CR2025 battery. When the display becomes dim or functions become erratic, it may be time to replace the battery. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

- **Display is blank or dim:** Check the battery. If the battery is low, replace it. Ensure the watch has not been exposed to extreme temperatures.
- **Time is incorrect:** Re-set the time and date following the instructions in Section 2.1. If the time consistently drifts, the battery may be low or the watch may require service.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not specify one). Try a soft reset by pressing all four buttons simultaneously for a few seconds (if

this does not work, consult a professional).

- **Water inside the watch:** If condensation or water droplets appear inside the watch, stop using it immediately and take it to a professional for inspection and repair to prevent further damage.

6. SPECIFICATIONS

PRODUCT PARAMETER

BRAND: SKMEI

MODEL: 2192

WEIGHT: 60.6g

MOV' T: DIGITAL

CRYSTAL: RESIN

CASE : ABS + ZINC ALLOY

BAND : TPU

BUCKLE: STAINLESS STEEL

W / P : 50M

FUNCTION: 2Time, Chrono, Alarm, Date, Week, EL Light, 12/24 hour clock, Countdown.

Case width: **49.8mm**

Case thickness: **14.8mm**

Band Width: **35mm**

Watch length: **265mm**

Image 6.1: Detailed product parameters and dimensions for the CakCity Model 2192 watch.

Feature	Specification
Brand	CakCity
Model Number	2192
Display Type	Digital
Movement Type	Digital Quartz

Case Material	ABS + Zinc Alloy
Dial Window Material	Resin
Band Material	TPU (Polyurethane)
Clasp Type	Buckle (Stainless Steel)
Water Resistance Depth	50 Meters (5 ATM)
Functions	Time (12/24H), Chronograph, Alarm, Countdown, Dual Time, Date, Week, EL Backlight
Case Diameter	49.8 mm
Case Thickness	14.8 mm
Band Width	35 mm
Band Length	265 mm
Item Weight	65 Grams
Battery Type	CR2025 (included)

7. WARRANTY AND SUPPORT

Information regarding specific warranty terms and customer support contacts is not available in the provided product data. For warranty claims or technical assistance, please refer to the product packaging or contact CakCity customer service directly through their official website or the retailer where the watch was purchased.