

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Princess House](#) /
- › [Princess House Vida Sana Cook+ Air Fryer Oven Model 10401 User Manual](#)

Princess House 10401

Princess House Vida Sana Cook+ Air Fryer Oven Model 10401 User Manual

Your comprehensive guide to operating and maintaining your appliance.

INTRODUCTION

Welcome to the Princess House Vida Sana Cook+ Air Fryer Oven, Model 10401. This versatile appliance is designed to simplify your cooking with its multi-functional capabilities, including air frying, baking, toasting, and broiling. Featuring a generous 12-liter capacity and 14 convenient presets, it offers a wide range of cooking options for various dishes. Please read this manual thoroughly before first use to ensure safe and optimal operation.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PACKAGE CONTENTS

Upon unpacking, please ensure all items are present and in good condition:

- Princess House Vida Sana Cook+ Air Fryer Oven (Main Unit)
- Air Fryer Basket
- Wire Rack(s)
- Baking Pan / Drip Tray
- Instruction Manual

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials, including any protective films or stickers from the appliance and its accessories.
2. **Placement:** Place the air fryer oven on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 6 inches) around the appliance for proper ventilation. Do not place it directly against a wall or under cabinets.
3. **Initial Cleaning:** Before first use, wipe the exterior of the oven with a damp cloth. Wash the air fryer basket, wire racks, and baking pan/drip tray with warm, soapy water. Rinse thoroughly and dry completely.
4. **First Run (Burn-off):** To eliminate any manufacturing odors, plug in the oven and run it empty at 350°F (175°C) for approximately 10-15 minutes. A slight odor or smoke may be present during this initial use; this is normal. Ensure the area is well-ventilated.



Image: The Princess House Vida Sana Cook+ Air Fryer Oven, black in color, with its digital display showing temperature and time, and a clear glass door revealing the empty interior racks.

OPERATING INSTRUCTIONS

Control Panel Overview

The Princess House Vida Sana Cook+ Air Fryer Oven features a user-friendly touch control panel and a central rotary dial for precise adjustments. The digital display shows temperature, time, and selected presets.



Image: A close-up view of the air fryer oven's control panel, showing a hand adjusting the central rotary dial. The digital display indicates settings for toast, light/darkness, and various cooking presets like Air Fry, Veggies, Bacon, Steak, Chicken, Fish, Roast, Pizza, Bake, Dehydrator, Broil, and Reheat.

Cooking Functions and Presets

Your oven comes equipped with 14 pre-programmed functions for common dishes. To use a preset:

1. Place food inside the oven on the appropriate accessory (air fryer basket, wire rack, or baking pan).
2. Select the desired preset function from the control panel. The oven will automatically set a recommended time and temperature.
3. You can adjust the time and temperature manually using the rotary dial if needed.
4. Press the Start/Pause button to begin cooking.

Key Functions:

- **Air Frying:** Ideal for crispy foods like fries, chicken wings, and vegetables. Use the air fryer basket for best results.
- **Baking:** Perfect for cakes, cookies, and casseroles. Use the baking pan or an oven-safe dish on the wire rack.

- **Toasting:** For bread, bagels, and frozen waffles. Adjust toast level (light/dark) as desired.
- **Broiling:** For browning the top of dishes or cooking thin cuts of meat. Place food on the top wire rack.
- **Other Presets:** Includes specific settings for Steak, Chicken, Fish, Pizza, Roast, Dehydrator, Reheat, and more. Refer to the control panel for all 14 options.

Using the Air Fryer Basket and Racks

The oven comes with multiple accessories to optimize cooking for different food types:

- **Air Fryer Basket:** Use for foods that require maximum air circulation for crispiness, such as French fries, chicken nuggets, or vegetables. Place it on the middle rack position.
- **Wire Racks:** Use for baking, roasting, or broiling. Multiple rack positions allow for cooking different items simultaneously or adjusting proximity to heating elements.
- **Baking Pan / Drip Tray:** Use this tray at the bottom to catch drips and crumbs, or as a baking pan for items like cookies or small casseroles.



Image: The Princess House Vida Sana Cook+ Air Fryer Oven with its door open, revealing empanadas cooking in an air fryer basket on the lower rack and on a baking tray on the upper rack.



Image: The Princess House Vida Sana Cook+ Air Fryer Oven with its door open, showing a pizza cooking on a baking tray inside. The digital display shows a temperature of 375 degrees and a remaining time of 15 minutes.

CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your appliance.

1. **Always Unplug:** Before cleaning, ensure the oven is unplugged from the power outlet and has cooled down completely.
2. **Interior Cleaning:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn food residue, a non-abrasive sponge can be used. Avoid harsh chemicals or abrasive cleaners.
3. **Exterior Cleaning:** Wipe the exterior with a soft, damp cloth. Do not immerse the main unit in water.
4. **Accessories:** The air fryer basket, wire racks, and baking pan/drip tray are dishwasher safe for easy cleaning. Alternatively, wash them by hand with warm, soapy water and a non-abrasive sponge.
5. **Door:** Clean the glass door with a glass cleaner or a damp cloth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance fault.	Ensure the power cord is securely plugged into a working outlet. Check your circuit breaker. If the problem persists, contact customer support.
Food is not cooking evenly.	Overcrowding the basket/rack; incorrect temperature/time; food not flipped/shaken.	Avoid overcrowding; cook in smaller batches. Adjust temperature and time as needed. For air frying, shake or flip food halfway through cooking.
White smoke coming from the oven.	Grease or food residue burning; high-fat food.	Unplug the oven and let it cool. Clean the interior and accessories thoroughly. For high-fat foods, use the drip tray and ensure it's clean.
Food is not crispy.	Too much moisture; overcrowding; insufficient oil (for air frying).	Pat food dry before cooking. Do not overcrowd the basket. A light spray of oil can help achieve crispiness. Ensure the air fryer basket is used for air frying.

SPECIFICATIONS

Model Name: 10401

Brand: Princess House

Capacity: 12 Liters

Output Wattage: 1600 Watts

Item Weight: 6.6 pounds (3 Kilograms)

Product Dimensions: 15 x 13 x 15 inches

Color: Black

Control Method: Touch control

Outer Material: Plastic

Air Frying Technology: Convection

Dishwasher Safe Parts: Yes (Accessories)

UPC: 726858095158

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or contact Princess House customer service. Keep your purchase receipt as proof of purchase for any warranty claims.