

[manuals.plus](#) /

› [Rollo](#) /

› [Rollo Wireless Thermal Shipping Label Printer User Manual](#)

Rollo Wireless Thermal Shipping Label Printer

Rollo Wireless Thermal Shipping Label Printer User Manual

Model: Wireless Thermal Shipping Label Printer

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Rollo Wireless Thermal Shipping Label Printer. Please read this guide thoroughly to ensure optimal performance and longevity of your device.




Image: The Rollo Wireless Thermal Shipping Label Printer shown with a roll of shipping labels.

2. SETUP

2.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the "Included in Box" section are present and undamaged. If any items are missing or damaged, contact Rollo support.



Included in box



USB Cable



Power Adapter

Image: The printer's dimensions (8" L x 4" W x 4" H, 3.5 lbs) and included accessories: USB Cable and Power Adapter.

2.2 Connecting the Printer

The Rollo Wireless Thermal Label Printer offers both Wi-Fi and USB connectivity options.

- **Wi-Fi Connectivity:** For wireless printing, connect the printer to your Wi-Fi network. This enables printing directly from iPhone, iPad, and Mac via AirPrint, or from Android, Windows, Chromebook, and Linux devices via Wi-Fi without requiring specific drivers.
- **USB Connectivity:** Alternatively, connect the printer to your computer using the provided USB cable for a direct wired connection.



WiFi &
Airprint



USB
Connectivity



Windows,
Mac, Linux &
Chromebook



iPhone, iPad
& Android



**Compatible to print from the Rollo App
& other major shipping platforms.**


Image: Visual representation of the printer's compatibility with various operating systems and connectivity methods, including Wi-Fi, AirPrint, and USB. It also highlights compatibility with the Rollo App and major shipping platforms.

2.3 Loading Labels

This printer is designed for thermal labels. Ensure you are using compatible labels for optimal performance. The printer automatically detects label size.

1. Open the printer's top cover.
2. Place the roll of thermal labels into the label compartment, ensuring the labels feed smoothly into the printer mechanism.
3. Close the top cover. The printer will automatically calibrate and detect the label size.

1000 Thermal Barcode/SKU Labels



Label Roll

Perforated Tearing Between Labels

Image: A roll of 1000 thermal barcode/SKU labels, illustrating their dimensions (2" x 1") and perforated design.

3. OPERATING INSTRUCTIONS

3.1 Printing Labels

The Rollo printer uses advanced direct thermal technology, eliminating the need for ink or toner. It prints at a high speed of 150mm/s, capable of producing one 4x6 label per second. The 203 DPI print head ensures clear and scannable labels.

- **From a Computer:** After connecting via Wi-Fi or USB, select the Rollo printer from your device's print options. Ensure the correct label size is selected in your print settings.
- **From Mobile Devices:** Use AirPrint for Apple devices or the Rollo App for Android and other compatible devices to send print jobs wirelessly.
- **Using the Rollo App:** The Rollo App provides an intuitive interface for managing print jobs and settings.

**Life span of
650,000 labels**
4x more than other brands

**High-speed
thermal printing**
One 4x6 label per second

High-res 203 DPI
Carrier approved resolution



Image: The Rollo printer in operation, demonstrating its high-speed printing capability and highlighting its long lifespan and high resolution.

3.2 Label Types and Applications

The included 2" x 1" (51mm x 25mm) thermal barcode sticker labels are suitable for various applications, including:

- E-commerce shipping labels
- Inventory tagging with UPC codes, FNSKU, FBA labels
- Mail and postage address labels

rollo sustainable




Image: A roll of Rollo sustainable labels, emphasizing their eco-friendly attributes such as being BPA-Free and FSC certified.

4. MAINTENANCE

4.1 Print Head Longevity

The Rollo thermal printer heads are designed for durability, offering a printing life of approximately 650,000 shipping labels (equivalent to 327,360 feet). This extended lifespan minimizes the need for frequent replacements.

4.2 Cleaning the Printer

To maintain print quality, periodically clean the print head and rollers. Use a soft, lint-free cloth lightly dampened with isopropyl alcohol. Ensure the printer is turned off and unplugged before cleaning.

4.3 Label Storage

Store thermal labels in a cool, dry place away from direct sunlight and heat to prevent premature fading or damage to the thermal coating.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your Rollo printer.

- **Printer Not Responding:**

- Check power connections.
- Verify Wi-Fi or USB connection status.
- Restart the printer and your device.

- **Poor Print Quality:**

- Ensure you are using compatible thermal labels.
- Clean the print head (refer to Section 4.2).
- Check label orientation.

- **Labels Not Feeding Correctly:**

- Ensure labels are loaded correctly and not jammed.
- Verify the label roll is seated properly.

- **Connectivity Issues:**

- For Wi-Fi, ensure the printer is connected to the correct network and within range.
- For USB, try a different USB port or cable.
- Update printer drivers if necessary (for Windows/Linux).

6. SPECIFICATIONS

Brand	Rollo
Model Name	Wireless Thermal Shipping Label Printer
Printing Technology	Thermal
Connectivity Technology	Wi-Fi, USB
Maximum Black and White Print Resolution	203 DPI
Print Speed	150mm/s (one 4x6 label per second)
Compatible Devices	Smartphones (iPhone, iPad, Android), Windows, Mac, Chromebook, Linux
Maximum Media Size	51mm x 25mm (2" x 1") for included labels; supports various thermal label sizes

Printer Output	Monochrome
Dimensions (Approx.)	8" L x 4" W x 4" H
Weight (Approx.)	3.5 lbs
Included in Box	Rollo Wireless Thermal Shipping Label Printer, USB Cable, Power Adapter, 1000 2x1 Barcode Labels

7. WARRANTY INFORMATION

This product comes with a limited warranty. For specific terms and conditions, please refer to the warranty documentation included with your purchase or visit the official Rollo website.

8. CUSTOMER SUPPORT

For further assistance, technical support, or to access updated drivers and software, please visit the official Rollo support website: www.rollo.com/support.

© 2024 Rollo. All rights reserved.

Related Documents - Wireless Thermal Shipping Label Printer

 <p>Rollo Logistics Label Printer User Guide</p> <p>Comprehensive user guide for the Rollo Logistics Label Printer, covering setup, driver installation, label setup, maintenance, troubleshooting, and specifications. Learn to streamline your shipping process with this high-speed thermal label printer.</p>	
 <p>MUNBYN Label Printer User Manual and Troubleshooting Guide</p> <p>Comprehensive user manual and troubleshooting guide for MUNBYN label printers, covering models like ITPP941, Rollo, IDPRT, POLONO, Jiose, and Jadens. Provides solutions for common issues such as blinking red lights, incorrect label darkness, and offers instructions for calibration, setting density, and speed for both Windows and Mac operating systems.</p>	

 <p>How to print different size and shape labels?</p> <p>Instructions:</p> <ol style="list-style-type: none"> 1 Download 'Jadens Printer' from google play or apple from their app store. 2 Open the App 'Jadens Printer' 	<p>How to Print Different Size and Shape Labels with Jadens Printer</p> <p>A step-by-step guide on how to print custom-sized and shaped labels using the Jadens Printer app and Bluetooth thermal label printer. Covers downloading the app, connecting the printer, selecting files, cropping, rotating, and adjusting print settings for various label types.</p>
 <p>PEDOOLO®</p> <p>Smartphone APP Quick User Guide</p> <p>Thank you for choosing the BY-482BT printer. Please read this guide for a full and easy set-up in your everyday use.</p>	<p>PEDOOLO BY-482BT Printer: Smartphone App Quick User Guide</p> <p>A quick user guide for the PEDOOLO BY-482BT printer, detailing how to set up and use the 'Label Expert' smartphone application for printing various label types, including PDF files and scanned barcodes.</p>
	<p>REKDOM WU550 Wireless Label Printer User Manual</p> <p>User manual for the REKDOM WU550 Wireless Label Printer, covering setup, connection, specifications, and troubleshooting. Learn how to print labels efficiently for shipping, barcodes, and more.</p>
 <p>Label Frequently Asked Questions</p> <p>1. How do I connect my printer to my computer? 2. How do I print from my smartphone? 3. How do I print from my tablet? 4. How do I print from my laptop? 5. How do I print from my desktop computer? 6. How do I print from my network printer? 7. How do I print from my wireless printer? 8. How do I print from my cloud printer? 9. How do I print from my mobile device? 10. How do I print from my desktop computer? 11. How do I print from my laptop? 12. How do I print from my tablet? 13. How do I print from my smartphone? 14. How do I print from my network printer? 15. How do I print from my wireless printer? 16. How do I print from my cloud printer? 17. How do I print from my mobile device? 18. How do I print from my desktop computer? 19. How do I print from my laptop? 20. How do I print from my tablet? 21. How do I print from my smartphone? 22. How do I print from my network printer? 23. How do I print from my wireless printer? 24. How do I print from my cloud printer? 25. How do I print from my mobile device?</p>	<p>Label Printer Troubleshooting FAQ: MUNBYN, Rollo, Jadens, and More</p> <p>Comprehensive FAQ and troubleshooting guide for common issues with MUNBYN, Rollo, Jadens, NELKO, IDPRT, POLONO, and Jiose label printers. Covers print quality, connectivity, and calibration problems.</p>