

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [YOKEKON](#) /

> [YOKEKON Rice Cooker Instruction Manual](#)

## YOKEKON KC-RC-ESL005

# YOKEKON Rice Cooker Instruction Manual

Model: KC-RC-ESL005

## 1. INTRODUCTION

Thank you for purchasing the YOKEKON Rice Cooker. This appliance is designed to simplify your cooking experience with its versatile functions and durable stainless steel inner pot. Please read this manual thoroughly before use to ensure safe and optimal operation.

## 2. PRODUCT FEATURES

- **6 Cup Large Capacity:** Suitable for families of 4-6 people, with a maximum capacity of 7 cups uncooked rice.
- **Multi-functional Menu:** Features settings for Brown Rice, White Rice, Steam, Quick Cook, and Yogurt.
- **Stainless Steel Inner Pot:** Made with robust, non-reactive stainless steel, preserving flavors and nutrients. Dishwasher-friendly for easy cleaning.
- **Delay Timer & Keep Warm Function:** Allows for preset cooking times and automatically transitions to keep-warm mode after cooking.
- **Triple Heaters & Dual Temperature Control:** Ensures even cooking and precise temperature control for perfectly cooked rice.

## 3. COMPONENTS AND PARTS

The YOKEKON Rice Cooker comes with the following components:

- Main Rice Cooker Unit
- Stainless Steel Inner Pot
- Steamer Basket
- Measuring Cup
- Rice Spoon



Image: Main rice cooker unit with the stainless steel inner pot placed in front.



Image: Close-up view of the stainless steel inner pot, showing internal measurement markings.

## 4. SETUP

1. Unpack all components from the packaging.

2. Wash the stainless steel inner pot, steamer basket, measuring cup, and rice spoon with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
5. Insert the clean, dry inner pot into the main unit.

## 5. OPERATING INSTRUCTIONS

---

Follow these general steps for cooking with your YOKEKON Rice Cooker:

1. Measure the desired amount of rice using the provided measuring cup. Rinse the rice thoroughly until the water runs clear.
2. Place the rinsed rice into the stainless steel inner pot.
3. Add the appropriate amount of water according to the rice type and desired consistency. Refer to the water level markings inside the inner pot.
4. Place the inner pot into the rice cooker and close the lid securely.
5. Plug the power cord into a suitable electrical outlet.
6. Select your desired cooking function (e.g., Rice, Brown Rice, Quick Cook) by pressing the corresponding button on the control panel.
7. Press the "Start" button to begin cooking. The display will show the remaining cooking time or a countdown.
8. Once cooking is complete, the rice cooker will typically beep and automatically switch to "Keep Warm" mode.
9. Allow the rice to rest in "Keep Warm" mode for 10-15 minutes before serving for optimal texture.
10. Unplug the appliance after use.



Image: A hand pressing the 'Start' button on the rice cooker's control panel.

## 6. COOKING FUNCTIONS

---

The YOKEKON Rice Cooker offers several specialized cooking functions:

- **Rice:** Standard setting for white rice. Provides perfectly cooked, fluffy rice.
- **Brown Rice:** Optimized for cooking brown rice, ensuring proper texture and doneness.
- **Steam:** Use the included steamer basket to steam vegetables, fish, dumplings, or other foods while rice cooks below, or independently.



Image: A steamer basket filled with vegetables being placed into the rice cooker for simultaneous cooking.

- **Quick Cook:** Reduces cooking time for white rice when you need it faster.

# QUICK COOK

Save up to 50% of time.



Image: The rice cooker highlighting the "Quick Cook" function, indicating a cooking time of approximately 30 minutes.

- **Yogurt:** Allows for easy preparation of homemade yogurt.



Image: The rice cooker with an open lid, showing yogurt inside, and examples of different yogurt preparations.

- **Delay Timer (Preset):** Set a delayed start time for your cooking, up to 12 hours in advance.



Image: The rice cooker on a kitchen counter with a clock, symbolizing the 12-hour delay timer and keep warm function.

## Video Demonstration:

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the YOKEKON 6-cup rice cooker, including its stainless steel inner pot, multi-functional menu, and cooking capabilities for various grains and dishes.

## 7. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your rice cooker:

- Always unplug the rice cooker and allow it to cool completely before cleaning.
- The stainless steel inner pot is dishwasher-safe. For hand washing, use warm, soapy water and a non-abrasive sponge.
- The steamer basket, measuring cup, and rice spoon can also be washed in the dishwasher or by hand.
- Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- The detachable steam valve can be removed for cleaning. Ensure it is clean and properly reattached before next use.



**Portable Handle**



**Rice Spoon Rack**



**Detachable Steam Valve**



**Dishwasher Safe**

Image: A composite image showing the portable handle, rice spoon rack, detachable steam valve, and the stainless steel inner pot being cleaned in a dishwasher.

## 8. TROUBLESHOOTING

If you encounter any issues with your rice cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard/undercooked.	Insufficient water, incorrect rice-to-water ratio, lid not properly closed.	Add more water next time, ensure lid is sealed, allow rice to rest in Keep Warm mode.
Rice is too soft/mushy.	Too much water, rice not rinsed properly.	Reduce water next time, rinse rice thoroughly before cooking.
"E5" error displayed.	Sensor malfunction or internal issue.	Unplug the unit, wait a few minutes, then plug it back in. If the error persists, contact customer service.
Unit does not power on.	Power cord not properly plugged in, power outlet issue.	Check power connections, try a different outlet.

For issues not listed here, please contact YOKEKON customer support.

## 9. SPECIFICATIONS

**Brand:** YOKEKON

**Model Name:** Rice cooker

**Item Model Number:** KC-RC-ESL005

**Capacity:** 2 Liters (6 cups uncooked rice)

**Product Dimensions:** 12.99"D x 8.27"W x 9.83"H

**Power Source:** Corded Electric

**Voltage:** 120 Volts

**Wattage:** 4500 Watts

**Material:** Stainless Steel (Inner Pot), Plastic (Exterior)

**Color:** Black

**Item Weight:** 4 Pounds

**Special Feature:** Automatic Keep Warm

**Product Care Instructions:** Hand Wash (Inner Pot is Dishwasher Safe)

## 10. WARRANTY AND SUPPORT

YOKEKON provides a **1-year manufacturer warranty** with the purchase of this rice cooker. For any questions, concerns, or warranty claims, please refer to the customer service information provided in the original packaging or contact YOKEKON customer support directly.

For further assistance, please visit the official YOKEKON store: [YOKEKON Store on Amazon](#)