

[Manuals.plus](#) /

› [LONTEK](#) /

› LONTEK A1 Portable Incline Walking Pad Treadmill User Manual

LONTEK A1

LONTEK A1 Portable Incline Walking Pad Treadmill

USER MANUAL

Introduction

Welcome to the user manual for your LONTEK A1 Portable Incline Walking Pad Treadmill. This document provides essential information for the safe and effective operation, setup, maintenance, and troubleshooting of your new fitness equipment. Please read this manual thoroughly before initial use and retain it for future reference.



Image: The LONTEK A1 Walking Pad Treadmill shown in use by a person walking, and also folded for easy carrying and storage. This illustrates its compact and portable design.

Safety Instructions

To ensure your safety and prolong the life of your treadmill, please adhere to the following guidelines:

- Consult a physician before starting any new exercise program.
- Place the treadmill on a flat, stable surface with adequate clearance around it.
- Keep children and pets away from the treadmill during operation.
- Wear appropriate athletic footwear.
- Do not use the treadmill if you feel dizzy, faint, or experience any pain.
- Ensure the power cord is not damaged and is properly connected to a grounded outlet.
- Do not attempt to service the treadmill yourself. Contact customer support for assistance.
- The maximum user weight capacity for this treadmill is 300 pounds (approximately 136 kg).

Setup

Your LONTEK A1 Walking Pad Treadmill is designed for minimal setup.

1. **Unpacking:** Carefully remove the treadmill and all included components (lubricant, power cord, remote control, tool kit) from the packaging.
2. **Placement:** Position the treadmill on a level surface. Ensure there is sufficient space around the unit for safe operation. The compact design (45.7" x 19.7" x 4.57") allows for placement in various home or office environments.
3. **Power Connection:** Connect the power cord to the treadmill and then to a suitable grounded electrical outlet.
4. **Portability:** The treadmill weighs approximately 38.6 pounds and features built-in wheels, making it easy to move and store.

Easy to Store and Move space saving



Image: The LONTEK A1 Walking Pad Treadmill shown stored upright next to a desk, highlighting its space-saving design and ease of storage.

Portable and Easy to Lift



Image: A person carrying the LONTEK A1 Walking Pad Treadmill up a flight of stairs, demonstrating its lightweight and portable nature.

Operating Instructions

Follow these steps to operate your LONTEK A1 Walking Pad Treadmill:

1. **Power On:** Plug in the treadmill and press the power button, usually located on the front panel.
2. **Control Methods:**

- **Remote Control:** Use the included wireless remote control to start, stop, and adjust the speed.
 - **SPAX App:** Connect your treadmill via Bluetooth to the SPAX app on your smartphone for additional control and tracking features.
3. **Adjusting Speed:** Use the speed controls on the remote or app to increase or decrease your walking speed. The treadmill features a quiet 2.5HP brushless motor.
 4. **Adjusting Incline:** The treadmill offers a manual two-stage incline adjustment up to 3%. This adjustment can increase calorie expenditure during your workout. Refer to the specific mechanism on your unit for manual adjustment.
 5. **Monitoring Data:** The integrated LED display shows real-time exercise data, including time, distance, calories burned, and current speed.
 6. **Shock Absorption:** The treadmill is equipped with 4 silicone shock-absorbing blocks, 8 built-in shock absorbers, and a double-layer structure to minimize impact on your joints.
 7. **Power Off:** After your workout, press the stop button on the remote or app, then turn off the main power switch and unplug the unit.

Adjustable Incline for Fat-Burning

0% Incline



3% Incline



Image: A visual representation of the LONTEK A1 Walking Pad Treadmill with 0% incline and 3% incline settings, illustrating how the manual incline adjustment can increase calorie burning.

Real-time data DISPLAY



Speed



Distance



Time



Calories



Image: A detailed view of the LONTEK A1 Walking Pad Treadmill's LED display, showing real-time data such as time, speed, distance, and calories. The remote control is also visible, indicating control options.

For Joint Protection




Image: An illustration highlighting the joint protection features of the LONTEK A1 Walking Pad Treadmill, including silicone pads and shock absorbers, designed to reduce impact during exercise.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your treadmill.

- **Cleaning:** Wipe down the treadmill surface with a damp cloth after each use to remove sweat and dust. Do not use

abrasive cleaners.

- **Lubrication:** Periodically lubricate the running belt according to the instructions provided with the included lubricant. This helps maintain smooth operation and reduces wear.
- **Belt Adjustment:** If the running belt feels loose or off-center, refer to the tool kit and specific instructions for adjusting belt tension and alignment.
- **Storage:** When not in use, store the treadmill in a dry, cool place. Its compact size allows for easy storage under furniture or against a wall.

Troubleshooting

If you encounter any issues with your LONTEK A1 Walking Pad Treadmill, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Treadmill does not power on.	Power cord not connected, outlet issue, main switch off.	Ensure power cord is securely plugged in. Check the wall outlet. Verify the main power switch is in the 'ON' position.
Running belt slips or stops.	Belt too loose, insufficient lubrication, excessive user weight.	Adjust belt tension as per maintenance instructions. Apply lubricant if needed. Ensure user weight does not exceed 300 lbs.
Unusual noise during operation.	Loose components, belt misalignment, motor issue.	Check for any loose screws or parts. Adjust belt alignment. If noise persists, discontinue use and contact customer support.
Remote control not responding.	Dead batteries, remote out of range, interference.	Replace remote control batteries. Ensure you are within range. Remove any obstructions between the remote and the treadmill.

For issues not listed here or if troubleshooting steps do not resolve the problem, please contact LONTEK customer support.

Specifications

Feature	Detail
Brand	LONTEK
Model Name	A1
Item Model Number	A3
Product Dimensions	116.1D x 50W x 11.6H Centimeters (45.7" x 19.7" x 4.57")
Item Weight	21 kg 500 g (approximately 38.6 lbs)
Material	Acrylonitrile Butadiene Styrene (ABS)
Maximum Speed	4 Miles per Hour
Motor Horsepower	2.5 HP (Brushless)

Feature	Detail
Maximum Incline	3% (Manual Two-Stage)
Maximum Weight Recommendation	300 Pounds
Input Power	300 Watts
Special Features	Manual Incline, Shock Absorbent (4 silicone pads, 8 built-in absorbers, double-layer structure), LED Display, Remote Control, Bluetooth (SPAX App)
Included Components	Lubricant, Power Cord, Remote Control, Tool Kit, User Manual

DIMENSION

11.6cm
/4.57"



116cm / 45.7"

50cm
/19.7"

Image: A diagram illustrating the dimensions of the LONTEK A1 Walking Pad Treadmill, showing its length, width, and height in both centimeters and inches.

Warranty and Support

LONTEK products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official LONTEK website.

For technical support, replacement parts, or any other inquiries, please contact LONTEK customer service. Contact

details can typically be found on the product packaging, the official website, or your purchase documentation.

© 2024 LONTEK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D4DSR39N>

More documents and user manuals: <https://manuals.plus/>