

[Manuals.plus](#) /

> [PHILIPS](#) /

> Philips Airfryer Combi 7000 Series XXL Instruction Manual

PHILIPS HD9876/20

Philips Airfryer Combi 7000 Series XXL Instruction Manual

Model: HD9876/20

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Philips Airfryer Combi 7000 Series XXL. Please read it thoroughly before first use and keep it for future reference.

The Philips Airfryer Combi 7000 Series XXL is designed to offer versatile cooking options, including frying, baking, grilling, roasting, dehydrating, braising, and more, all within a single appliance. It features Rapid CombiAir Technology for precise airflow control and can be connected to the HomeID App for guided cooking.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Do not immerse the appliance in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting it.
- Do not use the appliance if the plug, the mains cord, or the appliance itself is damaged.
- Keep the appliance and its cord out of reach of children.
- Do not let the mains cord hang over the edge of a table or worktop.
- Do not plug in the appliance or operate the control panel with wet hands.
- Always unplug the appliance after use and before cleaning.
- The surfaces may become hot during use. Do not touch hot surfaces directly.
- This appliance is intended for household use only.

3. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your Philips Airfryer Combi 7000 Series XXL.



Main Unit: The primary housing of the Airfryer, featuring the control panel and air vents. This image shows the front of the white model with its digital display and golden control knob.



Food Drawer and Basket: The removable drawer contains the cooking basket where food is placed. This image illustrates the drawer pulled out with food inside, demonstrating its capacity.



Control Panel: Features a digital display for temperature and time settings, along with various cooking mode icons and a rotary knob for adjustments. The "Rapid CombiAir Technology" logo is visible below the display.

4. SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials from the appliance.
2. **Cleaning:** Before first use, clean the food drawer and cooking basket with hot water, dish soap, and a non-abrasive sponge. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the Airfryer on a stable, horizontal, and level surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides, and above the appliance, to allow for proper air circulation.
4. **Power Connection:** Plug the appliance into a grounded wall outlet.
5. **Pre-heating (Optional):** For optimal results, pre-heat the Airfryer for 3-5 minutes at the desired cooking temperature before adding food.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. Pull out the food drawer from the appliance.
2. Place the ingredients into the cooking basket. Do not exceed the MAX indication.
3. Slide the food drawer back into the Airfryer.
4. Turn the control knob to select the desired cooking program or manually set the temperature and time.
5. Press the start button to begin cooking.
6. Some ingredients require shaking halfway through the preparation time. To shake the ingredients, pull the drawer out of the appliance by the handle and shake it. Then slide the drawer back into the Airfryer.
7. When the cooking time has elapsed, the appliance will beep. Pull out the drawer and carefully remove the food.

5.2 Rapid CombiAir Technology

The Rapid CombiAir Technology allows for high, low, and dynamic airflow settings, ensuring precise cooking results. This technology adapts the airflow to the specific food item, providing consistent and delicious outcomes.



Image: Visual representation of Rapid CombiAir Technology airflow.

5.3 Automatic Cooking Programs

The Airfryer Combi features automatic cooking programs. Simply select your ingredient and quantity, and the Airfryer will automatically adjust the settings for optimal cooking. Refer to the display for available programs.



Image: The Airfryer in a kitchen setting, highlighting its use with automatic cooking programs for various meals.

5.4 HomeID App Connectivity

Connect your Airfryer to the HomeID App for an enhanced cooking experience. The app provides delicious and healthy recipes, step-by-step guided cooking, and precise settings for perfect results every time.

- Download the HomeID App from your device's app store.
- Follow the in-app instructions to pair your Airfryer with your mobile device via Wi-Fi.
- Explore recipes, send cooking programs directly to your Airfryer, and monitor cooking progress remotely.



Image: The HomeID app interface, demonstrating its features for recipe discovery and guided cooking.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your Airfryer. Always unplug the appliance and allow it to cool down completely before cleaning.

6.1 Cleaning the Basket and Drawer

- Remove the food drawer and basket.
- The basket and drawer are dishwasher-safe. Alternatively, clean them with hot water, dish soap, and a non-abrasive sponge.
- For stubborn food residue, soak the basket and drawer in hot water with some dish soap for approximately 10 minutes.

6.2 Cleaning the Main Unit

- Wipe the exterior of the appliance with a damp cloth.
- Clean the interior of the appliance with a non-abrasive sponge or cloth.
- If necessary, use a cleaning brush to remove any food residue from the heating element.

Note: Do not use abrasive cleaning materials or steel wool, as they can damage the non-stick coating and surfaces.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Philips Airfryer Combi 7000 Series XXL.

Problem	Possible Cause	Solution
The Airfryer does not work.	The appliance is not plugged in.	Plug the mains plug into a grounded wall socket.
Food is not cooked evenly.	Too much food in the basket; food not shaken.	Reduce the amount of food per batch. Shake the basket halfway through cooking.
White smoke comes out of the appliance.	Fat residues from previous use; fatty ingredients.	Clean the basket and drawer thoroughly. Remove excess oil from ingredients.
Fresh fries are not crispy.	Not enough oil used; incorrect potato type.	Ensure potatoes are properly dried before adding a light coating of oil. Use fresh potatoes suitable for frying.
Cannot connect to HomeID App.	Wi-Fi issues; incorrect pairing steps.	Ensure your Wi-Fi network is stable. Restart the Airfryer and your mobile device. Follow the app's pairing instructions carefully.

8. TECHNICAL SPECIFICATIONS

- Model Number:** HD9876/20
- Capacity:** 8.3 Liters (2 kg)
- Power:** 2000 Watts
- Voltage:** 220 Volts
- Dimensions (L x W x H):** 44.27 x 33.46 x 35.77 cm
- Weight:** 9.42 Kilograms
- Material:** Stainless Steel
- Special Feature:** Wi-Fi Connectivity

9. WARRANTY AND SUPPORT

Philips provides a warranty for this product in accordance with the laws of the country where it is purchased. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Philips website.

For technical support, product registration, or to find answers to frequently asked questions, please visit the Philips support page or contact Philips Consumer Care in your region. Keep your proof of purchase for warranty claims.

Online Support: www.philips.com/support



© 2025 PHILIPS. All rights reserved.
Philips Airfryer Combi 7000 Series XXL - Model HD9876/20