

PHILIPS HD9876/90

Philips Airfryer Combi 7000-Series XXL User Manual

Model: HD9876/90

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Philips Airfryer Combi 7000-Series XXL (Model HD9876/90). Please read these instructions carefully before first use and retain them for future reference. This appliance is designed for household use only.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact Philips customer support for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Do not block any ventilation openings.

3. PRODUCT OVERVIEW

The Philips Airfryer Combi 7000-Series XXL is a versatile kitchen appliance designed for various cooking methods with minimal added fat. It features advanced technology and smart connectivity for an enhanced cooking experience.

3.1 Key Features

- **Rapid CombiAir Technology:** Provides high, low, and dynamic airflow settings for precise cooking results.
- **Auto-Cooking Programs:** Automatically adjusts settings based on ingredients and quantity.
- **Energy Saving:** Cooks meals efficiently, saving up to 70% energy compared to traditional ovens.
- **HomeID App Connectivity:** Access recipes, guided cooking, and remote control via the HomeID app.
- **22-in-1 Cooking Functions:** Offers versatile options including frying, baking, grilling, roasting, dehydrating, and braising.

3.2 Components

Familiarize yourself with the main parts of your Airfryer Combi:



Figure 1: Front View of the Philips Airfryer Combi 7000-Series XXL. This image displays the appliance from the front, showing the digital control panel with temperature and time display, and the main handle for the cooking basket.



Figure 2: Airfryer with Cooking Basket Partially Open. The image shows the Airfryer with its cooking basket pulled out, revealing cooked food (chicken and vegetables) inside, demonstrating its capacity.



Figure 3: Angled View of Airfryer with Open Basket. This perspective highlights the design of the appliance and the accessible cooking basket, containing food, ready for serving or further cooking.



Figure 4: Interior View of the Airfryer. The image provides a close-up of the interior, showcasing the heating element and the design of the cooking chamber, emphasizing the Rapid CombiAir Technology.



Figure 5: Airflow Diagram within the Airfryer. This illustrative image demonstrates the internal airflow pattern, highlighting how the Rapid CombiAir Technology circulates hot air for even cooking.



Figure 6: Cooking Basket with Food. A user is shown holding the cooking basket filled with a prepared meal (roast chicken and asparagus), illustrating the ease of handling and serving.

4. SETUP

4.1 Unpacking

1. Carefully remove all packaging materials from the appliance.

2. Remove any stickers or labels from the appliance.
3. Wash the basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge.
4. Wipe the inside and outside of the appliance with a moist cloth.

4.2 Placement

- Place the appliance on a stable, horizontal, and level surface.
- Do not place the appliance on non-heat-resistant surfaces.
- Ensure there is at least 10 cm (4 inches) of free space at the back, sides, and above the appliance to allow for proper ventilation.

4.3 First Use

Before using your Airfryer for the first time, perform a short empty run to eliminate any manufacturing odors:

1. Plug the appliance into a grounded wall outlet.
2. Pull out the pan with the basket from the appliance.
3. Set the temperature to 180°C (350°F) and the timer to 10 minutes.
4. Start the cooking cycle. A slight odor may be present, which is normal.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. Plug the Airfryer into a power outlet.
2. Pull out the pan and place ingredients into the basket. Do not exceed the MAX indication.
3. Slide the pan back into the Airfryer.
4. Press the power button to turn on the appliance.
5. Use the temperature and time controls on the digital display to set your desired cooking parameters.
6. Press the start button to begin cooking.
7. Some ingredients require shaking halfway through the preparation time. Pull out the pan by the handle and shake it. Then slide the pan back into the Airfryer.
8. When the cooking time has elapsed, the appliance will beep. Carefully pull out the pan and check if the ingredients are ready.
9. Empty the basket contents into a bowl or onto a plate.

5.2 Using the HomeID App

The Philips Airfryer Combi 7000-Series XXL can be connected to the HomeID app for enhanced functionality:

- Download the HomeID app from your smartphone's app store.
- Follow the in-app instructions to connect your Airfryer to your home Wi-Fi network.
- Once connected, you can access a wide range of recipes, guided cooking programs, and remotely control your Airfryer.
- The app provides personalized cooking recommendations and step-by-step guidance for various dishes.

5.3 Auto-Cooking Programs and 22-in-1 Functions

Leverage the Airfryer's intelligent features for effortless cooking:

- **Auto-Cooking Programs:** Select your ingredients and quantity, and the Airfryer will automatically set the optimal temperature and time. Refer to the HomeID app for a full list of available programs.
- **22-in-1 Functions:** Explore various cooking methods such as air frying, baking, grilling, roasting, dehydrating, toasting, defrosting, reheating, braising, slow cooking, stewing, simmering, sous vide, keep warm, fermenting, making yogurt, proofing, making sauces, thickening, making purees, making compotes, and more. Specific settings for these functions can be found in the HomeID app or by manually adjusting temperature and time.

6. MAINTENANCE AND CLEANING

Regular cleaning of your Philips Airfryer Combi ensures optimal performance and extends its lifespan. Always unplug the appliance and allow it to cool completely before cleaning.

6.1 Cleaning the Pan and Basket

- Remove the pan and basket from the Airfryer.
- Wash the pan and basket with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak the pan and basket in hot water with dish soap for approximately 10 minutes.
- **Note:** The pan and basket are **not dishwasher safe**. Hand wash only.

6.2 Cleaning the Interior and Exterior

- Wipe the exterior of the appliance with a moist cloth.
- Clean the interior of the appliance with hot water and a non-abrasive sponge.
- For the heating element, use a cleaning brush to remove any food residues.

7. TROUBLESHOOTING

If you encounter issues with your Philips Airfryer Combi, consult the following table for common problems and solutions:

Problem	Possible Cause	Solution
The Airfryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
Ingredients are not cooked evenly.	Too many ingredients in the basket; ingredients need shaking.	Reduce the amount of ingredients; shake the basket halfway through cooking.
White smoke comes out of the appliance.	Fat residues from previous use; fatty ingredients being cooked.	Clean the pan and basket thoroughly; remove excess oil from ingredients.
Fresh fries are not crispy.	Incorrect potato type; not rinsed properly; too much oil.	Use starchy potatoes; rinse potato sticks thoroughly and dry them; add only a small amount of oil.

Problem	Possible Cause	Solution
Appliance not connecting to HomeID App.	Wi-Fi issues; incorrect setup.	Ensure your Wi-Fi network is stable; restart the Airfryer and your router; follow app's connection guide carefully.

8. SPECIFICATIONS

Feature	Detail
Model Name	HD9876/90
Brand	PHILIPS
Capacity	8.3 litres (suitable for 7 persons)
Output Wattage	2000 Watts
Voltage	220 Volts
Product Dimensions (D x W x H)	44.3D x 33.5W x 35.8H Centimeters
Item Weight	9.42 Kilograms
Colour	Black
Nonstick Coating	No
Dishwasher Safe Parts	No
Manufacture Year	2024

9. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Philips website for your region. Philips offers comprehensive customer support for its products.

If you require service, support, or have questions about your Philips Airfryer Combi 7000-Series XXL, please contact Philips customer service. Contact details can typically be found on the Philips website or in the product packaging. Online resources, including FAQs and troubleshooting guides, are also available on the Philips support website.