

Midea MAD53109APK

Midea Air Fryer 5.5 Quart Instruction Manual

Model: MAD53109APK

Brand: Midea

INTRODUCTION

The Midea Air Fryer 5.5 Quart is designed to provide a convenient and efficient way to prepare a variety of meals with less oil. Utilizing Heatexpress Rapid Air Technology, this appliance circulates hot air to cook food quickly and evenly, resulting in crispy exteriors and tender interiors. Its intuitive touch control panel and 9 versatile preset menus simplify the cooking process, while the integrated see-through window allows for easy monitoring of food without interrupting the cooking cycle. This manual provides essential information for the safe and effective operation, maintenance, and care of your Midea Air Fryer.

PRODUCT OVERVIEW



The Midea Air Fryer 5.5 Quart, showcasing its sleek black design and prominent see-through window, ideal for monitoring cooking progress.

Key Features

- **9 Versatile Preset Menu Options:** Easy touch control for effortless cooking with options for: air fry, grill, bake, roast, broil, bagel, dehydrate, keep warm, and reheate.
- **Heatexpress Rapid Air Technology:** Patented technology offers optimized airflow convection allowing rapid hot air to cook the food faster and evenly to deliver the fried perfection you're craving.
- **+1 Minute Button & Favorite Function:** The flexible heating function allows you to increase cooking time by +1 minute at any time. Also, once you've perfected a recipe, press the FAV + save button and hold for 3 seconds to easily use the same cooking setting again.
- **Viewing Window:** Monitor your air-fryer oven's cooking progress, ensuring a perfect cook and precision every single time.
- **Durable Metallic Interior:** With the all-around metallic interior wall, your food heats up evenly and quickly.
- **Dishwasher Safe:** The non-stick cooking basket and detachable components make cleaning a breeze.

SETUP AND FIRST USE

Unpacking and Placement

1. Carefully remove all packaging materials from the air fryer and its accessories.
2. Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is adequate space (at least 6 inches) around the appliance for proper air circulation. Do not place it directly against a wall or under cabinets.

Initial Cleaning

1. Before first use, wash the removable cooking basket and crisping tray with warm, soapy water. Rinse thoroughly and dry completely.
2. Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.

First Use Operation

1. Insert the crisping tray into the cooking basket, then slide the basket into the air fryer until it clicks into place.
2. Plug the air fryer into a grounded electrical outlet.
3. For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight odor or smoke may be present, which is normal and will dissipate.

OPERATING INSTRUCTIONS

Control Panel Overview

The Midea Air Fryer features an intuitive touch control panel for easy operation.

+1 MINUTE BUTTON



Close-up of the Midea Air Fryer's touch control panel, highlighting the '+1 Min' button for quick time adjustments.

Cooking with Preset Menus

The air fryer comes with 9 pre-programmed settings for common dishes:

MULTI-FUNCTIONALITY



FRENCH FRIES



FISH



STEAK



CHICKEN



VEGETABLE



BAKE



DEHYDRATE



MORE

Visual representation of the Midea Air Fryer's versatility, showing various food types it can prepare, including French fries, fish, steak, chicken, vegetables, baked goods, and dehydrated items.

1. Place your food in the cooking basket. Do not overfill.
2. Select the desired preset menu option (e.g., Air Fry, Grill, Bake, Roast, Broil, Bagel, Dehydrate, Keep Warm, Reheat) by touching the corresponding icon on the control panel.
3. The air fryer will automatically set the recommended temperature and time for that preset.
4. Press the 'Start/Pause' button to begin cooking.

Manual Temperature and Time Adjustment

1. Place your food in the cooking basket.
2. Use the 'Temp +/-' buttons to set the desired cooking temperature (range: 104°F–400°F).
3. Use the 'Time +/-' buttons to set the desired cooking time (range: 1-60 minutes).
4. Press the 'Start/Pause' button to begin cooking.

Using the +1 Minute Button

During cooking, you can instantly add one minute to the remaining cooking time by pressing the '+1 Min' button. This is useful for achieving extra crispiness or ensuring food is cooked to your preference.

Favorite Function

To save a frequently used cooking setting:

1. Set your desired temperature and time manually.
2. Press and hold the 'FAV (Save/Hold 3 sec)' button for 3 seconds. The setting will be saved.

To recall a saved favorite setting:

- Simply press the 'FAV' button. The saved temperature and time will appear.
- Press 'Start/Pause' to begin cooking with your favorite setting.

Viewing Window and Light

The integrated see-through window allows you to monitor your food without opening the basket, which helps maintain consistent cooking temperature. Press the 'Light' button to illuminate the interior of the air fryer for better visibility.

HEATXPRESS TECHNOLOGY

Up to
57%
Faster cooking*

Up to
70%
Energy saving*



* Compared to a Midea conventional oven.

Illustration demonstrating the Heatexpress Rapid Air Technology, showing hot air circulating within the air fryer for efficient cooking.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your Midea Air Fryer.

General Cleaning

1. Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads.

Dishwasher Safe Components

DISHWASHER SAFE



The removable non-stick cooking basket and crisping tray are designed for easy cleaning and are dishwasher safe.

- The non-stick cooking basket and detachable crisping tray are dishwasher safe. For best results and to prolong the non-stick coating, hand washing with warm, soapy water is recommended.

- Ensure all parts are completely dry before reassembling or storing the air fryer.

Storage

Store the air fryer in a cool, dry place when not in use. Ensure the power cord is neatly wrapped and secured.

TROUBLESHOOTING

If you encounter any issues with your Midea Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; Power outlet malfunction; Basket not properly inserted.	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance. Make sure the cooking basket is fully inserted and clicked into place.
Food is not cooked evenly.	Basket is overcrowded; Temperature/time settings are incorrect.	Cook food in smaller batches. Shake or flip food halfway through cooking. Adjust temperature and/or time as needed for specific recipes.
White smoke coming from the appliance.	Grease residue from previous use; High-fat food cooking.	Clean the basket and crisping tray thoroughly after each use. For high-fat foods, drain excess fat from the basket during cooking.
Unusual odor during first use.	Manufacturing residue.	This is normal for the first few uses. Run the air fryer empty for 10-15 minutes as described in the 'Setup' section. Ensure good ventilation.

SPECIFICATIONS

Specification	Value
Model Name	MAD53109APK
Capacity	5.5 Quarts (5.5 Liters)
Product Dimensions (L x W x H)	11.81"L x 10.66"W x 13.54"H
Color	Black with See-Thru Window
Material	Metal
Output Wattage	1500 Watts
Voltage	120 Volts
Control Method	Touch
Temperature Range	104°F–400°F
Timer Range	1 to 60 minutes

Specification	Value
Nonstick Coating	Yes
Dishwasher Safe Components	Yes (Basket and Tray)
Item Weight	10.1 Pounds
UPC	840296511060

WARRANTY AND SUPPORT

Midea provides a one-year manufacturer warranty for this product. For detailed warranty information, customer service, or technical support, please refer to the complete user manual included with your purchase or visit the official Midea website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 Midea. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question