

[Manuals.plus](#) /

> [GOOFY TURTLE](#) /

> GOOFY TURTLE Vegetable Chopper, Dicer, Slicer Instruction Manual - Model ART 1803443

GOOFY TURTLE ART 1803443

GOOFY TURTLE Vegetable Chopper, Dicer, Slicer

Model: ART 1803443

INTRODUCTION

The GOOFY TURTLE Vegetable Chopper, Dicer, and Slicer is a versatile kitchen tool designed to simplify your food preparation. This manual provides essential information for safe setup, operation, and maintenance of your new appliance. With its sharp stainless steel blades and ergonomic design, it efficiently slices, dices, chops, grates, and juliennes a wide variety of fruits and vegetables.

SAFETY INSTRUCTIONS

WARNING: Blades are extremely sharp. Handle with extreme care to prevent injury.

- Never touch the blades directly with your hands.
- Always use the provided food pusher or a cut-resistant glove when operating the slicer or grater attachments.
- Ensure all attachments are securely locked into place before use.
- Keep the appliance and all its components out of reach of children.
- Do not force food through the blades; apply firm, even pressure.

PACKAGE CONTENTS

Your GOOFY TURTLE Vegetable Chopper package includes the following components:

- Main Chopper Unit with Integrated Collection Container
- Fine 12x12 Dicer Blade
- Large 6x6 Dicer Blade
- Slicer/Mandoline Attachment
- Grater Attachment
- Julienne Blade Attachment
- Spiralizer Attachment

- Food Pusher/Hand Guard
- Cleaning Brush
- Cleaning Scraper/Fork
- Blade Storage Organizer



Image: All components of the GOOFY TURTLE Vegetable Chopper, including various blades, container, and cleaning tools.

SETUP

1. Unpack all components from the packaging.
2. Wash all parts with warm, soapy water before initial use. Rinse thoroughly and dry.
3. Place the main chopper unit on a stable, flat surface.
4. Ensure the transparent collection container is securely attached underneath the chopping base.
5. Select the desired blade insert (e.g., Fine Dicer, Large Dicer, Slicer, Grater, Julienne, Spiralizer) and carefully insert it into the designated slot until it clicks securely into place.
6. For dicing, ensure the pusher block on the lid is aligned with the chosen dicer blade.



Image: The main vegetable chopper unit with a dicer blade inserted and a collection container underneath.

OPERATING INSTRUCTIONS

Dicing and Chopping

1. Select either the Fine 12x12 Dicer Blade or the Large 6x6 Dicer Blade and secure it in the main unit.

2. Place the food item (e.g., onion, potato, bell pepper) onto the center of the blade. For larger items, pre-cut them into smaller pieces that fit the blade area.
3. Align the top lid with the pusher block over the food.
4. With a swift, firm motion, press down on the lid to push the food through the blades.
5. The chopped food will fall directly into the collection container below.



Image: A hand pressing down on the chopper lid to dice vegetables into the container.

Slicing (Mandoline)

1. Replace the dicer blade with the Slicer/Mandoline Attachment.
2. Adjust the thickness setting using the side lever to your desired slice thickness.
3. Place the food item onto the mandoline surface. Always use the Food Pusher/Hand Guard to hold the food and protect your fingers.
4. Slide the food item back and forth across the blade with even pressure.

Grating and Julienne

1. Insert the Grater Attachment or Julienne Blade Attachment into the main unit.
2. Using the Food Pusher/Hand Guard, rub the food item across the grating or julienne surface.

Spiralizing

1. Attach the Spiralizer Attachment.
2. Insert a firm, cylindrical vegetable (e.g., cucumber, zucchini) into the spiralizer.
3. Twist the vegetable while applying gentle downward pressure to create spirals.

Your browser does not support the video tag.

Video: Demonstration of the GOOFY TURTLE Vegetable Chopper's various functions, including dicing, slicing, grating, and spiralizing, for efficient food preparation.

MAINTENANCE & CLEANING

Proper cleaning ensures the longevity and hygiene of your vegetable chopper.

- **Hand Wash Only:** The chopper is NOT dishwasher safe. All components should be hand washed.
- After each use, disassemble all parts.
- Use the provided Cleaning Brush and Scraper/Fork to carefully remove any food particles stuck in the blades or crevices.
- Wash all parts with warm, soapy water.
- Rinse thoroughly under running water.
- Dry all components completely before reassembling or storing to prevent rust and bacterial growth.



Image: The vegetable chopper with its various blades neatly stored in the included organizer for compact storage.

TROUBLESHOOTING

- **Food not cutting cleanly:** Ensure the blades are clean and free of debris. Make sure the food item is properly positioned on the blade and apply firm, even pressure.
- **Food stuck in blades:** Use the provided cleaning brush or scraper to carefully dislodge any stuck food. Never

use your fingers.

- **Difficulty attaching/detaching blades:** Ensure you are following the correct alignment and locking mechanisms. Do not force components.

SPECIFICATIONS

- **Brand:** GOOFY TURTLE
- **Model:** ART 1803443
- **Material:** Stainless Steel (Blades), Plastic (Body, Container, Attachments)
- **Product Dimensions:** 5"L x 5"W x 5"H
- **Item Weight:** 3 Pounds
- **Operation Mode:** Manual
- **Product Care Instructions:** Hand Wash Only
- **UPC:** 806700903333

WARRANTY & SUPPORT

For warranty information, product registration, or customer support inquiries, please refer to the original product packaging or contact GOOFY TURTLE customer service directly. Contact details can typically be found on the product box or our official website.