



[Manuals.plus](#) /

› [Prestige](#) /

› Prestige Multi-Chef All-in-One Air Fryer 6.5L Instruction Manual

Prestige Multichef AIO Air Fryer 6.5 L

Prestige Multi-Chef All-in-One Air Fryer 6.5L Instruction Manual

Model: Multichef AIO Air Fryer 6.5 L (Model No. 41410)

INTRODUCTION

Thank you for choosing the Prestige Multi-Chef All-in-One Air Fryer. This appliance is designed to provide versatile cooking options including air frying, oven baking, toasting, and grilling, with significantly less oil. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Prestige Multi-Chef All-in-One Air Fryer 6.5L



Image: The Prestige Multi-Chef All-in-One Air Fryer 6.5L, showcasing its sleek black design and compact form factor.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use attachments not recommended by the appliance manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

- Do not use the appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.
- The exterior surfaces may become hot during use. Use oven mitts when handling hot components.

PRODUCT OVERVIEW AND COMPONENTS

The Prestige Multi-Chef Air Fryer is designed for ease of use and efficient cooking. Familiarize yourself with its main components:

- **Main Unit:** Houses the heating element and fan.
- **Frying Basket:** Non-stick coated, 6.5L capacity, designed for even heat distribution.
- **See-Through Lid with Lamp:** Allows monitoring of food during cooking without opening.
- **Digital Control Panel:** Touch controls for time and temperature adjustment.
- **Cool-Touch Exterior:** Ensures safe handling during and after operation.

Safety You Can Feel Comfort You Can Trust



Image: The air fryer highlighting its see-through window with an internal lamp for monitoring food, and its cool-touch exterior for safe handling.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Cleaning:** Wipe the exterior of the appliance with a damp cloth. Wash the frying basket and any removable accessories with warm, soapy water. Rinse thoroughly and dry completely. The main unit is not dishwasher safe.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from walls and other appliances to allow for proper ventilation. Ensure there is at least 10 cm of free space on all sides.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The digital display will illuminate.
5. **Initial Run (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) to burn off any manufacturing residues. A slight odor may be present, which is normal.

The Prestige Multi-Chef Air Fryer features advanced digital controls for precise cooking.

Advanced Digital Control

Provides cooking convenience with an adjustable
Time and Temperature Control feature



Image: Close-up of the digital control panel with touch buttons for power, start/pause, temperature/time adjustment, and up/down arrows.

Basic Operation:

1. **Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Ensure the frying basket is securely placed inside the main unit. Close the lid.
3. **Power On:** Press the **ON/OFF** button to activate the display.
4. **Set Temperature:** Press the **TEMP/TIME** button once. Use the **UP** and **DOWN** arrows to adjust the temperature (100°C to 200°C).
5. **Set Time:** Press the **TEMP/TIME** button again. Use the **UP** and **DOWN** arrows to adjust the cooking time.
6. **Start Cooking:** Press the **START/PAUSE** button to begin the cooking cycle. The lamp inside will illuminate, and the

fan will start.

7. **Monitoring:** Use the see-through lid to monitor cooking progress.
8. **Pausing:** Press **START/PAUSE** to temporarily stop cooking. Press again to resume.
9. **Shaking/Flipping:** For even crisping, it is recommended to shake or flip ingredients halfway through cooking. Carefully open the lid, remove the basket, shake/flip, and reinsert. The appliance will pause automatically when the lid is opened.
10. **End of Cycle:** The air fryer will beep when the cooking time is complete. Carefully remove the cooked food.
11. **Power Off:** Press and hold the **ON/OFF** button to turn off the appliance. Unplug when not in use.

Cooking Functions (Airfry, Oven, Toast, Grill):

The Multi-Chef Air Fryer can perform various cooking tasks. The primary method of operation remains the same, with adjustments to temperature and time based on the desired function and food type.

- **Air Frying:** Ideal for crispy foods like fries, nuggets, samosas, and chicken wings. Use minimal to no oil.
- **Oven Baking:** Suitable for cakes, muffins, and small casseroles. Ensure bakeware fits within the basket.
- **Toasting:** For bread, bagels, or small pastries. Monitor closely to prevent burning.
- **Grilling:** For items like paneer tikka, vegetables, or small meat portions.

**Cook Crispy Food
with Less Oil**

UP TO
80%
LESS OIL



Image: The air fryer in operation, demonstrating its ability to cook crispy food with up to 80% less oil, showing fries and nuggets.

High Capacity Frying Basket

More Space. More Convenience.



The large frying basket lets you cook generous portions in one go, perfect for families or get-togethers, ensuring even air circulation for crisp, delicious results every time.

Image: A user lifting the lid to reveal the high-capacity frying basket, emphasizing ample space for cooking larger portions.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your air fryer. Always unplug the appliance and allow it to cool completely before cleaning.

Hassle-Free Care Effortless Upkeep

Designed for everyday convenience, the non-stick, detachable basket and smooth interior finish make cleaning quick and easy.



Image: A hand wiping the exterior of the Prestige Multi-Chef Air Fryer with a cloth, illustrating easy cleaning and upkeep.

Cleaning Steps:

1. **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners.
2. **Frying Basket:** The non-stick frying basket can be washed with warm, soapy water and a non-abrasive sponge. For stubborn food residues, soak the basket in warm water for 10-15 minutes before cleaning. Rinse and dry thoroughly.
Note: The frying basket is not dishwasher safe.
3. **Interior:** Wipe the interior of the appliance with a damp cloth. If necessary, use a mild detergent. Ensure no water enters the electrical components.
4. **Heating Element:** Gently clean the heating element with a soft brush to remove any food particles.
5. **Storage:** Store the clean and dry air fryer in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your Prestige Multi-Chef Air Fryer, please refer to the following table before contacting customer service.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Power outlet not working.	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance.
Food is not cooked evenly.	Basket is overfilled. Food not shaken/flipped.	Do not overfill the basket; cook in smaller batches. Shake or flip ingredients halfway through cooking.
Food is not crispy.	Too much moisture in food. Not enough oil (for certain foods). Temperature too low or time too short.	Pat food dry before cooking. Lightly brush or spray with oil. Increase temperature or cooking time.
White smoke coming from appliance.	Grease residue from previous use. High-fat food being cooked.	Clean the frying basket and interior thoroughly after each use. For high-fat foods, drain excess fat during cooking.
Appliance smells during first use.	Manufacturing residues burning off.	This is normal. Run the air fryer empty for 10-15 minutes at 180°C (350°F) before first use. Ensure good ventilation.

TECHNICAL SPECIFICATIONS

- **Model Name:** Multichef AIO Air Fryer 6.5 L
- **Model Number:** 41410
- **Capacity:** 6.5 Litres
- **Power:** 1200 Watts
- **Voltage:** 230 Volts, 50Hz
- **Temperature Range:** 100°C - 200°C
- **Control Method:** Touch Control
- **Product Dimensions (D x W x H):** 40 cm x 43 cm x 34 cm
- **Item Weight:** 6.2 Kilograms
- **Material:** Acrylonitrile Butadiene Styrene (Exterior), Non-stick coated metal (Inner)
- **Color:** Black
- **Included Components:** 1 x Multichef All-In-One Air Fryer
- **Country of Origin:** India

Dimension



Image: Diagram showing the dimensions of the Prestige Multi-Chef Air Fryer: 40 cm depth, 37.5 cm width, and 32 cm height. Please refer to the text specifications for precise measurements.

WARRANTY AND CUSTOMER SUPPORT

Your Prestige Multi-Chef All-in-One Air Fryer comes with a **1-Year Warranty** on the product.

For any feedback, comments, complaints, or service requests, please contact Prestige customer support:

- **Phone:** 080-6000 4411
- **Email:** customercare@tkprestige.com
- **Website:** shop.tkprestige.com/customer_service

To find a Prestige authorized service center, you can scan the QR code below:



Image: QR code for locating Prestige service centers. You can also visit <https://qr1.be/BMT7QY>.

