

[Manuals.plus](#) /

› [FUNMILY](#) /

› FUNMILY 2.5hp Under Desk Treadmill User Manual

FUNMILY B0DZHVQPQX

FUNMILY 2.5hp Under Desk Treadmill User Manual

Model: B0DZHVQPQX

1. INTRODUCTION

Thank you for choosing the FUNMILY 2.5hp Under Desk Treadmill. This portable and versatile treadmill is designed for home and office use, offering a convenient way to integrate walking or light jogging into your daily routine. With its powerful yet quiet motor, APP connectivity, remote control, and LED display, it provides an effective and enjoyable exercise experience. Please read this manual thoroughly before operation to ensure safe and proper use.



Image 1: The FUNMILY Under Desk Treadmill, highlighting its compact design and digital features.

2. SAFETY INFORMATION

To prevent injury or damage to the treadmill, please observe the following safety precautions:

- Always place the treadmill on a flat, stable surface.
- Ensure adequate clear space around the treadmill (at least 2 feet on all sides).
- Do not allow children or pets near the treadmill during operation.
- Wear appropriate athletic footwear.
- Do not operate the treadmill if it is damaged or malfunctioning.
- Unplug the treadmill from the power outlet when not in use or before cleaning/maintenance.
- The maximum weight capacity for this treadmill is 300 lbs. Do not exceed this limit.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- FUNMILY Under Desk Treadmill Unit
- Remote Control
- Power Cord
- Lubricant (for maintenance)
- User Manual (this document)

4. PRODUCT OVERVIEW

The FUNMILY treadmill is equipped with a powerful 2.5HP motor and a multi-layered running belt designed for comfort and durability.

Key Features:

- **APP & Bluetooth Enabled:** Connects to fitness apps for tracking and guided workouts.
- **Powerful & Quiet 2.5HP Motor:** Supports up to 300 lbs with minimal noise.
- **3-LED Display:** Shows real-time data including speed, distance, time, calories, and steps.
- **Remote Control:** Allows easy adjustment of settings during exercise.
- **Space-Saving Design:** Compact and portable with built-in transport wheels for easy storage.
- **3-in-1 Walking Pad:** Offers working (0.6-1.5mph), walking (0.6-2.5mph), and running (2.5-3.8mph) modes.



Image 2: Illustration of the powerful and quiet 2.5HP motor.



Image 3: Detail of the non-slip running belt with shock reduction design.

5. SETUP

Unpacking and Placement:

1. Carefully remove the treadmill from its packaging.
2. Place the treadmill on a firm, level surface. Ensure there is sufficient space around the unit for safe operation and movement.
3. Check that the power cord is not pinched or obstructed.

Initial Setup:

1. Plug the power cord into a grounded electrical outlet.
2. Locate the power switch, usually at the front or side of the treadmill, and turn it to the 'ON' position.

3. The LED display should illuminate, indicating the treadmill is ready for use.



Image 4: Demonstrating the ease of movement and storage for the treadmill.

6. OPERATING INSTRUCTIONS

Power On/Off:

- To turn on, flip the main power switch. The display will light up.
- To turn off, flip the main power switch back to the 'OFF' position.

Using the Remote Control:

The remote control allows you to start/stop the treadmill and adjust speed. Ensure the remote has working batteries.

- **Start/Stop Button:** Press to begin or end your workout.
- **Speed +/- Buttons:** Adjust the treadmill speed incrementally.

- **Mode Button:** Cycle through different exercise modes (if applicable).

APP Connectivity:

The treadmill supports APP connectivity via Bluetooth for enhanced tracking and interactive workouts.

1. Download the recommended fitness APP (e.g., FitShow) from your device's app store.
2. Ensure Bluetooth is enabled on your smartphone or tablet.
3. Open the APP and follow the on-screen instructions to pair with your FUNMILY treadmill.
4. Once connected, you can track your workout data, access training plans, and control the treadmill via the APP.

Exercise Modes:

The treadmill offers three primary modes based on speed:

- **Working Mode:** 0.6 - 1.5 mph (ideal for light activity while working)
- **Walking Mode:** 0.6 - 2.5 mph (suitable for brisk walking)
- **Running Mode:** 2.5 - 3.8 mph (for light jogging)

SMART TREADMILL WITH HD LED DISPLAY



Image 5: The smart LED display and remote/APP control features.



HOME EXERCISE EQUIPMENT

Speed Range: **0.5-3.8MPH**

Image 6: Various home exercise applications of the treadmill.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

Cleaning:

- Wipe down the treadmill with a damp cloth after each use to remove sweat and dust.
- Do not use abrasive cleaners or solvents.
- Keep the area around the treadmill clean and free of debris.

Lubrication:

The running belt requires periodic lubrication to reduce friction and extend its lifespan. Use the provided lubricant.

1. Unplug the treadmill.

2. Carefully lift the edge of the running belt.
3. Apply a small amount of lubricant evenly under the belt, about 1-2 inches from the edge.
4. Plug in the treadmill and run it at a low speed (e.g., 1 mph) for 5 minutes to distribute the lubricant.
5. Lubricate every 3-6 months depending on usage.

Storage:

When not in use, the treadmill can be easily moved and stored upright against a wall or under furniture thanks to its built-in wheels.

8. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Treadmill does not power on.	Power cord not plugged in; Power switch off; Circuit breaker tripped.	Ensure power cord is securely plugged in; Turn power switch to 'ON'; Check household circuit breaker.
Running belt slips or hesitates.	Belt needs lubrication; Belt tension is too loose.	Lubricate the running belt (refer to Maintenance section); Adjust belt tension (consult customer support if unsure).
Remote control not responding.	Batteries are dead; Remote not paired.	Replace batteries in the remote; Re-pair the remote with the treadmill (refer to APP/Remote instructions or contact support).
Unusual noise during operation.	Loose parts; Belt misalignment; Motor issue.	Check for loose screws and tighten; Adjust belt alignment (consult customer support); If noise persists, contact customer support.

9. SPECIFICATIONS

Detailed technical specifications for your FUNMILY treadmill:

Feature	Specification
Brand	FUNMILY
Model Name	B0DZHVQPQX
Color	Fashion black
Product Dimensions (LxWxH)	50"D x 24"W x 5.5"H
Material	Alloy Steel
Maximum Horsepower	2.5 HP
Speed Range	0.6 - 3.8 MPH

Feature	Specification
Maximum Weight Recommendation	300 Pounds
Special Features	APP Connection, Bluetooth Remote Control, LED Display, Quiet Motor

10. WARRANTY AND SUPPORT

Warranty Information:

This FUNMILY treadmill comes with a**1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

Customer Support:

If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact FUNMILY customer support. Have your product model number (B0DZHVQPQX) and purchase date ready when contacting support.

For the most up-to-date contact information, please refer to the official FUNMILY website or your purchase documentation.

© 2025 FUNMILY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question