Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Phomemo /
- > Phomemo M833 Bluetooth Thermal Printer User Manual

Phomemo M833

Phomemo M833 Bluetooth Thermal Printer User Manual

Model: M833

1. Introduction

This manual provides comprehensive instructions for the Phomemo M833 Bluetooth Thermal Printer. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before using the printer.

2. PRODUCT OVERVIEW

The Phomemo M833 is a portable, inkless thermal printer designed for convenience and high-quality document printing. It supports various thermal paper sizes, including US Letter (8.5" x 11"), A4 (8.27" x 11.69"), and smaller widths (2", 3", 4").



Figure 2.1: Phomemo M833 Thermal Printer with its protective carrying case.

Key Features:

- Inkless Thermal Printing: Eliminates the need for ink cartridges or toner.
- High Resolution: 300dpi for clear and sharp prints.
- Multi-size Paper Support: Compatible with US Letter, A4, and various roll paper widths.
- Portable Design: Lightweight (750g) with a built-in 2600mAh battery for on-the-go printing.
- Wireless Connectivity: Bluetooth connection for mobile devices (Phone, iPad).
- Wired Connectivity: USB connection for laptops and computers.
- Versatile Document Support: Prints PDF, Word, Excel, JPG, Web pages, and TXT files.



Figure 2.2: The M833 printer's capabilities, including 300dpi resolution, 2600mAh battery, and supported file formats like Word, Excel, TXT, JPG, and PDF.

Package Contents:

- Phomemo M833 Thermal Printer
- Protective Carrying Case
- USB-C Charging Cable
- Thermal Paper Roll (sample)
- · Quick Start Guide



Figure 2.3: Contents of the Phomemo M833 printer package, showing the printer, paper rolls, and charging cable.

3. SETUP

3.1 Charging the Printer

Before initial use, fully charge the printer. Connect the supplied USB-C cable to the printer's charging port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The indicator light will show charging status.

Your browser does not support the video tag.

Video 3.1: Demonstrates how to charge the Phomemo M833 printer and turn it on. This video also shows how to install roll paper.

3.2 Installing Thermal Paper

The M833 printer supports both thermal paper rolls and folded thermal paper sheets. Ensure you use thermal paper as the printer does not use ink.

3.2.1 Installing Roll Paper

- 1. Press the two release buttons on either side of the printer simultaneously to open the top cover.
- 2. Remove any existing paper roll or protective paper.
- 3. Unwrap a new thermal paper roll and ensure the printing side (usually smoother) is facing the print

head.

- 4. Place the paper roll into the designated slot.
- 5. Pull a small section of paper out, ensuring it is straight and aligned with the paper exit slot.
- 6. Close the top cover until it clicks securely into place.



Figure 3.1: The Phomemo M833 printer actively printing a document, illustrating the paper feeding mechanism.

3.2.2 Installing Folded Thermal Paper Sheets

- 1. Ensure the printer is powered on.
- 2. Locate the paper inlet slot at the back of the printer.
- 3. Insert a single sheet of folded thermal paper into the inlet, printing side facing up. The printer will automatically feed the paper into position.
- 4. Ensure the paper is inserted straight to prevent jams or skewed prints.

3.3 Connecting to the Phomemo App (Bluetooth)

For mobile printing, download the "Phomemo" app from your device's app store (Google Play for Android, App Store for iOS).

1. Ensure your printer is charged and powered on (green indicator light).

- 2. Enable Bluetooth on your mobile device.
- 3. Open the Phomemo app. The app will automatically search for nearby printers.
- 4. Select "M833" from the list of available devices to connect.
- 5. Once connected, the app will prompt you to select the paper type (e.g., Large roll paper, Small roll paper, Single sheet paper). Choose the appropriate option.



Figure 3.2: The Phomemo M833 printer connected to a smartphone, displaying the Phomemo app interface with various print options.

3.4 Connecting to a Computer (USB)

For printing from a laptop or desktop computer, connect the printer using the supplied USB-C cable.

- 1. Connect one end of the USB-C cable to the printer's USB port.
- 2. Connect the other end to an available USB port on your computer.
- 3. The computer should automatically detect the printer. If not, you may need to install the printer driver, which can typically be found on the Phomemo official website.
- 4. Once the driver is installed, the printer will appear in your computer's list of printers, ready for use.

4. OPERATING INSTRUCTIONS

4.1 Printing from Mobile Device (Phomemo App)

- 1. Ensure the printer is connected to the Phomemo app via Bluetooth.
- 2. From the app's main interface, select your desired printing function (e.g., "Print Documents," "Print Images," "Print Web").
- 3. Browse and select the file or image you wish to print.
- 4. Adjust print settings such as copies, thickness (light, medium, heavy), and paper size within the app's print preview screen.
- 5. Tap the "Print" button to initiate printing.

Your browser does not support the video tag.

Video 4.1: A short demonstration of the Phomemo M833 printer's compact size and ease of use for business and homeschooling applications.

4.2 Printing from Computer

- 1. Ensure the printer is connected to your computer via USB and the necessary drivers are installed.
- 2. Open the document or image you wish to print on your computer.
- 3. Go to "File" > "Print" (or use the shortcut Ctrl+P/Cmd+P).
- 4. Select "Phomemo M833" as your printer.
- 5. Adjust print preferences (e.g., paper size, orientation, print quality) in the printer settings dialog.
- 6. Click "Print" to send the job to the printer.



Figure 4.1: A visual comparison demonstrating the superior print clarity of the M833 at 300DPI compared to a 203DPI printer.

5. MAINTENANCE

5.1 Cleaning the Print Head

To maintain print quality, regularly clean the print head. Use a soft, lint-free cloth lightly dampened with isopropyl alcohol. Gently wipe the print head surface. Ensure the printer is off and completely dry before use.

5.2 Replacing Paper

Follow the instructions in Section 3.2 for installing new thermal paper rolls or sheets when the current supply runs out.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Printer not turning on	Low battery or power issue.	Charge the printer using the supplied USB-C cable. Ensure the power button is pressed and held for 3 seconds.

Problem	Possible Cause	Solution
Poor print quality (faint/streaky)	Incorrect paper type, dirty print head, or low battery.	Ensure you are using thermal paper. Clean the print head (Section 5.1). Charge the printer. Adjust print density in the app/driver settings.
Paper jam	Improper paper loading or foreign object.	Open the top cover and carefully remove the jammed paper. Reload paper correctly (Section 3.2).
Cannot connect via Bluetooth	Bluetooth off, printer not discoverable, or app issue.	Ensure printer is on and Bluetooth is enabled on your device. Restart the app and try connecting again. Forget the device in Bluetooth settings and re-pair.
Cannot print from computer	Driver not installed, incorrect USB connection.	Ensure USB cable is securely connected. Install the correct printer driver from the Phomemo website. Restart computer and printer.

7. SPECIFICATIONS

Feature	Detail
Model	M833
Printing Technology	Thermal
Resolution	300dpi
Connectivity	Bluetooth, USB-C
Battery Capacity	2600mAh
Supported Paper Sizes	US Letter (8.5" x 11"), A4 (8.27" x 11.69"), 2", 3", 4" width thermal paper
Supported Paper Types	Thermal standard paper sheets, roll paper, folded thermal paper
Weight	Approx. 750g
Compatible Devices	Phone (iOS/Android), iPad, Laptop/PC

8. WARRANTY AND SUPPORT

Phomemo products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the official Phomemo website or contact their customer service directly. Keep your purchase receipt for warranty claims.

For further assistance, visit the Phomemo Store on Amazon.

Related Documents - M833








Phomemo P831 Portable Printer User Guide

Comprehensive user guide for the Phomemo P831 portable printer, covering package contents, printer components, button functions, indicator lights, precautions, app installation, paper usage, cleaning, and warranty information.

Capparell a été évalué pour répondre aux exigences générales d'exposition aux 87. L'appareil peut être stéléé-dans des conditions d'exposition portable asses restriction.	
The country Carlo The country C	
The former is a second of the control of the contro	Phomemo M832 A4 Portable Thermal Printer User Guide and Tips Information and usage tips for the Phomemo M832 A4 Portable Thermal Printer by Zoolion, including setup instructions and troubleshooting advice.
ASSIM/ASSIM/255M Treader Sections 1 - Control Land 1 - Control 1	Phomemo A281M/A282M/A285M Troubleshooting Guide A comprehensive troubleshooting guide for Phomemo A281M, A282M, and A285M thermal printers, covering product information, usage, common machine and connection issues, printing problems, and app-related questions.
	Phomemo M08F Portable Printer Quick Start Guide
	A quick start guide for the Phomemo M08F portable thermal printer, covering setup, operation, app







1	4.Low power	Arjust the print density to the highest
	5. Paper oil has been last to ser for a long time	Compaper rat, being is modifie or it all for a long time may make missing printing. Unused paper rats are pecked in sested togs or boson.
Distinctions in different from edit fact	I. When printing the same contact with different models printed, the forts are different.	Overte different phone-models and versions, the princed force will be different suitche phone options force as the default fact.
		Thermo-sonaltine paper correct be pealed with give
	er on Improper ser and presentation	Effords records before printing, and by he would using oil Conscipence or gall person the printing paper wher printing
hodbron		Antivert temperature, humidity, or sicahol, distribution, seem or year hands, or hand san blow will after the locking of words
below off.		Please choses to avoid light and stars the printing paper in a day environment.
		After printing, the printed controvation of the in- contact with a notine printed surface or transparent long for storage.
		First need to 50 A. the printing paper, places adopt the official paper with advante backing, Some allies so Equal advantes will accompany the facing.
ı		