

[manuals.plus](#) /› [Timex](#) /› [Timex TW14 Alarm Clock with Wireless Charger User Manual](#)**Timex TW14**

Timex TW14 Alarm Clock with Wireless Charger User Manual

Model: TW14

Overview	Setup	Operation	Introduction	Package Contents	Product Specifications	Warranty & Support
--------------------------	-----------------------	---------------------------	------------------------------	----------------------------------	--	--

1. INTRODUCTION

Thank you for purchasing the Timex TW14 Alarm Clock with Wireless Charger. This compact device combines a digital alarm clock with a convenient 15W wireless charging pad, suitable for various smartphones and earbuds. This manual provides essential information for setting up, operating, and maintaining your new alarm clock.

2. PACKAGE CONTENTS

Please ensure all items are present in the package:

- Timex TW14 Alarm Clock with Wireless Charger
- USB-A to USB-C Power Cable
- User Manual (this document)

Note: A 18W QC3.0 adapter and 2 AAA batteries for backup are **not included** and must be purchased separately.

3. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Timex TW14 alarm clock.

Rest Easy!



Battery Backup

Maintain Clock & Alarm Settings in Case of Power Failure



USB Power Cable Included



Image 3.1: Top view of the Timex TW14 alarm clock, highlighting the control buttons and the wireless charging pad. The display shows "10:09". A USB power cable is also shown.

Front Panel:

- **LED Display:** Shows time, alarm status, and PM indicator.

Top Panel:

- **Wireless Charging Pad:** For charging compatible devices.
- **"M" Button:** Mode/Set button for time and alarm settings, also functions as snooze.
- **"-" Button:** Decrease value, navigate backward, also functions as snooze.
- **"+" Button:** Increase value, navigate forward, also functions as snooze.

Rear Panel:

- **USB-C Power Input:** Connects to the power cable.

Bottom Panel:

- **Battery Compartment:** For 2 AAA backup batteries.

4. SETUP

4.1 Power Connection

1. Connect the supplied USB-A to USB-C power cable to the USB-C input port on the rear of the alarm clock.
2. Connect the USB-A end of the cable to a compatible 18W QC3.0 USB power adapter (not included).
3. Plug the power adapter into a standard wall outlet. The clock display will illuminate.

4.2 Battery Backup Installation

The battery backup system maintains time and alarm settings during a temporary power outage. It does not power the clock display or wireless charging function.

1. Locate the battery compartment on the bottom of the unit.
2. Open the battery compartment cover.
3. Insert 2 new AAA batteries (not included), observing the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

5. OPERATING INSTRUCTIONS

5.1 Setting the Time

1. Press and hold the **M** button until the hour digits begin to flash.
2. Use the **-** or **+** buttons to adjust the hour. Pay attention to the PM indicator if using 12-hour format.
3. Press the **M** button again to confirm the hour, and the minute digits will flash.
4. Use the **-** or **+** buttons to adjust the minutes.
5. Press the **M** button once more to confirm the minutes and exit time setting mode.

5.2 Setting the Alarm

1. Press the **M** button once (do not hold) to enter alarm setting mode. The alarm time will be displayed, and the alarm icon will flash.
2. Press and hold the **M** button until the alarm hour digits begin to flash.
3. Use the **-** or **+** buttons to adjust the alarm hour.
4. Press the **M** button again to confirm the alarm hour, and the alarm minute digits will flash.
5. Use the **-** or **+** buttons to adjust the alarm minutes.
6. Press the **M** button once more to confirm the alarm minutes and exit alarm setting mode. The alarm icon will remain lit, indicating the alarm is active.
7. To turn the alarm ON/OFF, press the **M** button briefly when the current time is displayed. The alarm icon will appear or disappear.

5.3 Snooze Function

When the alarm sounds, press any of the **M**, **-**, or **+** buttons to activate the snooze function. The alarm will temporarily stop and sound again after approximately 9 minutes.

To turn off the alarm completely, allow the alarm to ring for its full duration or turn off the alarm via the **M** button when not ringing.

5.4 Display Dimmer

To adjust the brightness of the LED display, repeatedly press the **M** button (when not in setting mode) to cycle through High, Low, and Off brightness levels.

5.5 Wireless Charging

The Timex TW14 features a 15W wireless charging pad compatible with Qi-enabled devices such as iPhone, Android smartphones, and AirPods.



Image 5.1: An iPhone placed on the wireless charging pad of the Timex TW14 alarm clock, indicating active charging.



Image 5.2: AirPods case placed on the wireless charging pad of the Timex TW14 alarm clock, indicating active charging.

1. Place your Qi-enabled device (e.g., smartphone, AirPods case) directly onto the center of the wireless charging pad on the top of the alarm clock.
2. Ensure the device is properly aligned with the charging coil. A charging indicator (if available on your device) will confirm charging has begun.
3. If charging does not start, slightly reposition your device on the pad.

Important Considerations:

- For optimal charging performance, use an 18W QC3.0 power adapter.
- Thick phone cases or cases containing metal may interfere with wireless charging. Remove such cases if charging issues occur.
- Charging speed may vary depending on the device, its battery level, and environmental factors.

6. MAINTENANCE

6.1 Cleaning

To clean the unit, gently wipe the surfaces with a soft, dry cloth. Do not use liquid cleaners, abrasive

materials, or chemical sprays, as these may damage the finish or internal components.

6.2 Battery Replacement

Replace the 2 AAA backup batteries annually or if you notice settings are not retained during power outages. Always use new batteries and dispose of old batteries responsibly.

7. TROUBLESHOOTING

If you experience issues with your Timex TW14 alarm clock, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clock display is off or not working.	No power, loose connection, or display dimmer set to "Off".	Ensure the USB-C power cable is securely connected to the clock and a functional power adapter. Check if the adapter is plugged into a live outlet. Press the M button to cycle through display brightness settings (High/Low/Off).
Wireless charging is not working.	Device not Qi-compatible, improper alignment, phone case interference, insufficient power adapter.	Verify your device supports Qi wireless charging. Reposition the device on the center of the charging pad. Remove thick or metallic phone cases. Ensure you are using an 18W QC3.0 power adapter.
Wireless charging is slow.	Power adapter not powerful enough, device alignment, background apps on device.	Use an 18W QC3.0 power adapter for optimal speed. Ensure perfect alignment of the device on the charging pad. Close unnecessary apps on your device.
Alarm settings are lost after power outage.	Backup batteries are dead or not installed.	Install 2 new AAA batteries in the battery compartment, ensuring correct polarity. Replace old batteries if necessary.
Difficulty setting time/alarm.	Incorrect button press sequence.	Refer to sections 5.1 and 5.2 for detailed instructions on setting the time and alarm. Ensure you press and hold the M button at the correct steps.

8. SPECIFICATIONS

Brand	Timex
Model Number	TW14
Color	Black
Display Type	Digital LED (0.8" white)
Special Features	Alarm, 15W Wireless Charging, Display Dimmer, Battery Backup

Product Dimensions	5" (Width) x 5" (Depth) x 1.2" (Height)
Power Source	USB-A to USB-C power cable (included), requires 18W QC3.0 adapter (not included)
Battery Backup	2 x AAA batteries (not included)
Frame Material	Plastic
Item Weight	0.2 Kilograms (7 ounces)



Image 8.1: Timex TW14 alarm clock with its dimensions (5"W x 5"D x 1.2"H) clearly indicated.

9. WARRANTY AND SUPPORT

Timex products are manufactured to high quality standards. For information regarding warranty coverage, technical support, or customer service, please refer to the warranty card included with your purchase or visit the official Timex website. Please retain your proof of purchase for warranty claims.

© 2024 Timex. All rights reserved. Model TW14.