

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Longer](#) /

› [LONGER Ruby Pulsed Infrared Laser Module User Manual for RAY5 Series](#)

## Longer RAY5 Ruby

# LONGER Ruby Pulsed Infrared Laser Module User Manual

For LONGER RAY5 5W/10W and RAY5 20W (3-pin) Laser Engravers

## 1. PRODUCT OVERVIEW

The LONGER Ruby Ultimate Pulsed Infrared Laser Module is an advanced accessory designed to enhance the capabilities of your LONGER RAY5 5W/10W or RAY5 20W (3-pin) laser engraver. This module utilizes pulsed infrared laser technology to achieve high-precision engraving and cutting on a diverse range of materials, including various metals, plastics, leather, and ceramics. Its ultrafine laser spot size of 0.03x0.03mm allows for intricate detailing and clean cuts.



Figure 1: LONGER Ruby Pulsed Infrared Laser Module

## 2. PACKAGE CONTENTS

---

Verify that all components are present and in good condition upon unpacking. The standard package for the LONGER Ruby module typically includes:

- LONGER Ruby Laser Module
- Power Adapter
- Mounting Plate
- Limit Switches (2)
- Mounting Hardware (screws, nuts)
- Wrench
- Hex Keys (various sizes)
- Connection Cable



Figure 2: Included accessories for the laser module.

### 3. SETUP AND INSTALLATION

This section outlines the general steps for installing the LONGER Ruby Laser Module onto a compatible LONGER RAY5 series engraver. Refer to your specific engraver's manual for detailed frame assembly instructions.

- 1. Power Off:** Ensure your laser engraver is powered off and unplugged from the power source before beginning installation.
- 2. Remove Existing Module (if applicable):** Carefully detach any previously installed laser module from the engraver's gantry. Disconnect all cables.
- 3. Mount the Ruby Module:** Attach the LONGER Ruby module to the gantry using the provided mounting plate and hardware. Ensure it is securely fastened and aligned correctly.
- 4. Connect Cables:** Connect the power and signal cables from the Ruby module to the corresponding ports on your engraver's control board. Ensure correct pin orientation if applicable.
- 5. Install Limit Switches:** If upgrading or replacing, install the new limit switches as per your engraver's instructions.
- 6. Power On and Test:** Once installation is complete, power on your engraver. Perform a basic movement test to ensure the module moves freely along the X and Y axes.

### 3.1. Focusing the Laser

Accurate focusing is crucial for optimal engraving and cutting performance. The LONGER Ruby module features an ultrafine laser spot for precision.

- Place a piece of scrap material on the working surface.
- Adjust the module's height until the laser spot is at its smallest and most intense point on the material surface.
- Some models may include a focusing tool or a fixed focal length. Refer to your specific model's quick start guide for precise focusing methods.



Figure 3: The 0.03mm compression laser spot for high-resolution effects.

## 4. OPERATING INSTRUCTIONS

The LONGER Ruby module is compatible with various laser control software. This section provides general operating guidelines.

### 4.1. Material Compatibility

The Ruby module offers exceptional versatility across a wide range of materials:

- **Metals:** Iron, copper, aluminum, magnesium, zinc, gold, silver, titanium, metal oxides, electroplated surfaces.
- **Non-Metals:** ABS, inks, epoxy resins, leather, ceramics, stone.




Figure 4: Versatility of engraving materials with the LONGER Ruby module.

## 4.2. Software and Settings

Use LightBurn or other compatible laser control software to prepare your designs and control the engraver. Proper settings are crucial for desired results.

- **Power:** Adjust laser power based on material type and desired depth of engraving/cut.
- **Speed:** Control the movement speed of the laser head. Slower speeds generally result in deeper cuts or darker engravings.
- **Passes:** For thicker materials, multiple passes at lower power/higher speed may be more effective than a single high-power pass.
- **Air Assist:** Utilize air assist for cleaner cuts and to prevent material charring, especially with certain non-metals.

## 4.3. Example Operations

#### 4.3.1. Laser Module Cutting Performance

Your browser does not support the video tag.

Video 1: Demonstrates the cutting capabilities of a laser module, showing various power settings and their effect on material thickness.

#### 4.3.2. Infrared Laser Module Metal Engraving

Your browser does not support the video tag.

Video 2: Shows the process of DIY metal engraving using an infrared laser module, highlighting its precision on metallic surfaces.

### 4.4. Using the LightBurn Camera Kit (Optional)

For enhanced precision and workflow, the LONGER Ruby module can be integrated with a LightBurn Camera Kit. This allows for accurate material placement and visual alignment of designs.

1. **Install Camera Bracket:** Open the camera bracket into a cross shape and secure it to the bottom mounting bracket using the hand-tightening set screws.
2. **Attach Camera Module:** Attach the camera module to the camera bracket.
3. **Mount to Engraver:** Attach the bottom mounting bracket to the frame of your RAY5 or B1 engraver.
4. **Adjust Camera Height:** Ensure the distance between the working plane and the camera lens is approximately 450mm.
5. **LightBurn Setup:** Open LightBurn settings, switch the camera capture system to the default capture system, and select full-color for the camera view.
6. **Calibrate Camera Lens:** Use the 'Calibrate Camera Lens' function in LightBurn. Place the dot cards in five positions (left, right, top, bottom, and middle) to capture 5 times. Ensure the captured result scores  $\geq 1$ .
7. **Align Camera:** Click 'Camera Control' -> 'Camera Alignment' -> 'Camera' -> Next. Click the intersection position in the order of numbers 1-4, zooming in to the maximum and double-clicking the intersection point. If there's an obvious offset, reselect.
8. **Material Placement:** Place your material (e.g., basswood flat) in the working area.
9. **Set Engraving Parameters:** Adjust engraving parameters (speed, power, passes) and set the scale value according to the actual positioning size.
10. **Frame and Start:** Before clicking 'Frame', select 'Current Position' as the 'Start Form'. The lower left corner point is used as the 'Job Origin'. Patrol to see if there is a collision. Click 'Start' to make a positioning mark, then capture the image.

#### 4.4.1. LightBurn Camera Kit Setup and Operation

Your browser does not support the video tag.

Video 3: A detailed guide on setting up and using the LightBurn Camera Kit for precise laser engraving, including calibration steps.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your LONGER Ruby Laser Module.

- **Clean the Lens:** Periodically clean the laser lens with a soft, lint-free cloth and lens cleaning solution to remove dust and debris that can affect laser performance.
- **Check Connections:** Ensure all electrical connections are secure and free from damage.
- **Inspect Cooling Fan:** Keep the cooling fan free of dust and obstructions to prevent overheating.
- **Gantry and Rails:** Keep the engraver's gantry and linear rails clean and lubricated according to your engraver's manual.

## 6. TROUBLESHOOTING

This section addresses common issues you might encounter with your laser module.

### 6.1. Laser Not Firing or Weak Output

- **Check Connections:** Verify all cables are securely connected to both the module and the control board.
- **Power Supply:** Ensure the power adapter is correctly plugged in and providing adequate power.
- **Software Settings:** Confirm that laser power and speed settings in your software are appropriate for the material.
- **Lens Cleanliness:** A dirty lens can significantly reduce laser output. Clean the lens as described in the Maintenance section.
- **Focus:** Incorrect focus will result in weak or no engraving. Re-focus the laser.

### 6.2. Unexpected Laser Firing or Safety Shutdowns

The LONGER RAY5 series engravers are equipped with thermal protection features to prevent accidents.

- **Thermal Protection Triggered:** If the machine detects excessive heat or an uncontrolled laser emission, it may trigger a flame protection shutdown. This will typically display a warning on the screen and require a machine restart.
- **Restart Procedure:** If a safety shutdown occurs, power off the machine, wait a few moments, and then power it back on. Investigate the cause of the shutdown (e.g., material catching fire, sensor obstruction).

#### 6.2.1. LONGER RAY5 Thermal Protection Test

Your browser does not support the video tag.

Video 4: Demonstrates the thermal protection feature of the LONGER RAY5, showing how the machine alerts and stops operation when an issue like material ignition is detected.

## 7. SPECIFICATIONS

Feature	Detail
Product Dimensions	1 x 1 x 1 inches
Item Weight	3.12 pounds
Manufacturer	Longer
Item Model Number	Laser Engraver Module
Batteries Required	No

## 8. WARRANTY INFORMATION

The LONGER Ruby Ultimate Pulsed Infrared Laser Module comes with a **One Year Warranty**. For warranty claims or detailed terms and conditions, please contact LONGER customer support.

## 9. CUSTOMER SUPPORT

For technical assistance, troubleshooting, or any inquiries regarding your LONGER Ruby Laser Module, please utilize the following support channels:

- **Email Support:** Reach out via email for detailed inquiries.

- **Live Chat:** Available for immediate assistance.
- **Phone Support:** Contact our technical service team directly.
- **Facebook Group:** Join the official LONGER community for peer support and updates.

Our technical service team aims to provide a 24-hour reply to ensure your issues are resolved promptly.

© 2026 Longer. All rights reserved. Visit [www.longer3d.com](http://www.longer3d.com) for more information.