

Wallfire 3L Air Fryer

Wallfire 3L Electric Air Fryer User Manual

Model: 3L Air Fryer

INTRODUCTION

Thank you for purchasing the Wallfire 3L Electric Air Fryer. This appliance utilizes 360° high-speed air circulation technology to cook food with little to no oil, providing a healthier alternative to traditional frying. Its compact design and versatile functions make it suitable for individuals or small families (1-2 people).

Please read this manual thoroughly before use to ensure safe and optimal operation. Keep this manual for future reference.

SAFETY INFORMATION

Your safety is paramount. Please observe the following precautions:

- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the main unit in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not block the air inlet or outlet vents during operation.
- Unplug the appliance when not in use and before cleaning.
- Do not operate the appliance if the power cord or plug is damaged.
- This product is PSE certified, meeting strict Japanese safety standards for electrical appliances.



Image: PSE Certification Mark. This mark indicates the product complies with Japanese electrical appliance safety standards.

PRODUCT COMPONENTS

The Wallfire 3L Electric Air Fryer includes the main unit, a removable basket, and a cooking rack. Refer to the diagram below for a visual representation of the components.



Image: The Wallfire 3L Electric Air Fryer, showing the main unit with its basket and control panel.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and check for any damage.
2. **Initial Cleaning:** Before first use, clean the basket and cooking rack with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a flat, stable, and heat-resistant surface, away from walls and other appliances to allow for proper air circulation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

The air fryer features an intuitive touch panel for easy operation.



Image: Close-up of the air fryer's touch panel, displaying various cooking menu options.

Basic Operation:

1. **Preparation:** Place food in the air fryer basket. For best results, do not overcrowd the basket.
2. **Power On:** Press the power button on the touch panel.
3. **Select Menu:** Choose from 8 preset cooking menus or manually set the temperature and time.
4. **Temperature Adjustment:** Use the temperature controls to set the desired cooking temperature (80-200°C).
5. **Timer Setting:** Use the timer controls to set the cooking duration (1-12 hours for reservation, up to 60 minutes for cooking).
6. **Start Cooking:** Press the start button to begin the cooking process.
7. **Visible Window:** Monitor cooking progress through the visible window without opening the basket.
8. **Pause Function:** The appliance features a "pause memory" function. If you pull out the basket during cooking, the operation will pause and resume automatically once the basket is reinserted.
9. **Reservation Function:** You can set a delayed start time for up to 24 hours, allowing you to prepare meals in advance.

Preset Menus:

The air fryer offers 8 convenient preset menus for common dishes. These settings are a guideline and may need adjustment based on food quantity and desired crispiness.



Image: Icons illustrating the multi-functional capabilities of the air fryer, including frying, baking, and more.

Examples of preset menus include: Dried Fruits, French Fries, Egg Tart, Steak, Grilled Fish, Chicken Thighs, Chicken Wings, Sweet Potatoes.

 <p>ドライフルーツ 80min 100℃</p>	 <p>フライドポテト 16min 180℃</p>	 <p>エッグタルト 18min 180℃</p>	 <p>ステーキ 20min 180℃</p>
 <p>焼き魚 20min 190℃</p>	 <p>鶏もも肉 24min 200℃</p>	 <p>鶏の羽 26min 200℃</p>	 <p>さつまいも 50min 200℃</p>

8つメニューの設定があるので、
初心者にもやさしい。
15分時間予約機能搭載！いつでも美味しい料理！

Image: A visual guide showing various food items with recommended cooking times and temperatures using the air fryer's preset menus.

COOKING GUIDE & BENEFITS

The Wallfire Air Fryer allows you to enjoy your favorite fried foods with significantly less oil, reducing fat intake by up to 95% and calories. This is achieved through 360° high-speed hot air circulation, which cooks food evenly and creates a crispy exterior while keeping the inside juicy.

油分最大95%カット！

360° 高速空気循環&NTCインテリ温度制御で、ヘルシー調理を実現。



Image: Illustration of the air fryer cooking chicken wings, highlighting a 95% reduction in oil usage.

Example Cooking Times (Approximate):

- **French Fries:** 16 minutes at 180°C
- **Steak:** 20 minutes at 180°C
- **Chicken Wings:** 26 minutes at 200°C
- **Sweet Potatoes:** 50 minutes at 200°C
- **Dried Fruits:** 80 minutes at 100°C

For detailed recipes and cooking tips, refer to the included recipe book.



Image: A Japanese recipe book provided with the air fryer, offering various cooking ideas.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your air fryer. The non-stick coating makes cleaning easy.

お手入れも簡単

ノンスティック加工



布で拭く



食洗機もOK



Image: A composite image demonstrating the easy cleaning process of the air fryer basket, including rinsing under water and being placed in a dishwasher.

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Basket and Rack:** The cooking basket and rack are dishwasher safe. Alternatively, wash them with warm water and a mild detergent. Use a non-abrasive sponge to protect the non-stick coating.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
4. **Storage:** Ensure all parts are dry before storing the appliance in a cool, dry place. Its compact size allows for easy storage without taking up much space.

コンパクトなので収納
スペースを取らない



本体*1

説明書*1

レシピです*1

製品仕様

製品寸法：L26xW26xH32cm

容量：3L

重量：約2.6kg

温度調整範囲：80-200℃

タイマー範囲：1-12H

定格電圧：100V,50/60HZ

定格出力：1000W

Image: The compact air fryer unit shown fitting neatly into a kitchen cabinet, illustrating its space-saving design.

TROUBLESHOOTING

If you encounter any issues with your Wallfire Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the power cord is securely plugged in. Test the outlet with another appliance. Press the power button firmly.
Food is not cooked evenly.	Basket overcrowded; food not shaken/flipped during cooking.	Do not overcrowd the basket. Shake or flip food halfway through cooking for even results.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food.	Clean the basket and heating element thoroughly. For high-fat foods, drain excess fat during cooking.
Food is not crispy.	Insufficient cooking time/temperature; too much moisture in food.	Increase cooking time or temperature. Pat food dry before cooking. A light spray of oil can help.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Product Dimensions	31.2 x 26.3 x 26.1 cm (L x W x H)
Capacity	3 Liters
Weight	Approx. 2.93 kg
Color	Earth Black
Temperature Range	80-200°C
Timer Range	1-12 hours (Reservation), up to 60 minutes (Cooking)
Rated Voltage	100V, 50/60Hz
Rated Power Output	1000W
Control Method	Touch Panel
Air Frying Technology	Cyclone

