

APUZOM M5

APUZOM Kids Alarm Clock with Sound Machine (Model M5) - Instruction Manual

Model: M5

1. PRODUCT OVERVIEW

The APUZOM Kids Alarm Clock with Sound Machine, Model M5, is designed to assist children in developing healthy sleep habits. It integrates a sleep training system, sound machine, night light, and alarm clock functions into a single device. Key features include visual cues for wake-up and bedtime, a selection of soothing sounds, adjustable night light colors and brightness, and a digital time display.



Image 1: Front view of the APUZOM Kids Alarm Clock, displaying time and various icons, with a colorful ambient light.

2. PACKAGE CONTENTS

- APUZOM Kids Alarm Clock (Model M5)
- USB Power Cable
- Power Adapter
- Instruction Manual

3. SETUP

3.1 Power Connection

The alarm clock is powered via a USB cable and power adapter. Connect the USB cable to the clock's port and plug the adapter into a standard electrical outlet. A built-in CR5 button battery (included) serves as a backup to preserve clock settings during power outages, but the clock requires continuous power to operate its full functions.



Image 2: The alarm clock connected to a wall outlet via its USB power cable.

3.2 Initial Time Setting

Upon first power-up or after a prolonged power disconnection without battery backup, the time may need to be set. Refer to the "Operating" section for detailed instructions on setting the time and other features.

4. OPERATING INSTRUCTIONS

The APUZOM Kids Alarm Clock features several buttons on its rear for configuration and control. Familiarize yourself with these controls for optimal use.

12 Soothing Sounds for Sleep

Help your kiddo wind down peacefully



Image 3: The alarm clock displaying time and nightlight settings, illustrating dimmable display and nightlight options.

4.1 Sleep Training Function

This feature uses color and icon cues to indicate wake-up and bedtime.

- **Wake-Up Time:** The sun icon flashes, and the clock glows **GREEN** for one hour, signaling it is time to wake up.
- **Bedtime:** The moon icon appears, and the clock illuminates **RED**, indicating it is time for bed.



Image 4: Illustration of the sleep training feature, showing a green light and sun icon for wake-up, and a red light and moon icon for bedtime.

4.2 Sound Machine

The clock offers 12 calming sounds to aid sleep, with 10 adjustable volume levels. Sounds include waves, rain, crickets, waterflow, frogs, birds, and lullabies. An integrated timer allows automatic sound and light shut-off after 15, 30, 60, or 90 minutes.

Dimmable Display & Nightlight

Eliminate light disturb during sleep



Image 5: The alarm clock displaying time with a moon icon, indicating sleep mode, and showing options for 12 soothing sounds and various timer settings.

4.3 Night Light

The night light features 10 adjustable soft colors, including a red light for optimal sleep. Brightness intensity can be customized to prevent harsh light. This function can also be used for ambient lighting or during nighttime care.

4.4 Alarm Clock

Set a sound alarm with a choice of 6 chimes (buzzer, birds, or light music). The clear LCD display shows the time, which can be set to standard 12-hour or 24-hour military time. A large snooze button provides an additional 9 minutes of sleep.



Image 6: The alarm clock showing two wake-up modes, indicating options for light only or light with sound, along with snooze and volume level indicators.

4.5 Button Functions

The back of the clock features several buttons for controlling its various functions. Refer to the diagram below for a visual guide to button placement and their primary functions.

Short Press:

- **Music Note Icon:** Turn on sound machine and change sound options.
- **Timer Icon:** Turn on sleep timer and change timer durations.
- **Snooze/Wakeup:** Snooze alarm when it goes off; turn on nightlight and change light colors.
- **'+' Button:** Add/Next/Forward.
- **'-' Button:** Decrease/Previous/Backward.
- **Wake Button:** Turn alarm on/off.
- **Dimmer/Lock:** Adjust display brightness.
- **Brightness/Time Set:** Adjust nightlight brightness when light is on; turn on nightlight and change light colors.
- **Day/Night Set:** Turn on/off Day/Night time (Sun/Moon icon shows or disappears from display).
- **Sleep Button:** Turn on sleep feature.

Hold and Press (for 2-3 seconds):

- **Music Note Icon:** Turn off sound machine.
- **Timer Icon:** Turn off timer.
- **Wake Button:** Enter alarm setting.
- **Dimmer/Lock:** Turn off child lock (hold for 5 seconds).
- **Brightness/Time Set:** Enter 12/24h and clock setting.
- **Day/Night Set:** Enter Day/Night time setting.
- **Sleep Button:** Enter Sleep setting.



Image 7: Detailed diagram illustrating the various buttons on the back of the alarm clock and their corresponding short press and hold functions.

5. MAINTENANCE

To ensure the longevity and proper functioning of your APUZOM Kids Alarm Clock, follow these maintenance guidelines:

- **Cleaning:** Wipe the clock's surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Placement:** Place the clock on a stable, flat surface away from direct sunlight, excessive heat, or moisture.
- **Handling:** Handle the device with care. Avoid dropping it or subjecting it to strong impacts.
- **Power:** Ensure the power cable is not kinked or damaged. Always use the provided power adapter.

6. TROUBLESHOOTING

If you encounter issues with your APUZOM Kids Alarm Clock, refer to the following common troubleshooting steps:

- **Clock Not Turning On:**
 - Verify that the USB power cable is securely connected to both the clock and the power adapter.
 - Ensure the power adapter is properly plugged into a working electrical outlet.
 - Check if the outlet itself is functional by plugging in another device.
- **Settings Not Saving:**
 - The internal CR5 button battery is for backup during power outages. If settings are not saving

even with continuous power, ensure the battery is correctly installed.

- If the clock is frequently unplugged, the backup battery may eventually deplete. Replace the CR5 battery if necessary.

- **Alarm Not Sounding/Light Not Changing:**

- Confirm that the alarm is enabled and set to the correct time.
- Check the volume level for the alarm sound.
- Ensure the sleep training feature (Day/Night setting) is correctly configured for the desired times.

- **Display Too Bright/Dim:**

- Use the "Dimmer" button to adjust the display brightness.
- Use the "Brightness" button to adjust the nightlight brightness.

If issues persist, please contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	APUZOM
Model Number	M5
Color	White
Display Type	Digital
Special Features	Adjustable Brightness, Alarm, Noise Machine, OK to Wake, Timer
Product Dimensions	5.1"W x 5.1"H
Power Source	Corded Electric
Room Type	Bedroom, Classroom, Kid's Room, Study Room
Shape	Round
Material	Plastic
Item Weight	11.6 ounces (0.33 Kilograms)
Batteries	1 CR5 battery required (included, for backup only)
Mounting Type	Tabletop/Desktop

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the product packaging or contact APUZOM customer service directly. Contact details are typically provided on the product box or through the retailer where the item was purchased.

