

[manuals.plus](#) /› [DASH](#) /› [DASH 7qt Clear View Digital Air Fryer DVAF700GBCM01 User Manual](#)

## **DASH DVAF700GBCM01**

# **DASH 7qt Clear View Digital Air Fryer User Manual**

Model: DVAF700GBCM01 | Brand: DASH

## **1. INTRODUCTION**

The DASH 7qt Clear View Digital Air Fryer is designed for efficient and healthier cooking. Utilizing AirCrisp® Technology, it circulates 360° hot air to cook food with significantly less oil than traditional deep frying methods. Its generous 7-quart capacity is suitable for preparing meals for families and gatherings. The appliance features a user-friendly digital touchscreen with preset cooking options, a Clear View drawer for monitoring cooking progress, and a Shake Reminder function to ensure even results.



Figure 1: DASH 7qt Clear View Digital Air Fryer, showcasing its design and clear cooking window.

## 2. SAFETY INSTRUCTIONS

Please read all instructions before operating the appliance. Keep this manual for future reference.

- Always unplug the air fryer from the power outlet when not in use or before cleaning.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances, allowing adequate air circulation.
- Do not block any air vents during operation.
- Exercise extreme caution when removing the hot crisper drawer or crisper plate.
- This appliance is for household use only.

### 3. PRODUCT OVERVIEW & COMPONENTS

The DASH 7qt Clear View Digital Air Fryer consists of the main unit, a removable crisper drawer with a clear viewing window, and a crisper plate. The digital touchscreen provides intuitive control over cooking settings.

- **Main Unit:** Houses the heating element, fan, and digital controls.
- **Crisper Drawer:** A pull-out drawer with a handle and a transparent window to observe food during cooking.
- **Crisper Plate:** Sits inside the crisper drawer, allowing air to circulate around the food for even cooking and crisping.
- **Digital Touchscreen:** Displays time, temperature, and preset options.



Figure 2: The Clear View drawer allows easy monitoring of food.

### 4. SETUP

Before first use, follow these steps:

1. Remove all packaging materials, stickers, and labels from the air fryer.
2. Wash the crisper drawer and crisper plate thoroughly with warm, soapy water. Rinse and dry completely.  
These parts are dishwasher safe.
3. Wipe the interior and exterior of the main unit with a damp cloth.

4. Place the air fryer on a stable, level, heat-resistant surface. Ensure there is at least 6 inches of space around the back and sides for proper air circulation.

## 5. OPERATING INSTRUCTIONS

---

Operating your DASH Air Fryer is straightforward with its digital touchscreen controls.

- **Powering On:** Plug the air fryer into a grounded electrical outlet. The digital display will illuminate. Press the power icon to turn the unit on.
- **Setting Temperature and Time:** Use the temperature (up/down arrows) and time (up/down arrows) controls on the digital touchscreen to set your desired cooking parameters. The temperature range is 180°F to 400°F, and the timer can be set up to 60 minutes.
- **Preheating:** For best results, preheat the air fryer before adding food. Set the desired temperature and time, then press the Start/Pause button. The unit will indicate when preheating is complete.
- **Using Preset Cooking Settings:** The air fryer features 11 preset cooking settings for common foods such as French Fries, Bacon, Chicken, Steak, Dessert, Vegetables, Toast, Fish, Wings, Warm, and Defrost. Simply select the desired preset icon on the touchscreen for one-touch cooking.
- **Shake Reminder Function:** For certain foods, the air fryer will prompt you to shake the crisper drawer halfway through the cooking cycle to ensure even crisping.
- **Clear View Window:** Monitor your food's progress without opening the drawer, preserving heat and cooking efficiency.
- **Inserting/Removing Crisper Drawer:** Always use the handle to slide the crisper drawer in and out. The air fryer will automatically pause when the drawer is removed and resume when it's reinserted.

# ONE-TOUCH COOKING!

Cook it *exactly* how you like it with 11 preset cook modes, up to 400°F and 60 minutes.



FRENCH FRIES



BACON



CHICKEN



STEAK



DESSERT



VEGETABLES



TOAST



FISH



WINGS



WARM



DEFROST

Figure 3: Digital Touchscreen with 11 preset cooking modes.

## 6. COOKING GUIDE

The air fryer is versatile for various cooking tasks, from air frying to roasting and baking. For optimal results, consider the following:

- **Do Not Overfill:** Avoid overcrowding the crisper drawer to allow hot air to circulate freely, ensuring even cooking and crisping.
- **Shake or Toss:** For foods like fries or wings, shake or toss the contents of the crisper drawer periodically during cooking. The Shake Reminder function will assist with this.
- **Check Doneness:** Always use a food thermometer to ensure meats and poultry reach safe internal temperatures.
- **Recipe Guide:** Refer to the included Recipe Guide for specific recipes, temperatures, and cooking times tailored for your air fryer.



Figure 4: Crispy fries prepared using the air fryer.

## 7. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your air fryer.

1. Always unplug the air fryer and allow it to cool completely before cleaning.
2. The crisper drawer and crisper plate are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge.
3. Wipe the exterior of the air fryer unit with a damp cloth. Do not use abrasive cleaners or scouring pads.
4. Ensure all parts are completely dry before reassembling and storing the appliance.



Figure 5: The crisper drawer and plate are easily removable for cleaning.

## 8. TROUBLESHOOTING

If you encounter issues with your air fryer, consult the following common problems and solutions:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into a grounded outlet. Check if the crisper drawer is fully inserted.
- **Food is not crispy:** Avoid overcrowding the basket. Cook in smaller batches if necessary. Ensure the temperature and cooking time are appropriate for the food type. Shake or toss food halfway through cooking.
- **White smoke from appliance:** This may indicate excess oil or grease from fatty foods. Clean the crisper drawer and plate thoroughly after each use.
- **Uneven cooking:** Ensure food is arranged in a single layer and shaken/tossed regularly.

## 9. SPECIFICATIONS

| Feature               | Detail  |
|-----------------------|---|
| Model Number          | DVAF700GBCM01   |
| Capacity              | 7 Quarts  |
| Wattage               | 1500 Watts  |
| Temperature Range     | Up to 400 Degrees Fahrenheit                                  |
| Control Method        | Touch   |
| Product Dimensions    | 11.8"D x 12.8"W x 15.28"H                                     |
| Material              | Polypropylene (PP)  |
| Dishwasher Safe Parts | Yes (Crisper Drawer & Plate)                                  |
| Special Feature       | Temperature Control, Timer, Clear View Window, Shake Reminder |



Figure 6: Product dimensions for placement reference.

## 10. WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official DASH website. For any product support, questions, or service requests, please contact DASH customer service.

## Related Documents - DVAF700GBCM01

|   |  |
|---|--|
|    | <p><a href="#"><u>Dash Deluxe Air Fryer: User Manual, Features, and Recipes</u></a></p> <p>Comprehensive guide for the Dash Deluxe Air Fryer (DFAF455GB), including important safety instructions, parts and features, usage guide, cleaning tips, troubleshooting, and a collection of delicious recipes.</p>   |
|    | <p><a href="#"><u>Dash Tasti-Crisp™ Digital Air Fryer Instruction Manual and Recipe Guide</u></a></p> <p>Comprehensive guide for the Dash Tasti-Crisp™ Digital Air Fryer, including important safety information, parts and features, operating instructions, tips and tricks, temperature charts, cleaning and maintenance, troubleshooting, and a variety of recipes.</p>  |
|   | <p><a href="#"><u>Dash Compact Air Fryer DCAF150: User Manual, Recipes &amp; Support</u></a></p> <p>Comprehensive guide for the Dash Compact Air Fryer (DCAF150), including important safety instructions, parts identification, usage tips, troubleshooting, a detailed recipe book, and customer support information.</p>  |
|  | <p><a href="#"><u>Dash Digital Compact Air Fryer DCAF155 User Manual and Recipe Book</u></a></p> <p>Comprehensive user manual for the Dash Digital Compact Air Fryer (DCAF155) featuring AirCrisp™ Technology. Includes detailed safety instructions, operating guide, parts identification, usage tips, cooking charts, cleaning and maintenance, troubleshooting, a collection of recipes, customer support information, and warranty details.</p> |
|  | <p><a href="#"><u>DASH Air Fryer &amp; Rice Cooker User Manual and Recipe Guide</u></a></p> <p>Comprehensive user manual and recipe guide for the DASH Tasti-Crisp™ Digital Air Fryer (DCAF260) and the DASH Mini Rice Cooker Steamer (DRCM200), featuring setup, operation, maintenance, troubleshooting, and recipes.</p>  |
|  | <p><a href="#"><u>Dash DCAF260 Digital Tasti-Crisp Air Fryer: Instruction Manual &amp; Recipe Guide</u></a></p> <p>Comprehensive instruction manual and recipe guide for the Dash DCAF260 Digital Tasti-Crisp Air Fryer. Learn how to safely operate, maintain, and use this kitchen appliance for delicious air-fried meals.</p>  |