

[Manuals.plus](#) /

> [EndlessMining](#) /

> Bitmain Antminer L9 Instruction Manual

## EndlessMining Antminer L9

# Bitmain Antminer L9 Instruction Manual

MODEL: ANTMINER L9 (16GH/s, 3360W)

## 1. Product Overview

The Bitmain Antminer L9 is a high-performance cryptocurrency mining rig designed for efficient Litecoin (LTC) and Dogecoin (Doge) mining, utilizing the Scrypt algorithm. It features a hash rate of 16Gh/s and a power consumption of 3360W. This manual provides essential information for the proper setup, operation, and maintenance of your Antminer L9.



Image: Front view of the Bitmain Antminer L9, showcasing its robust cooling system with multiple fans and the integrated control board.

## Key Features:

- **Powerful Mining Rig:** Delivers an impressive 16Gh/s hash rate for Scrypt-based cryptocurrencies.
- **High Power Consumption:** Operates at 3360W, requiring adequate power supply and cooling infrastructure.
- **Wide Input Voltage Range:** Compatible with 220-277V AC input, offering flexibility in power source integration.
- **Designed for Continuous Operation:** Engineered for uninterrupted performance in mining environments.
- **Compact Form Factor:** Optimized design for space-efficient setup.

## 2. Setup Guide

### 2.1 Unpacking and Inspection

- Carefully remove the Antminer L9 from its packaging.
- Inspect the unit for any visible damage that may have occurred during shipping.
- Ensure all components, including power cables (if supplied), are present.

### 2.2 Power Connection

The Antminer L9 requires a 220-277V AC power input. It is crucial to use a power supply unit (PSU) and power cables that are rated for the miner's 3360W power consumption.

- Connect the appropriate C13 power connector(s) from your PSU to the miner's power input ports.
- Ensure all connections are secure to prevent power loss or damage.
- Verify your electrical infrastructure can support the miner's power requirements.

### 2.3 Network Connection

The miner requires an Ethernet connection to access the mining pool and the internet.

- Connect an Ethernet cable from your network router or switch to the RJ45 port on the Antminer L9's control board.
- Ensure a stable internet connection for optimal mining performance.

### 2.4 Cooling and Environment

Proper cooling is essential for the longevity and performance of the Antminer L9. The unit uses air cooling.

- Place the miner in a well-ventilated area with adequate airflow.
- Maintain an ambient temperature within the recommended operating range (refer to specifications).
- Avoid placing the miner in enclosed spaces or near heat sources.

## 3. Operating Instructions

### 3.1 Initial Power-On

- After connecting power and network cables, switch on the power supply to the miner.
- The miner will initiate its boot sequence. Observe the indicator lights for status.

### 3.2 Accessing the Web Interface

To configure the miner, you will need to access its web-based management interface.

- Use an IP scanner tool on your network to find the IP address assigned to the Antminer L9.
- Open a web browser and enter the miner's IP address in the address bar.
- Log in using the default credentials (refer to Bitmain documentation for specific default username/password).

### 3.3 Configuration for Mining

Within the web interface, configure the mining settings:

- Navigate to the 'Miner Configuration' or 'Pool Settings' section.
- Enter the URL, username, and password for your chosen Litecoin (LTC) or Dogecoin (Doge) mining pool.
- Save the settings and restart the miner if prompted.
- Monitor the 'Miner Status' page to confirm that the miner is hashing correctly and submitting shares to the pool.

## 4. Maintenance

### 4.1 Regular Cleaning

Dust accumulation can impede cooling and reduce efficiency.

- Periodically clean the miner's fans and heatsinks using compressed air.
- Ensure the miner is powered off and unplugged before cleaning.
- Do not use liquids or abrasive cleaners.

### 4.2 Environmental Control

- Maintain a stable operating environment with consistent temperature and humidity.
- Ensure proper ventilation to dissipate heat generated by the miner.

### 4.3 Firmware Updates

Check the official Bitmain website for the latest firmware updates. Firmware updates can improve performance, stability, and security.

- Follow the manufacturer's instructions carefully when performing firmware updates.
- Ensure a stable power supply during the update process to prevent bricking the device.

## 5. Troubleshooting

### 5.1 Miner Not Powering On

- Check all power cable connections to the miner and the power outlet.
- Verify that the power supply unit (PSU) is functioning correctly.
- Ensure the input voltage is within the 220-277V AC range.

### 5.2 No Network Connection

- Confirm the Ethernet cable is securely connected to both the miner and the router/switch.
- Check the network status lights on the miner's control board and your router.
- Verify that your network is operational and providing internet access.

### 5.3 Low Hash Rate or No Shares

- Verify your mining pool settings (URL, username, password) in the web interface.
- Check your internet connection stability and latency to the mining pool.
- Ensure the miner's temperature is within acceptable limits; overheating can cause performance degradation.
- Inspect the hash boards for any errors reported in the miner's status page.

## 6. Technical Specifications

Specification	Value
Model Name	Antminer L9
Hash Rate	16Gh/s
Power Consumption	3360W
Input Voltage	220-277V AC
Compatible Devices	Doge, LTC
Connector Type	C13
Cooling Method	Air Cooling
Product Dimensions (L x W x H)	15.75 x 7.68 x 11.42 inches
Manufacturer	Bitmain
Brand	EndlessMining

## **7. Warranty and Support**

This product is manufactured by Bitmain and distributed by EndlessMining. For specific warranty terms and conditions, please refer to the official documentation provided with your purchase or visit the manufacturer's website.

Protection plans may be available for extended coverage. For example, a 4-Year Protection Plan is offered for this product.

For technical support or inquiries regarding your Antminer L9, please contact the vendor or manufacturer's customer service channels.