

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RCF](#) /

› [RCF LF21X451 21-inch Sub Woofer Instruction Manual](#)

## RCF RCF-LF21X451

# RCF LF21X451 21-inch Sub Woofer Instruction Manual

Model: RCF-LF21X451

## 1. INTRODUCTION

This manual provides comprehensive instructions for the RCF LF21X451 21-inch Sub Woofer. It covers product features, specifications, setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before installation and use.

## 2. KEY FEATURES

Image: Front view of the RCF LF21X451 21-inch Sub Woofer, showcasing its robust design and voice coil.

- **4.5-inch Fiberglass Inside/Outside Copper Voice Coil:** Designed for high power handling and efficient heat dissipation.
- **4000 Watt Continuous Program Power Handling:** Capable of delivering substantial acoustic output.
- **97 dB Sensitivity:** Ensures efficient conversion of amplifier power into sound.
- **28 Hz - 1 kHz Frequency Range:** Provides deep bass reproduction and extends into the lower midrange.
- **Dual-Forced Air Ventilation:** Minimizes power compression and maintains performance during extended use.
- **Dual Spider Design with Silicon-Based Damping Control:** Enhances stability and linearity of cone movement.
- **BL of 30.5 Txm:** Delivers fast and accurate low-frequency response.

## 3. WHAT'S IN THE BOX

The RCF LF21X451 package includes the following components:

- RCF LF21X451 21-inch Sub Woofer (8 Ohm)

Please inspect all contents upon unboxing to ensure no items are missing or damaged.

## 4. TECHNICAL SPECIFICATIONS

### 4.1. General Specifications

Parameter	Value
Nominal Diameter	530 / 21 mm/inch
Rated Impedance	8 Ohm
Program Power	4000 W AES
Power Handling Capacity	2000 W AES
Sensitivity	97 dB
Frequency Range	28 Hz &divide; 1000 Hz
Effective Piston Diameter	470 / 18.5 mm/inch
Max Excursion Before Damage (peak to peak)	54 / 2.12 mm/inch
Minimum Impedance	6.7 Ohm

### 4.2. Voice Coil and Cone Specifications

Parameter	Value
Voice Coil Diameter	115 / 4.5 mm/inch
Voice Coil Material	Copper
Voice Coil Winding Depth	34 / 1.33 mm/inch
Number of Layers	2
Kind of Layer	Inside / Outside
Top Plate Thickness	15 / 0.6 mm/inch
Cone Material	No pressed pulp
Cone Design	Curved
Surround Material	Polycotton
Surround Design	Triple roll

### 4.3. Thiele-Small Parameters

Parameter	Value
Resonance Frequency (Fs)	28 Hz
DC Resistance (Re)	5.4 Ohm
Mechanical Factor (Qms)	6.9

Parameter	Value
Electrical Factor (Qes)	0.39
Total Factor (Qts)	0.37
BL Factor (BL)	30.5 T · m
Effective Moving Mass (Mms)	355 g
Equivalent Cas Air Load (Vas)	385 liters
Effective Piston Area (Sd)	0.173 m <sup>2</sup>
Max. Linear Excursion (Xmax)	13.5 mm
Voice-Coil Inductance @ 1kHz (Le)	2.9 mH
Half-Space Efficiency (&eta;0)	2.2%

## 5. MOUNTING INFORMATION

Proper mounting is crucial for the performance and longevity of your RCF LF21X451 sub woofer. Refer to the diagrams below for precise dimensions.



Image: Top-down view of the subwoofer with overall diameter (Ø 547 mm) indicated.



Image: Side view of the subwoofer with depth (228.4 mm), top plate thickness (15 mm), and voice coil dimensions (Ø 245 mm, Ø 508 mm) indicated.

Parameter	Value
Overall Diameter	547 / 21.5 mm/inch
Bolt Circle Diameter	527 / 20.7 mm/inch
Bolt Hole Diameter	6.5 / 0.25 mm/inch
Front Mount Baffle Cut-out	512 / 20.1 mm/inch
Rear Mount Baffle Cut-out	512 / 20.1 mm/inch
Depth	230 / 9.05 mm/inch
Volume Occupied by the Driver	6.5 / 0.229 liters/ft <sup>3</sup>
Net Weight	15.5 / 34.0 kg/lbs
Shipping Weight	17.59 / 26.6 kg/lbs

## 6. SETUP AND INSTALLATION

This section provides general guidelines for setting up your RCF LF21X451 sub woofer. For specific enclosure designs, consult a professional audio engineer or refer to specialized acoustic design resources.

## 6.1. Enclosure Design

The LF21X451 is designed for use in custom-built enclosures. Consider the following:

- **Enclosure Volume:** The Thiele-Small parameters (especially  $V_{as}$ ) are critical for designing an appropriate enclosure (sealed, ported, bandpass). The driver occupies 6.5 liters (0.229 ft<sup>3</sup>) of volume within the enclosure.
- **Port Tuning:** For ported designs, ensure the port is tuned to complement the driver's characteristics and desired frequency response.
- **Material:** Use rigid, non-resonant materials like high-density MDF or plywood for the enclosure to prevent unwanted vibrations.
- **Bracing:** Internal bracing is recommended to increase enclosure rigidity.

## 6.2. Mounting the Driver

Use the provided mounting information for precise cut-out and bolt hole dimensions:

- **Baffle Cut-out:** Ensure the front or rear baffle cut-out (512 mm / 20.1 inches) is precise for a snug fit.
- **Bolt Holes:** Drill bolt holes (6.5 mm / 0.25 inches diameter) accurately on a bolt circle diameter of 527 mm (20.7 inches).
- **Sealing:** Use a gasket or sealant between the driver frame and the baffle to ensure an airtight seal, preventing air leaks that can degrade performance.
- **Fasteners:** Use appropriate screws or bolts that securely fasten the driver without overtightening, which could damage the frame.

## 6.3. Wiring

Connect the sub woofer to a suitable amplifier using high-quality speaker wire. Observe correct polarity (+ to + and - to -) to ensure proper phase alignment with other speakers in your system.

- **Impedance Matching:** Ensure your amplifier can safely drive an 8 Ohm load.
- **Wire Gauge:** Use sufficiently thick speaker wire to minimize power loss, especially for long cable runs.

## 7. OPERATION

Once installed, follow these guidelines for operating your RCF LF21X451 sub woofer:

- **Amplifier Power:** Ensure the amplifier's power output is within the sub woofer's recommended power handling (2000 W AES / 4000 W Program Power). Underpowering can be as damaging as overpowering due to clipping.
- **Crossover Settings:** Use an external crossover or your amplifier's built-in crossover to filter out frequencies above the sub woofer's effective range (e.g., set a low-pass filter around 80-100 Hz). This prevents the sub woofer from reproducing frequencies it's not designed for, improving overall system clarity and protecting the driver.
- **Gain Staging:** Properly set the gain on your amplifier to match the output of your source device. Avoid setting the gain too high, which can lead to distortion and potential damage.
- **Break-in Period:** Allow a break-in period of several hours of moderate use before operating the sub woofer at high volumes. This allows the suspension components to loosen and settle.
- **Listening Levels:** While the sub woofer is designed for high output, prolonged operation at extreme volumes can still cause fatigue or damage. Listen responsibly.

## 8. MAINTENANCE

The RCF LF21X451 sub woofer is designed for durability, but proper maintenance will ensure its long-term performance:

- **Cleaning:** Gently wipe the cone and surround with a soft, dry cloth to remove dust. Avoid using harsh chemicals or excessive moisture.
- **Inspection:** Periodically inspect the cone, surround, and spider for any signs of damage, tears, or deterioration. Check the terminals for secure connections.
- **Environmental Conditions:** Store and operate the sub woofer in a stable environment, away from extreme temperatures, humidity, and direct sunlight.
- **Protection:** If the sub woofer is exposed to potential physical impact, consider using a protective grille.

## 9. TROUBLESHOOTING

If you encounter issues with your RCF LF21X451 sub woofer, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No Sound	Loose or incorrect wiring; Amplifier off or faulty; Source device issue.	Check all speaker wire connections for proper polarity and secure fit. Ensure amplifier is powered on and functioning. Verify source device (e.g., receiver, processor) is sending audio signal.
Distorted Sound	Overdriving the sub woofer/amplifier; Incorrect gain settings; Damaged voice coil/cone.	Reduce amplifier volume. Adjust amplifier gain to prevent clipping. Check for physical damage to the cone or voice coil. Ensure proper crossover settings.
Weak Bass Output	Incorrect phase; Insufficient amplifier power; Improper enclosure design; Room acoustics.	Verify correct wiring polarity. Ensure amplifier provides adequate power. Review enclosure design specifications. Experiment with sub woofer placement in the room.
Rattling/Buzzing Noise	Loose mounting screws; Air leak in enclosure; Foreign object in voice coil gap; Damaged cone/surround.	Tighten mounting screws. Check enclosure for air leaks and seal if necessary. Inspect voice coil gap for debris. Examine cone and surround for tears or detachment.


If the problem persists after attempting these solutions, contact a qualified audio technician or RCF customer support.


## 10. WARRANTY AND SUPPORT

The RCF LF21X451 sub woofer comes with a **Limited Warranty**. Please refer to the warranty card included with your purchase or visit the [official RCF website](#) for detailed terms and conditions regarding warranty coverage, duration, and claims procedures.

For technical support, service, or inquiries not covered in this manual, please contact RCF customer service through their official website or authorized distributors. Keep your purchase receipt as proof of purchase for warranty claims.

## Related Documents - RCF-LF21X451

	<p><a href="#">RCF KX32-A Active 2-Way Speaker System</a></p> <p>Detailed specifications and features of the RCF KX32-A, a 3200W Peak, 1600W RMS active 2-way speaker system with a 12-inch neodymium woofer and a 3-inch titanium compression driver. Includes information on its acoustic performance, input/output, processor, amplifier, and physical dimensions. Also lists compatible accessories.</p>
	<p><a href="#">RCF KX45-A Active 2-Way Speaker System: Specifications and Accessories</a></p> <p>Detailed specifications and optional accessories for the RCF KX45-A, a 3200W Peak, 1600W RMS active 2-way speaker with a 15-inch neodymium woofer and a 1.4-inch titanium compression driver, featuring RDNet compatibility.</p>
	<p><a href="#">RCF SUB 8008-AS Professional Active Subwoofer Owner's Manual</a></p> <p>Comprehensive owner's manual for the RCF SUB 8008-AS professional active subwoofer, detailing safety precautions, technical specifications, setup, and troubleshooting.</p>
	<p><a href="#">RCF M 18 Digital Mixer Reference Guide</a></p> <p>Comprehensive reference guide for the RCF M 18 Digital Mixer, detailing features, setup, operation, firmware updates, network connectivity, and technical specifications for musicians and audio professionals.</p>
	<p><a href="#">RCF COMPACT C Series: COMPACT C 32 &amp; C 45 Owner's Manual</a></p> <p>Comprehensive owner's manual for RCF COMPACT C 32 and COMPACT C 45 two-way professional loudspeakers, covering safety precautions, product description, connection details, configuration options, mounting instructions, accessory information, low impedance connection notes, dimensions, and technical specifications.</p>



### [RCF HDL15-AS Active Flyable High Power Subwoofer Owner Manual](#)

This owner's manual provides detailed information for the RCF HDL15-AS Active Flyable High Power Subwoofer. It covers safety precautions, product features, technical specifications, installation, rigging, and array design for professional audio and touring applications.