

TPW-AF01--IN

Generic 3L Digital Air Fryer User Manual

Model: TPW-AF01--IN

1. INTRODUCTION

Thank you for purchasing the Generic 3L Digital Air Fryer. This appliance is designed to cook your favorite foods with little to no oil, offering a healthier alternative to traditional frying. Please read this manual thoroughly before first use to ensure safe and optimal operation. Keep this manual for future reference.

Key Features:

- **Compact Design:** Space-saving appliance for delicious fried foods with minimal oil.
- **Rapid Air Circulation:** Ensures even cooking and crisping from all sides.
- **Temperature Control:** Adjustable settings for optimal cooking results.
- **Timer Function:** Built-in timer prevents overcooking.
- **Easy Cleaning:** Non-stick interior and removable basket for simple maintenance.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block the air inlet and outlet openings.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Generic 3L Digital Air Fryer.

Components:

- Main Body
- Frying Basket
- Grid/Crisper Plate



Image 3.1: Front view of the Generic 3L Digital Air Fryer, showcasing its compact design and digital touch control panel.



Image 3.2: The removable frying basket and crisper grid, designed for easy food placement and cleaning.

4. SETUP AND FIRST USE

Unpacking:

1. Remove all packaging materials from the air fryer.
2. Check that all components (main body, basket, grid) are present and undamaged.
3. Remove any stickers or labels from the appliance.

Before First Use:

1. Clean the frying basket and grid thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.

2. Wipe the inside and outside of the appliance with a damp cloth.
3. Place the air fryer on a stable, level, and heat-resistant surface, ensuring adequate space (at least 10 cm) around the back and sides for proper ventilation.
4. Plug the power cord into a grounded wall outlet.
5. It is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) during the first use to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal.

5. OPERATING INSTRUCTIONS

Basic Operation:

1. Place the grid inside the frying basket.
2. Carefully place the ingredients into the frying basket. Do not overfill the basket.
3. Slide the frying basket back into the air fryer. Ensure it is fully closed.
4. Plug the appliance into a power outlet. The digital display will illuminate.
5. Press the Power button to turn on the air fryer.
6. Use the temperature control buttons to set the desired cooking temperature.
7. Use the timer control buttons to set the desired cooking time.
8. Press the Start/Pause button to begin cooking.
9. Some recipes may require shaking the ingredients halfway through the cooking time. To do this, pull out the basket, shake it gently, and then slide it back in. The air fryer will resume cooking automatically.
10. When the timer reaches zero, the air fryer will beep, indicating cooking is complete.
11. Carefully pull out the basket and transfer the cooked food to a plate. Use tongs to remove food.
12. Unplug the appliance after use.

Recommended Uses:

This air fryer is versatile and can be used for various cooking methods:

- Baking
- Reheating
- Roasting
- Tandoor-style cooking
- Deep frying (with minimal oil)
- Frying

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

Cleaning After Each Use:

1. Unplug the air fryer and allow it to cool down completely before cleaning.
2. Remove the frying basket and grid.
3. Wash the basket and grid with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak them in hot water for about 10 minutes.
4. Wipe the exterior of the air fryer with a damp cloth. Do not use harsh abrasive cleaners.
5. Clean the interior of the appliance with a damp cloth and mild detergent.
6. Ensure all parts are completely dry before reassembling or storing.

Note: The frying basket and grid are **not dishwasher safe**.

Storage:

Store the air fryer in a cool, dry place, away from direct sunlight and moisture. Ensure the power cord is neatly wrapped and secured.

7. TROUBLESHOOTING

If you encounter any issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Basket not fully inserted.	Ensure the power cord is securely plugged into a grounded outlet. Push the frying basket completely into the appliance until it clicks into place.
Food is not cooked evenly.	Basket is overfilled. Food not shaken/flipped.	Reduce the amount of food in the basket. Cook in smaller batches. Shake or flip ingredients halfway through cooking.
White smoke coming from the appliance.	Greasy residue from previous use. High fat content food.	Clean the basket and grid thoroughly after each use. Remove excess oil from food before air frying.
Food is not crispy.	Too much moisture in food. Not enough oil (for certain foods).	Pat food dry before cooking. Lightly brush or spray food with a small amount of oil.

8. SPECIFICATIONS

Model Number	TPW-AF01--IN
Brand	Generic
Capacity	3 Litres
Output Wattage	1200 Watts
Voltage	220 Volts
Controller Type	Touch Control
Material	Plastic
Product Dimensions (D x W x H)	28D x 22.6W x 29.6H Centimeters
Item Weight	3.1 Kilograms
Special Features	Automatic Shut-Off, Light Weight, Temperature Control, Space-saving design

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.