

[manuals.plus](#) /› [Dell](#) /› [Dell OptiPlex 7020 MFF Micro Form Factor Mini Business Desktop Computer User Manual](#)

Dell 7020 MFF

Dell OptiPlex 7020 MFF Micro Form Factor Mini Business Desktop Computer User Manual


Model: 7020 MFF

1. PRODUCT OVERVIEW


The Dell OptiPlex 7020 MFF is a Micro Form Factor Mini Business Desktop Computer designed for efficient performance in compact spaces. It features a 14th Gen Intel Core i7-14700T processor, 64GB DDR5 RAM, and a 4TB PCIe SSD, making it suitable for demanding business tasks. This system supports up to three simultaneous displays with 4K resolution via its HDMI and DisplayPort outputs.

OptiPlex 7020 MFF

Business Mini PC Computer



Intel Core
i7-14700T



Intel UHD Graphics
770



DDR5 RAM
Max 64 GB



PCIe NVMe SSD*2
Max 4TB



10/100/1000 Mbps



Wireless Connection
Wi-Fi 6 + Bluetooth



Wired Keyboard
and Mouse



2x DisplayPorts+1 HDMI+1 Type-C



4 Screen Display



Operating system
Windows 11 Pro

Image: Front view of the Dell OptiPlex 7020 MFF desktop computer, showcasing its compact design.

2. KEY FEATURES


- Processor:** 14th Gen Intel Core i7-14700T (20 Cores, 28 Threads, up to 5.2GHz)
- Graphics:** Integrated Intel UHD Graphics 770
- Memory:** 64GB DDR5 RAM for enhanced multitasking
- Storage:** 4TB M.2 PCIe NVMe SSD for fast boot and data access
- Display Support:** Connect up to 3 displays (1 HDMI 1.4b, 2 DisplayPort 1.4a) with up to 4K resolution
- Connectivity:** Wi-Fi 6 (802.11ax), Bluetooth, Gigabit Ethernet
- Ports:** USB 3.2 Gen 2x2 Type-C, USB 3.2 Gen 2 Type-A, USB 3.2 Gen 1 Type-A, USB 2.0 Type-A
- Operating System:** Windows 11 Professional



Image: Diagram illustrating key specifications and features of the OptiPlex 7020 MFF, including CPU, GPU, RAM, storage, network, display, and operating system.

3. PHYSICAL OVERVIEW: PORTS AND CONNECTORS

Front Panel



Ports & Slots

1. Power Button
2. Storage Activity Light
3. Universal Audio Port
4. USB 3.2 Type-A Gen 1
5. USB 3.2 Type-C Gen 2x2

Image: Detailed view of the front panel ports and their labels.

1. Power Button
2. Storage Activity Light
3. Universal Audio Port
4. USB 3.2 Gen 1 (5 Gbps) Type-A Port with PowerShare
5. USB 3.2 Gen 2x2 (10 Gbps) Type-C Port

Rear Panel

7. RJ-45 Ethernet Port

8. DisplayPort 1.4a

9. USB 2.0 Type-A with SmartPower On

10. USB 2.0 Type-A

11. 2x USB 3.2 Type-A Gen 1

12. Kensington Security Cable Slot and

Padlock Ring

13. HDMI 1.4b

14. DisplayPort 1.4a

15. Power Connector




Image: Detailed view of the rear panel ports and their labels.

6. Kensington Security Cable Slot and Padlock Ring

7. RJ-45 Ethernet Port

8. USB 2.0 Type-A Port (480 Mbps) with SmartPower On

9. USB 2.0 Type-A Port (480 Mbps)

10. 2x USB 3.2 Gen 1 (5 Gbps) Type-A Ports

11. 2x DisplayPort 1.4a Ports

12. HDMI 1.4b Port

13. Power Adapter Port

4. SETUP INSTRUCTIONS

4.1 Unpacking and Placement

Carefully remove the computer and all accessories from the packaging. Place the computer on a stable, flat surface. The compact design allows for versatile placement, including mounting behind a compatible monitor.

Dimensions & Weight

1. Height: 7.17 in. (182 mm)

2. Depth: 7.01 in. (178 mm)

3. Width: 1.42 in. (36 mm)

Weight (minimum): 2.41 lb (1.09 kg)

Weight (maximum): 2.95 lb (1.34 kg)



Image: The Dell OptiPlex 7020 MFF mounted on the back of a monitor, demonstrating space-saving installation.

4.2 Connecting Peripherals

1. **Connect Display:** Connect your monitor(s) to the DisplayPort or HDMI ports on the rear panel. The system supports up to three displays simultaneously.
2. **Connect Keyboard and Mouse:** Plug the included keyboard and mouse into any available USB ports on the front or rear panel.
3. **Connect Network:** For a wired connection, connect an Ethernet cable to the RJ-45 port. For wireless, ensure your Wi-Fi network is available.
4. **Connect Power:** Plug the power adapter into the power adapter port on the rear panel, then connect the power cable to an electrical outlet.

4.3 Initial Power On

Press the power button on the front panel to turn on the computer. Follow the on-screen instructions for the initial setup of Windows 11 Professional.

5. OPERATING SYSTEM

The Dell OptiPlex 7020 MFF comes pre-installed with **Windows 11 Professional**. This operating system provides a secure and productive environment for business applications. For detailed information on using Windows 11, refer to the official Microsoft documentation or support resources.

6. SPECIFICATIONS

Feature	Specification
Processor	14th Gen Intel Core i7-14700T (20 Cores, 28 Threads, up to 5.2GHz)
Graphics	Intel UHD Graphics 770
RAM	64GB DDR5
Storage	4TB M.2 PCIe NVMe SSD
Operating System	Windows 11 Professional
Wireless Connectivity	Wi-Fi 6 (802.11ax), Bluetooth
Ethernet	RJ-45 (Gigabit)
Front Ports	1x Universal Audio Port, 1x USB 3.2 Gen 1 Type-A (with PowerShare), 1x USB 3.2 Gen 2x2 Type-C
Rear Ports	1x RJ-45, 2x USB 2.0 Type-A (one with SmartPower On), 2x USB 3.2 Gen 1 Type-A, 2x DisplayPort 1.4a, 1x HDMI 1.4b, 1x Power Adapter Port
Dimensions (HxWxD)	7.17 x 1.42 x 7.01 inches (182 x 36 x 178 mm)
Weight (minimum)	2.41 lb (1.09 kg)
Included Components	Keyboard, Mouse





Image: Diagram showing the dimensions and weight of the Dell OptiPlex 7020 MFF.

7. MAINTENANCE

7.1 Cleaning the Computer

- Always power off the computer and disconnect it from the power outlet before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution to wipe exterior surfaces.
- Do not spray liquids directly onto the computer.
- Use compressed air to clear dust from vents and ports.

7.2 Software Updates

Regularly update your operating system, drivers, and applications to ensure optimal performance and security. Windows Update can be configured to automatically download and install updates.

8. TROUBLESHOOTING

8.1 No Power

- Ensure the power cable is securely connected to both the computer and the electrical outlet.
- Verify the power outlet is functional by plugging in another device.
- Check the power adapter for any damage.

8.2 No Display

- Confirm that the monitor is powered on and connected correctly to the computer's DisplayPort or HDMI port.
- Try connecting the monitor to a different port or using a different cable.
- Ensure the correct input source is selected on your monitor.

8.3 Peripheral Not Responding

- Ensure the peripheral (keyboard, mouse, etc.) is securely plugged into a USB port.
- Try connecting the peripheral to a different USB port.
- Restart the computer.

9. WARRANTY AND SUPPORT

This Dell OptiPlex 7020 MFF computer is covered by Dell's standard limited warranty. For specific warranty terms, registration, and support options, please visit the official Dell support website or contact Dell customer service. Keep your purchase receipt and product serial number readily available for warranty claims.

Dell Support Website: www.dell.com/support