

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Doro](#) /

› [Doro Leva L10 Mobile Phone User Manual](#)

## Doro Leva 10

# Doro Leva L10 Mobile Phone

## USER MANUAL

Model: Leva 10 | Brand: Doro

### Introduction

The Doro Leva L10 is a user-friendly mobile phone designed for seniors, offering simplified communication with essential features. It boasts a large landscape screen, powerful sound, a built-in camera, and a dedicated assistance button with GPS location for enhanced safety. This manual provides detailed instructions on setting up, operating, maintaining, and troubleshooting your Doro Leva L10.



Figure 1: Doro Leva L10 mobile phone with its charging dock, showing both the front keypad and screen, and the textured back panel with camera and assistance button.

## 1. Setup

### 1.1 Unboxing and Package Contents

Before you begin, ensure all components are present in the package:

- Doro Leva L10 Mobile Phone
- Charging Dock
- USB Type-C Cable
- Power Adapter
- User Manual (this document)

## 1.2 Charging the Battery

The phone comes with a 1000mAh Lithium-ion battery. It is recommended to fully charge the phone before first use.

1. Connect the USB Type-C cable to the charging dock.
2. Connect the power adapter to the USB Type-C cable and plug it into a wall outlet.
3. Place the Doro Leva L10 phone into the charging dock. Ensure it is seated correctly and the charging indicator appears on the screen.
4. Alternatively, you can connect the USB Type-C cable directly to the phone's charging port.

A full charge typically takes a few hours. The battery offers long autonomy.

## 1.3 Inserting the SIM Card

The Doro Leva L10 requires a SIM card to make calls and send SMS messages. Refer to the phone's back panel for the SIM card slot location.





Figure 2: Rear view of the Doro Leva L10, highlighting the camera lens, flash, and the prominent assistance button. The speaker grille is also visible at the bottom.

1. Power off the phone before inserting or removing the SIM card.
2. Carefully remove the back cover of the phone.
3. Locate the SIM card slot(s). Insert your SIM card(s) according to the diagram near the slot, ensuring the gold contacts face down.
4. Replace the back cover securely.

## 1.4 Powering On/Off

- To power on: Press and hold the Power/End Call button (usually red) until the screen lights up.
- To power off: Press and hold the Power/End Call button, then follow the on-screen prompts to shut down.

## 2. Operating Instructions

---

### 2.1 Making Calls and Sending SMS

The Doro Leva L10 is designed for straightforward communication.

- **Making a Call:** Dial the number using the large, well-spaced keypad and press the Green Call button.
- **Answering a Call:** Press the Green Call button when the phone rings.
- **Ending a Call:** Press the Red End Call button.
- **Sending SMS:** Navigate to the 'Messages' menu, select 'New Message', enter the recipient's number and your message using the keypad, then send.

## Larges touches espacées



Figure 3: A hand demonstrating the ease of use with the Doro Leva L10's large, clearly spaced keypad buttons, designed for comfortable and accurate dialing.

### 2.2 Display and Readability

The phone features a 2.4-inch landscape screen with high contrast, ensuring optimal readability, especially for users with low visual acuity.

Un contraste élevé et un écran facile à lire



Figure 4: The Doro Leva L10 display, illustrating its high contrast and large text, making it easy to read for all users.

### 2.3 Assistance Button with GPS

For added security, the Doro Leva L10 includes a dedicated assistance button located on the back of the phone. When pressed, it alerts your trusted contacts via SMS, including your GPS location.

- **Setting up Contacts:** Access the 'Assistance' or 'SOS' settings in the phone's menu to add and manage your emergency contacts.
- **Using the Button:** In an emergency, press and hold the assistance button for a few seconds until the alert is activated.

### 2.4 Camera and Torch

The phone is equipped with a 2MP camera with flash for capturing memories and an integrated torch for convenience.

- **Camera:** Access the camera from the main menu. Use the navigation keys to frame your shot and the 'OK' button to capture.
- **Torch:** The torch function can typically be activated via a shortcut key or through the utilities menu.

## 2.5 Sound Features

The Doro Leva L10 offers powerful and clear sound, compatible with hearing aids (HAC). This ensures conversations are easily heard.

- **Volume Adjustment:** Use the side volume buttons during a call or when playing media to adjust the sound level.
- **Hearing Aid Compatibility:** The phone is designed to work seamlessly with most hearing aids, reducing interference.

## 3. Maintenance

### 3.1 Cleaning the Device

To keep your Doro Leva L10 in optimal condition, clean it regularly:

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.
- Ensure no moisture enters openings.

### 3.2 Splash Resistance (IP54)

The Doro Leva L10 has an IP54 rating, meaning it is protected from dust ingress sufficient to prevent the product from operating normally and from water splashes from any direction. While it offers some protection, it is not waterproof and should not be submerged in water.

## 4. Troubleshooting

If you encounter issues with your Doro Leva L10, try the following solutions:

| Problem                       | Possible Cause  | Solution   |
|-------------------------------|---|--|
| Phone does not power on       | Low battery; Faulty battery/charger                             | Charge the phone for at least 30 minutes. Ensure charger and cable are working.                        |
| Cannot make/receive calls     | No SIM card; SIM card not inserted correctly; No network signal | Check SIM card insertion. Move to an area with better network coverage. Contact your service provider. |
| Poor sound quality            | Low volume; Speaker/microphone blocked                          | Adjust volume. Ensure speakers and microphone are clear of debris.                                     |
| Assistance button not working | Contacts not set up; GPS signal weak                            | Verify emergency contacts in settings. Ensure phone has clear view of sky for GPS.                     |

If the problem persists, please contact Doro customer support.

## 5. Specifications

| Feature    | Detail   |
|------------|----------|
| Brand      | Doro     |
| Model Name | Leva 10  |
| Color      | Graphite |

| Feature                        | Detail                  |
|--------------------------------|-------------------------|
| Screen Size                    | 2.4 Inches              |
| Screen Resolution              | 320 x 240               |
| Camera Resolution              | 2 Megapixels            |
| Connectivity                   | 4G                      |
| Battery Composition            | Lithium-ion (1000mAh)   |
| Operating System               | OxygenOS                |
| Storage Capacity               | 64 GB                   |
| Ingress Protection (IP) Rating | IP54 (Splash resistant) |

## 6. Warranty and Support

Doro products are designed for reliability. For information regarding your product's warranty, please refer to the warranty card included in your product packaging or visit the official Doro website.

For technical support, troubleshooting assistance beyond this manual, or service inquiries, please contact Doro customer support. Contact details can typically be found on the Doro website or on your purchase receipt.

**Doro Official Website:** [www.doro.com](http://www.doro.com)

© 2024 Doro. All rights reserved. Information in this manual is subject to change without notice.

### Related Documents - Leva 10

|   |  |
|---|--|
| <p>Doro Leva E20/E21/E22<br/>Repair Manual DFC-0610</p>  <p>doro</p> | <p><a href="#">Doro Leva E20/E21/E22 Repair Manual</a><br/>Comprehensive repair manual for the Doro Leva E20, E21, and E22 mobile phones, covering disassembly, component replacement, assembly, and troubleshooting.</p>  |
| <p>Doro Leva E30/E31<br/>Repair Manual DFC-0620</p>  <p>doro</p>     | <p><a href="#">Doro Leva E30/E31 Repair Manual: Disassembly, Assembly, and Troubleshooting Guide</a><br/>Comprehensive repair manual for Doro Leva E30 and E31 flip phones. Provides step-by-step instructions for disassembly, component replacement, assembly, and troubleshooting. Includes parts lists and diagrams. Find spare parts at <a href="http://doro.com/repair">doro.com/repair</a>.</p> |

|  |   |
|--|---|
| <p>Doro Leva E21</p>  <p>doro</p>     | <p><a href="#">Doro Leva E21 User Manual: Guide to Features and Operations</a></p> <p>Comprehensive user manual for the Doro Leva E21 clamshell mobile phone, detailing setup, calls, messages, settings, safety instructions, and specifications for easy and accessible communication.</p>  |
|                                       | <p><a href="#">Doro Leva E22 Noir - Notice d'utilisation</a></p> <p>Manuel d'utilisation détaillé pour le téléphone mobile Doro Leva E22 Noir. Découvrez comment configurer, utiliser les appels, messages, paramètres et fonctions de sécurité.</p>  |
| <p>Doro Leva L20</p>  <p>doro</p>     | <p><a href="#">Manuale Utente Doro Leva L20: Guida Completa</a></p> <p>Questo documento fornisce istruzioni dettagliate per l'utilizzo del telefono Doro Leva L20, coprendo la panoramica del dispositivo, le procedure di configurazione, le funzioni di chiamata e messaggistica, le impostazioni e le istruzioni di sicurezza.</p> |
| <p>Doro Aurora A30</p>  <p>doro</p> | <p><a href="#">Doro Aurora A30 User Manual</a></p> <p>Comprehensive user manual for the Doro Aurora A30 smartphone, covering setup, features, settings, and safety instructions. Learn how to use your Doro Aurora A30 with this detailed guide.</p>  |

## Documents - Doro – Leva 10



### [\[pdf\] User Manual Instructions Label](#)

Allen® Advance Table Hillrom The symbol on the labels is intended to show when IFU should be referenced for use techniques detailed in this manual are only manufacturer s 80028193LIT hillrom co uk content dam aem us en sap documents LIT 80028 |||

Allen Advance Table Instructions for Use Product Code A-71102-JP 80028193

Version G English LANGUAGES ENGLISH .....

.....1 .....

lang:i-klingon **score:10** filesize: 11.93 M page\_count: 1552 document date: 2023-03-10



[\[pdf\]](#) Catalog

2025 Q2 MOBILE Exellent FR catalogus mobile q2 catalogue Video YouTube Spotify et bien d autres encore Séries documentaires NEST SONNETTE VIDÉO HELLO GONESTHELLOBW Enregistrement en continu jour uni 058639c6554e3eabbc2632edc47605d1 exellent be folders HTML files assets common ||| Votre specialiste, toujours proche CATALOGUES MOBILE 2025 Q2 IP68 GALAXY S25 ULTRA 5G - SUS938B ... C compatible avec les appareils auditifs Batterie 1000 mAh DAS : 1,4 W/kg D 4G 4G 4G DORO **LEVA 10** DOLEVAL10 cran : 2.4 Extensible d une carte MicroSD Camra l arrire : 2 MP Gros bouton...  
lang:es **score:8** filesize: 8.14 M page\_count: 36 document date: 2025-04-14