

Midea MRD20B1AMK

Midea 2L Multi-Functional Rice Cooker User Manual

MODEL: MRD20B1AMK

Introduction

Welcome to your new Midea Multi-Functional Rice Cooker. This appliance is designed to simplify your cooking experience with its versatile functions and user-friendly design. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions carefully before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the power cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors. This appliance is for indoor household use only.
- Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to "off", then remove the plug from the wall outlet.
- Do not use the appliance for other than its intended use.

Product Overview

The Midea Multi-Functional Rice Cooker is equipped with advanced heating technology and a non-stick inner pot, designed for efficient and convenient cooking.

Components Included:

- Inner Pot (Non-stick coated aluminum)
- Instruction Manual (this document)
- Spoon
- Measuring Cup
- Steaming Basket



Image: Front view of the Midea Multi-Functional Rice Cooker, showcasing its sleek design and digital control panel.

Setup

Unpacking:

1. Carefully remove all packaging materials and the rice cooker from the box.
2. Check that all components listed in the "Product Overview" section are present.
3. Dispose of packaging materials responsibly.

Before First Use:

1. Wash the inner pot, steaming basket, spoon, and measuring cup with warm, soapy water. Rinse thoroughly and dry completely.
2. Wipe the exterior of the rice cooker with a damp cloth. Do not immerse the main unit in water.
3. Ensure the power cord is free from damage before plugging in.

Operating Instructions

Control Panel Overview:

The digital display and touch buttons allow for easy selection of cooking functions and settings.



Image: Detailed view of the Midea Rice Cooker's control panel, highlighting the 9 available cooking functions.

Cooking Rice (General Steps):

1. Measure the desired amount of rice using the provided measuring cup. One cup (160ml) of uncooked white rice typically yields 2-3 servings. The 2L capacity can cook up to 4 cups of uncooked white rice.
2. Rinse the rice thoroughly under cold water until the water runs clear.
3. Place the rinsed rice into the inner pot.
4. Add the appropriate amount of water. A common ratio is 1:1 for white rice (1 cup rice to 1 cup water), but adjust according to rice type and preference.
5. Place the inner pot into the rice cooker, ensuring it is seated correctly. Close the lid securely.
6. Plug the power cord into a suitable electrical outlet (220V AC).
7. Select the desired rice cooking function (e.g., "White Rice", "Brown Rice", "Quick Rice") using the "Menu" button.
8. Press "Start" to begin cooking. The cooker will automatically switch to "Keep Warm" mode once cooking

is complete.

Using Specific Functions (9 Functions):

The Midea Rice Cooker offers 9 versatile functions to meet your diverse cooking needs:

- **White Rice:** For perfectly cooked white rice.
- **Brown Rice:** Optimized for brown rice, which typically requires longer cooking times.
- **Porridge:** Ideal for creamy porridge or congee.
- **Grains:** Suitable for cooking various types of grains beyond traditional rice.
- **Mixed:** For preparing mixed rice dishes.
- **Steam:** Use with the included steaming basket for vegetables, dumplings, and more.
- **Soup:** For preparing various soups.
- **Stew:** For slow-cooked stews and tender dishes.
- **Quick Rice:** Cooks white rice in approximately 30 minutes for faster meals.



Image: A family enjoying a meal, illustrating the Midea Rice Cooker's capacity, which is ideal for 1-3 people.

Timer and Keep Warm Function:

The rice cooker features a 24-hour delay timer and an automatic "Keep Warm" function for added convenience.

- **Delay Timer:** Press the "Delay" button after selecting a cooking function to set a delayed start time. This allows you to prepare ingredients in advance and have your meal ready at a specific time.
- **Keep Warm:** After cooking, the appliance automatically switches to "Keep Warm" mode, maintaining the food's temperature without overcooking for up to 24 hours.



Image: The Midea Rice Cooker with an overlay indicating its 24-hour timer function.

Maintenance and Cleaning

General Cleaning:

Regular cleaning ensures the longevity and optimal performance of your rice cooker.

1. Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot:** The non-stick inner pot is easy to clean. Wash it by hand with warm, soapy water and a soft sponge. Do not use abrasive cleaners or metal scouring pads, as this can damage the non-stick coating. Rinse thoroughly and dry.
3. **Steaming Basket, Spoon, Measuring Cup:** Wash these accessories by hand with warm, soapy water.
4. **Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Lid and Steam Vent:** Clean the inside of the lid and the steam vent regularly to prevent blockages and ensure proper steam release. The anti-leakage design helps prevent overflow.



Image: A hand scooping rice from the inner pot (left) and the separate steaming basket accessory (right), illustrating ease of use and cleaning.

Troubleshooting

If you encounter any issues with your Midea Rice Cooker, please refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Rice is too hard/dry	Not enough water; rice not soaked (for some types); lid not closed properly.	Add more water next time; ensure lid is sealed; consider soaking rice for 30 minutes before cooking for certain varieties.
Rice is too soft/mushy	Too much water.	Reduce water amount next time.
Cooker does not turn on	Not plugged in; power outage; faulty outlet.	Check power cord connection; check circuit breaker; try a different electrical outlet.
Overflow during cooking	Too much water/rice; steam vent blocked.	Do not exceed the maximum fill line for rice and water; clean the steam vent regularly. The built-in NTC temperature sensor and intelligent temperature control help prevent overflow.



Image: A visual representation of the rice cooker's steam release and anti-overflow design, ensuring clean and efficient cooking.

Specifications

Brand: Midea

Model Number: MRD20B1AMK

Capacity: 2 Liters (equivalent to 4 cups of uncooked rice)

Color: Black

Voltage: 220 Volts AC

Material: Non-stick coated aluminum (inner pot)

Product Dimensions: 24.8D x 21.7W x 21H centimeters

Special Features: 9 cooking functions (digital display, timer, keep warm, support for various rice types), Anti-leakage cooking, 30-minute Quick Rice.

Included Components: Inner Pot, Instruction Manual, Spoon, Measuring Cup, Steaming Basket

Care Instructions: Hand wash

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Midea website for the most up-to-date information.

Manufacturer: Midea

ASIN: B0DHZBDMP6

Date First Available: September 30, 2024