

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NENEN](#) /

› [NENEN DDS661 Single Phase Digital Energy Meter User Manual](#)

NENEN DDS661

NENEN DDS661 Single Phase Digital Energy Meter User Manual

Model: DDS661 (AC110V 60Hz / AC220V 50Hz)

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your NENEN DDS661 Single Phase Digital Energy Meter. Please read this manual thoroughly before installation and use, and retain it for future reference. This device is designed for measuring active energy consumption in single-phase AC circuits.

SAFETY INFORMATION

- Installation must be performed by qualified personnel only.
- Ensure power is disconnected before installation or maintenance.
- Do not operate the meter if it is damaged.
- Observe all local electrical codes and regulations.
- The meter is designed for indoor use in a dry environment.

PRODUCT OVERVIEW

The NENEN DDS661 is a single-phase digital energy meter designed for DIN rail mounting. It features an LCD backlight display for clear readings of energy consumption (KWh), and is available in AC110V 60Hz and AC220V 50Hz variants. Some models may include RS485 communication capabilities for remote data access.



Figure 1: Front view of the NENEN DDS661 Digital Energy Meter. This image shows the meter's compact design, the LCD screen displaying KWh, and the pulse indicator light. The model number DDS661 is visible at the top of the display area.

With RS485
AC110V/60HZ

AC220V/60HZ



Positive Power Consumption



Reverse Power Consumption



Total Power



Power



Power Factor



Frequency



Voltage



Current

Figure 2: Display modes of the DDS661 meter. This image illustrates the different electrical parameters that can be shown on the LCD, including KWh for positive and reverse consumption, total power, instantaneous power, power factor, frequency, voltage, and current. Some models may feature RS485 communication.

SETUP AND INSTALLATION

The DDS661 energy meter is designed for easy installation on a standard 35mm DIN rail. Ensure the installation location is dry, well-ventilated, and free from excessive vibration or electromagnetic interference.

Installation Steps:

1. **Power Disconnection:** Before beginning any installation, ensure that the main power supply to the circuit where the meter will be installed is completely disconnected and locked out.
2. **Mounting:** Attach the meter securely to a 35mm DIN rail. The meter features a clip mechanism for quick mounting.



Figure 3: Side view illustrating the DIN rail mounting mechanism. This image highlights the blue clip used to secure the meter onto a standard DIN rail.

3. **Wiring:** Connect the input and output wires according to the wiring diagram provided on the meter's casing or in the detailed wiring instructions (not provided in this general manual). Ensure correct phase and neutral connections. The meter supports up to 60A.
4. **Verification:** Double-check all connections for tightness and correctness.
5. **Power Restoration:** Restore power to the circuit. The meter's LCD display should illuminate, indicating proper function.



Figure 4: The DDS661 meter securely installed on a DIN rail. This image demonstrates how the meter appears once properly mounted, ready for electrical connections.

OPERATING INSTRUCTIONS

Display Readings:

The DDS661 meter features an LCD backlight display that cycles through various parameters or can be manually advanced depending on the model. Common display parameters include:

- **KWh:** Total active energy consumption.
- **Voltage (V):** Instantaneous line voltage.
- **Current (A):** Instantaneous line current.
- **Power (W):** Instantaneous active power.
- **Power Factor (PF):** The ratio of real power to apparent power.
- **Frequency (Hz):** The frequency of the AC supply.

The green LED indicator flashes at a rate of 1000 imp/kWh, indicating active energy measurement. A faster flash rate signifies higher power consumption.

RS485 Communication (for DDS661-RS485 models):

For models equipped with RS485, the meter can be integrated into a monitoring system for remote data acquisition. Refer to the specific RS485 communication protocol documentation for details on data registers, baud rates, and addressing.

This functionality allows for convenient management and monitoring of power status.

MAINTENANCE

The NENEN DDS661 energy meter is designed for long-term, maintenance-free operation under normal conditions. Regular checks are recommended:

- **Cleaning:** Keep the meter clean and free from dust. Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.
- **Connection Checks:** Periodically inspect wiring connections to ensure they remain tight and free from corrosion.
- **Environmental Conditions:** Ensure the operating environment remains within specified temperature and humidity ranges.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Meter display is blank.	No power supply; incorrect wiring; internal fault.	Check power supply to the circuit. Verify wiring connections. If power is present and wiring is correct, the meter may be faulty and require replacement.
KWh reading not increasing.	No load connected; incorrect wiring; internal fault.	Ensure a load is connected and drawing power. Verify wiring, especially input/output terminals. If issues persist, the meter may be faulty.
Green LED not flashing.	No power consumption; LED fault.	Confirm that there is active power consumption. If power is being consumed and the LED does not flash, there might be an internal issue.
Inaccurate readings.	Incorrect wiring; external interference; meter calibration issue.	Re-check all wiring connections. Ensure the meter is not exposed to strong electromagnetic fields. If suspected calibration issues, contact support.

For problems not listed here or if solutions do not resolve the issue, please contact NENEN customer support.

SPECIFICATIONS

Parameter	Value
Model	DDS661 / DDS661-RS485
Rated Voltage	AC110V (60Hz) or AC220V (50Hz/60Hz)
Rated Current	5(60)A
Display	LCD Backlight Digital Display
Pulse Frequency	1000 imp/kWh
Installation	35mm DIN Rail

Parameter	Value
Material	Engineering Plastic
Item Weight	Approximately 1.32 pounds (0.6 kg)
Package Dimensions	Approximately 1.18 x 0.79 x 0.39 inches (3 x 2 x 1 cm)

WARRANTY AND SUPPORT

NENEN products are manufactured to high-quality standards. For warranty information, please refer to the documentation included with your purchase or visit the official NENEN website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact NENEN customer service through the retailer where the product was purchased or via the contact information provided on the NENEN official website.

Note: Specific warranty terms may vary by region and retailer.

