

## Xiaomi 58437

# Xiaomi Multifunctional Rice Cooker 4L

Model: 58437

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and retain them for future reference. Improper use may result in serious injury or damage to the appliance.

- Do not immerse the main unit, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Always unplug the appliance from the power outlet when not in use, before cleaning, or if a malfunction occurs.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Place the rice cooker on a stable, level, heat-resistant surface, away from direct sunlight or heat sources.
- Do not cover the steam vent during operation, as this can cause excessive pressure buildup.
- Be cautious of hot steam escaping from the vent during and after cooking.
- Only use accessories recommended by the manufacturer.

## 2. PRODUCT OVERVIEW

The Xiaomi Multifunctional Rice Cooker is designed for efficient and versatile cooking, featuring a 4-liter capacity and multiple cooking modes.

### Components:

- Main Unit with Control Panel
- Inner Pot (6-layer non-stick)
- Steam Basket

- Measuring Cup
- Rice Paddle



Image: Side view of the Xiaomi Multifunctional Rice Cooker, showcasing its compact design and the Xiaomi logo on the front.



Image: Top view of the rice cooker, highlighting the digital display and touch control buttons for various cooking functions.

### 3. SETUP AND FIRST USE

#### 3.1 Unpacking

- Carefully remove all packaging materials and accessories.
- Check that all components listed in Section 2 are present and undamaged.

#### 3.2 Initial Cleaning

- Wash the inner pot, steam basket, measuring cup, and rice paddle with warm, soapy water. Rinse thoroughly and dry completely.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners.

#### 3.3 Placement

- Place the rice cooker on a flat, stable, and heat-resistant surface.
- Ensure there is adequate ventilation around the appliance, especially near the steam vent.
- Keep it away from walls, cabinets, and other appliances to allow steam to escape freely.

### **3.4 Power Connection**

- Plug the power cord into a grounded electrical outlet. The display will light up, indicating the appliance is ready for use.

## **4. OPERATING INSTRUCTIONS**

---

### **4.1 Basic Rice Cooking**

1. Measure the desired amount of rice using the provided measuring cup. One cup typically yields two bowls of cooked rice.
2. Wash the rice thoroughly under running water until the water runs clear.
3. Place the washed rice into the inner pot.
4. Add water according to the markings inside the inner pot, corresponding to the number of rice cups. For example, if you added 2 cups of rice, fill water to the '2' mark. Adjust water level based on desired rice consistency.
5. Place the inner pot into the main unit, ensuring it is seated correctly. Close the lid firmly.
6. Select the desired cooking mode (e.g., 'Rice' or 'Quick Rice') using the 'Select' button. The default cooking time will be displayed.
7. Press the 'Start' button to begin cooking. The indicator light will illuminate.
8. Once cooking is complete, the appliance will beep and automatically switch to 'Keep Warm' mode.
9. Allow the rice to rest for 10-15 minutes in 'Keep Warm' mode before serving for best results.



Image: A person serving freshly cooked rice from the Xiaomi Multifunctional Rice Cooker into a bowl, demonstrating its ease of use.

## 4.2 Cooking Modes

The rice cooker offers 10 versatile cooking modes:

- **Rice:** Standard cooking for various types of rice.
- **Quick Rice:** Faster cooking cycle for when you need rice quickly (approx. 30 minutes).
- **Keep Warm:** Automatically activated after cooking to maintain food temperature for up to 12 hours.
- **Congee:** For preparing porridge or congee.
- **Soup:** Ideal for simmering soups and broths.
- **Steam:** Use with the steam basket for steaming vegetables, dumplings, or other foods.
- **Mixed Congee:** For congee with mixed grains.
- **Multigrain Rice:** Optimized for cooking various multigrain rice types.
- **Reheat:** To warm up previously cooked food.

## 4.3 Timer Function

The 24-hour timer allows you to set a delayed start time for cooking.

1. Prepare ingredients in the inner pot as usual.
2. Select the desired cooking mode.
3. Press the 'Timer' button. Use the '+' and '-' buttons to adjust the desired delay time (up to 24 hours).
4. Press 'Start' to confirm. The appliance will begin cooking automatically after the set delay.

## 5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your rice cooker.

### 5.1 Cleaning the Inner Pot

- Allow the inner pot to cool completely before cleaning.
- Wash the inner pot with warm, soapy water using a soft sponge or cloth. The non-stick coating is delicate; avoid abrasive scrubbers or metal utensils.
- Rinse thoroughly and dry completely before storing or reusing.



Image: A person rinsing the non-stick inner pot under a faucet, demonstrating the ease of cleaning.

### 5.2 Cleaning the Lid and Steam Vent

- The inner lid is removable for easy cleaning. Gently pull it off.
- Wash the inner lid and steam vent components with warm, soapy water.
- Ensure all food residues are removed from the steam vent to prevent blockages.
- Rinse and dry thoroughly before reattaching.

### 5.3 Cleaning the Exterior

- Wipe the exterior of the main unit with a soft, damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or immerse the main unit in water.

### 5.4 Storage

- Ensure the appliance is clean and dry before storing.
- Store in a cool, dry place, away from direct sunlight and moisture.

## 6. TROUBLESHOOTING

If you encounter issues with your rice cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard/dry	Insufficient water; lid not closed properly; 'Quick Rice' mode used for large quantity.	Add more water next time; ensure lid is sealed; use 'Rice' mode for larger batches.
Rice is too soft/mushy	Too much water; rice not washed properly.	Reduce water next time; wash rice thoroughly until water is clear.
Rice sticks to the bottom	Not enough water; inner pot not clean; non-stick coating damaged.	Ensure proper water ratio; clean inner pot thoroughly; avoid metal utensils.
Appliance does not turn on	Not plugged in; power outage; faulty outlet.	Check power connection; test outlet with another appliance; contact support if issue persists.
Steam leaking from lid	Lid not closed properly; seal ring dirty or damaged.	Ensure lid is firmly closed; clean or replace seal ring if necessary.

If the problem persists after trying these solutions, please contact Xiaomi customer support.

## 7. SPECIFICATIONS

- **Brand:** Xiaomi
- **Model Number:** 58437
- **Capacity:** 4 Liters
- **Power:** 960 Watts
- **Voltage:** 230 Volts
- **Material:** Plastic
- **Product Dimensions:** 36.8 x 31.8 x 26.4 cm
- **Item Weight:** 3.4 Kilograms
- **Additional Features:** Timer, Alarm, Automatic Cooking, Automatic Shut-off, Non-stick Inner Pot

## 8. WARRANTY AND SUPPORT

This Xiaomi product comes with a standard manufacturer's warranty. For detailed warranty information, terms, and conditions, please refer to the warranty card included with your purchase or visit the official Xiaomi website.

For technical support, service, or spare parts, please contact Xiaomi customer service through their official channels or visit their support page online.

Official Xiaomi Website: [www.mi.com/global/support](http://www.mi.com/global/support)

---

© 2025 Xiaomi. All rights reserved.