

EASYERA AC-SCE60A

EASYERA Sunrise Alarm Clock Sound Machine User Manual

Model: AC-SCE60A

1. PRODUCT OVERVIEW

The EASYERA Sunrise Alarm Clock Sound Machine is an all-in-one sleep solution designed to enhance your waking and sleeping experience. It combines a sunrise simulation alarm clock, a sound machine with 26 soothing sounds, a dimmable night light with 17 colors, and a Bluetooth speaker.

Key features include:

- **Sunrise Simulation:** Gradually brightens to gently wake you up.
- **26 Soothing Sounds:** A variety of white noise and nature sounds for relaxation and sleep.
- **Dimmable Night Light:** 17 color options with adjustable brightness for a personalized ambiance.
- **Bluetooth Speaker:** Connect your device to play music or other audio.
- **Backlit Buttons:** Easy to operate even in low light conditions.
- **Snooze Function:** Tap the snooze knob for extra minutes of sleep.



Figure 1: Front view of the EASYERA Sunrise Alarm Clock, showcasing its vibrant light and digital display.

All-in-One Sleep Solution



Sleep Sound
Machine



Sunrise
Alarm Clock



Night Light



Bluetooth
Speaker



Figure 2: The alarm clock serving as an all-in-one sleep solution: sound machine, sunrise alarm, night light, and Bluetooth speaker.

2. SETUP GUIDE

2.1 Unboxing and Initial Placement

Carefully remove the Sunrise Alarm Clock from its packaging. Place the device on a stable, flat surface, such as a bedside table, away from direct sunlight or heat sources. Ensure adequate ventilation around the unit.

2.2 Power Connection

Connect the provided USB cable to the power input port on the back of the alarm clock. Plug the other end of the USB cable into the included power adapter, and then plug the adapter into a standard wall outlet. The display will light up, indicating the device is powered on.

The unit requires 1 CR2032 battery (not included) for backup power to retain time settings during power outages.

2.3 Setting the Time

To set the current time:

1. Press the **"Time Set"** button (usually located on the side or back).
2. Use the **"+"** and **"-"** buttons (or the rotary knob) to adjust the hour. Press **"Time Set"** again to confirm.
3. Repeat the process to set the minutes.
4. Some models may offer 12/24-hour format selection. Refer to the specific button for this setting.

The clock's time may automatically calibrate after Bluetooth connection with a paired device, as noted in some user experiences.

3. OPERATING INSTRUCTIONS

3.1 Setting an Alarm

The alarm clock supports multiple alarm settings (e.g., everyday, weekdays, weekends). To set an alarm:

1. Press the **"Alarm"** button (often indicated by a bell icon).
2. Use the **"+"** and **"-"** buttons (or rotary knob) to set the desired alarm time (hour and minute).
3. Select your preferred alarm sound from the available 26 options (nature sounds, white noise, melodies).
4. Adjust the alarm volume using the volume controls.
5. Choose the light intensity and color for the sunrise simulation.
6. Confirm the alarm setting by pressing the **"Alarm"** button again or waiting for the display to revert.

To snooze, tap the snooze knob on top of the device. This typically provides an additional 8-9 minutes of sleep. To turn off the alarm completely, locate and press the designated alarm off button (not the snooze button).



Figure 3: Visual representation of the sunrise simulation, gradually brightening from 7:30 to 8:00 AM.

Your browser does not support the video tag.

Video 1: A demonstration of the alarm clock's light features, including color changes and brightness adjustments.

3.2 Sound Machine Functions

The device offers 26 soothing sounds, including 15 natural sounds and 11 white noise options, to aid in sleep and relaxation.

- Press the **"Sound"** button (often indicated by a music note or wave icon) to cycle through available sounds.
- Adjust the volume using the dedicated volume controls.
- Set a sleep timer (10-480 minutes) to automatically turn off sounds and lights after a set duration.



Figure 4: An overview of the 26 available sleep sounds, categorized into natural sounds and white noise.

Your browser does not support the video tag.

Video 2: A user demonstrating the sound machine features and various light settings of the alarm clock.

3.3 Night Light and Ambient Lighting

The alarm clock features a dimmable night light with 17 color options (8 solid, 9 RGB). You can adjust the brightness to your preference.

- Press the "**Light**" or "**RGB**" button to activate and cycle through light modes and colors.
- Use the dimmer control (often a rotary knob or dedicated buttons) to adjust brightness levels.

17 Colors Dimmable Night Light



8 Solid Lights



9 RGB Lights



Figure 5: The alarm clock showcasing its range of 17 dimmable night light colors, including solid and RGB options.

3.4 Bluetooth Speaker

The device features Bluetooth 5.3 for wireless audio streaming.

- Press the **"Bluetooth"** or **"BT"** button to enter pairing mode.
- On your smartphone or other Bluetooth-enabled device, search for **"EASYERA"** (or similar name) in the Bluetooth settings and connect.
- Once paired, you can play music or other audio through the alarm clock's speaker.



Figure 6: The alarm clock functioning as a Bluetooth 5.3 speaker, compatible with various devices for music playback.

4. MAINTENANCE

- To clean the device, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the device away from water and high humidity.
- Ensure the device is unplugged before cleaning or if it will not be used for an extended period.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Not properly connected to power source.	Ensure the power adapter is securely plugged into both the device and a working wall outlet.
Alarm does not sound or light up.	Alarm not activated or set incorrectly.	Verify alarm settings (time, sound, light, active status). Ensure volume is not set to zero.
Bluetooth connection issues.	Device not in pairing mode; too far from source; interference.	Ensure the alarm clock is in Bluetooth pairing mode. Move the devices closer. Disconnect from other Bluetooth devices.
Time display is too bright/dim.	Brightness setting needs adjustment.	Use the dimmer control to adjust the display brightness to your preference.
Sound quality is poor.	Volume too high; audio source issue.	Adjust the volume. If using Bluetooth, check the volume on your connected device. Ensure the audio source is of good quality.

6. SPECIFICATIONS

Feature	Detail
Brand	EASYERA
Model Number	AC-SCE60A
Color	White
Product Dimensions	7.48"W x 6.97"H
Item Weight	1.28 pounds (0.58 Kilograms)
Power Source	Battery Powered (1 CR2032 required for backup)
Display Type	Digital (imitation)
Special Feature	Ambient Light, Sunrise Simulation, Sound Machine, Bluetooth Speaker
Number of Soothing Sounds	26
Night Light Colors	17 (8 solid, 9 RGB)
Bluetooth Version	5.3
UPC	810089906489

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your product packaging or visit the official EASYERA website. Keep your purchase receipt for any warranty claims.

If you encounter any issues not covered in this manual, please contact EASYERA customer service for assistance.

© 2025 EASYERA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question