

[Manuals.plus](#) /

› [NORTHCLAN](#) /

› NORTHCLAN GS-328L 800W Centrifugal Juicer Machine Instruction Manual

NORTHCLAN GS-328L

NORTHCLAN GS-328L 800W Centrifugal Juicer Machine Instruction Manual

Model: GS-328L

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your NORTHCLAN GS-328L 800W Centrifugal Juicer Machine. Please read this manual thoroughly before first use and retain it for future reference.



Figure 1: The NORTHCLAN GS-328L Centrifugal Juicer Machine. This image displays the complete juicer unit, including the motor base, juicing assembly, and a collection pitcher filled with green juice. Various fresh fruits such as apples, oranges, grapefruit, and grapes are arranged around the base, illustrating the machine's purpose.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the juicer.
- Ensure the appliance is unplugged from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Always use the food pusher provided.
- The juicer is equipped with a safety locking arm. Ensure the cover is firmly in place and the locking arm is secured

before operating. The appliance will not operate if the locking arm is not correctly engaged.

- An overload protection system automatically shuts down the motor if the temperature exceeds 105 degrees Celsius (221 degrees Fahrenheit). Allow the unit to cool down before resuming operation.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your NORTHCLAN GS-328L Centrifugal Juicer:

- Food Pusher
- Transparent Cover
- Filter Basket (Stainless Steel)
- Juice Collector
- Motor Base with Control Dial
- Safety Locking Arm
- Pulp Container
- Juice Pitcher (1100ml/37oz) with Foam Filter

4. SETUP AND ASSEMBLY

Before first use, wash all removable parts (food pusher, transparent cover, filter basket, juice collector, pulp container, juice pitcher) in warm, soapy water. Rinse thoroughly and dry.

1. Place the motor base on a dry, flat, and stable surface.
2. Position the juice collector onto the motor base, ensuring it is seated correctly.
3. Insert the stainless steel filter basket firmly into the juice collector. Ensure it clicks into place.
4. Place the transparent cover over the filter basket and juice collector.
5. Lift the safety locking arm and secure it into the grooves on the transparent cover. The juicer will not operate unless the locking arm is properly engaged.
6. Place the pulp container under the pulp spout and the juice pitcher under the juice spout.



Figure 2: Installation and Spout Functionality. This image illustrates how to correctly install the juice spout by pushing it in. It also demonstrates the "Making Juice" position where the spout is rotated left to allow juice flow, and the "Anti-drip Function" position where the spout is rotated right to prevent dripping.

5. OPERATING INSTRUCTIONS

5.1. Preparing Fruits and Vegetables

- Wash all fruits and vegetables thoroughly.
- For larger items, cut them into pieces that fit comfortably into the 3-inch wide feed chute. The wide chute can accommodate whole apples or peeled oranges, reducing prep time.
- Remove hard pits from fruits like peaches, cherries, or plums.
- Remove thick, inedible peels from fruits such as oranges, pineapples, and melons.

5.2. Speed Settings

The NORTHCLAN GS-328L features two speed settings for optimal juicing performance:

- **"I" Low Speed (13000-17000 RPM):** Ideal for soft fruits and vegetables such as oranges, grapes, strawberries, and cucumbers.
- **"II" High Speed (17000-21000 RPM):** Suitable for harder produce like apples, carrots, celery, and ginger.

Select the appropriate speed using the control dial on the motor base to maximize juice yield and efficiency.

JUICER MACHINE

TWO-SPEED MODES



**"I" low speed for soft
(12000rpm-15000rpm)**

like strawberry, cucumber, orange



**II" fast speed for hard
(16000rpm-18000rpm)**

like carrot, celery, apple, ginger



Figure 3: Two-Speed Modes. This image displays the control dial with settings "0", "I", and "II". It visually indicates that "I" (low speed) is for soft items like strawberries, cucumbers, and oranges, while "II" (fast speed) is for hard items such as carrots, celery, apples, and ginger.

5.3. Juicing Process

1. Ensure the juicer is properly assembled and the safety locking arm is secured.

2. Plug the power cord into a suitable electrical outlet.
3. Turn the control dial to the desired speed setting ("I" or "II").
4. Gradually feed the prepared fruits and vegetables into the feed chute using the food pusher. Do not force the produce down; allow the juicer to process it at its own pace.
5. Fresh juice will flow into the juice pitcher, and pulp will collect in the pulp container. The built-in foam filter in the juice pitcher helps to separate foam for a smoother juice.
6. When finished juicing, turn the control dial to "0" (off) and unplug the appliance.

5.4. Anti-Drip Function

To prevent drips after juicing, rotate the juice spout to the right (as shown in Figure 2) to close the opening. Rotate it to the left to allow juice to flow.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your juicer.

1. Always unplug the juicer before cleaning.
2. Disassemble the juicer by reversing the assembly steps.
3. Rinse all removable parts (food pusher, transparent cover, filter basket, juice collector, pulp container, juice pitcher) under running water immediately after use to prevent pulp from drying.
4. Most removable parts are dishwasher safe. For manual cleaning, use warm, soapy water and a non-abrasive brush for the filter basket to remove any pulp residue.
5. Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
6. Ensure all parts are completely dry before reassembling or storing the juicer.



Figure 4: Juicer Filter and Blades. This image provides a detailed view of the stainless steel filter basket and its sharp blades, highlighting the design intended for high juice yield and minimal pulp residue. The image also shows examples of juice yield percentages for various fruits.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in. Safety locking arm not engaged. Overload protection activated.	Ensure the power cord is securely plugged into a working outlet. Check that the safety locking arm is firmly secured in place. Unplug the unit and allow it to cool for at least 30 minutes before restarting.
Low juice yield or excessive pulp.	Incorrect speed setting for produce type. Filter basket clogged. Feeding produce too quickly.	Use "I" speed for soft produce and "II" speed for hard produce. Clean the filter basket thoroughly. Feed produce slowly and steadily.
Vibration or loud noise during operation.	Improper assembly. Excessive load.	Disassemble and reassemble the juicer, ensuring all parts are correctly seated. Reduce the amount of produce being fed at one time.

8. SPECIFICATIONS

Brand	NORTHCLAN
Model Name	GS-328L
Power	800W
Voltage	120 Volts
Speed Settings	"I" Low Speed: 13000-17000 RPM "II" High Speed: 17000-21000 RPM
Feed Chute Size	3 inches (wide)
Juice Pitcher Capacity	1100ml / 37oz
Product Dimensions	16.25"D x 12.25"W x 8.52"H
Item Weight	9.54 pounds
Special Feature	Easy to Clean
Dishwasher Safe Parts	Yes (removable parts)
UPC	696168472522

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation included with your purchase or visit the official NORTHCLAN store online.
Official NORTHCLAN Store: [NORTHCLAN Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question