

[Manuals.plus](#) /

> [CIYODO](#) /

> CIYODO Hand Dehydrator Manual Squeezer User Manual

CIYODO T4NI6D0744IJNV29XBPM9Q2M

CIYODO Hand Dehydrator Manual Squeezer User Manual

Model: T4NI6D0744IJNV29XBPM9Q2M

INTRODUCTION

Thank you for choosing the CIYODO Hand Dehydrator Manual Squeezer. This efficient kitchen tool is designed to help you easily remove excess water from fruits, vegetables, and other ingredients, making it ideal for preparing dumpling fillings, salads, and more. Its manual operation requires no electricity, offering a simple and convenient solution for your food preparation needs.

SAFETY INFORMATION

Please read all safety instructions before using the product to ensure safe and proper operation.

- Keep out of reach of children. This product is not a toy.
- Use only for its intended purpose of dehydrating food ingredients.
- Do not use with excessively hot ingredients, as this may damage the plastic material.
- Avoid using abrasive cleaners or sharp objects that could scratch or damage the surface.
- Ensure all parts are clean and dry before storage.

PRODUCT OVERVIEW

The CIYODO Hand Dehydrator consists of several key components designed for effective water removal.



Image: The main components of the CIYODO Hand Dehydrator, including the outer basket, inner press, and collection base.

- **Outer Basket:** The main container with drainage holes where ingredients are placed.
- **Inner Press:** The component used to press down on the ingredients, forcing out liquid.
- **Collection Base:** The bottom part that collects the squeezed liquid.

SETUP

Before first use, ensure all parts are clean. Follow these steps to set up your dehydrator:

1. Unpack all components from the packaging.
2. Wash all parts (outer basket, inner press, collection base) with warm soapy water.
3. Rinse thoroughly with clean water and allow to air dry completely or dry with a clean cloth.
4. Place the outer basket securely onto the collection base.
5. The dehydrator is now ready for use.



Image: The Hand Dehydrator assembled and ready for use, showing the outer basket placed on the collection base.

OPERATING INSTRUCTIONS

This manual squeezer is designed for efficient water removal from various ingredients.

Preparing Vegetables for Dumpling Fillings

1. Chop or grate your vegetables (e.g., cabbage, carrots, zucchini) into small pieces suitable for dumpling filling.
2. Place the chopped vegetables into the outer basket of the dehydrator. Do not overfill; ensure there is space for the

inner press.

3. Insert the inner press into the outer basket, positioning it directly on top of the vegetables.
4. Apply firm, steady downward pressure on the inner press. You will see liquid begin to drain into the collection base.
5. Continue pressing until the desired amount of liquid has been removed.
6. Remove the inner press and the outer basket. Discard the collected liquid from the base.
7. The dehydrated vegetables are now ready to be mixed into your dumpling filling.



Image: The Hand Dehydrator in action, showing a hand pressing down on the inner component to extract liquid from chopped vegetables.



Image: The collection base of the dehydrator, showing the liquid that has been successfully squeezed out from the vegetables.

General Use for Fruits and Other Ingredients

- This dehydrator can also be used for other soft fruits or vegetables where excess moisture needs to be removed.
- Ensure ingredients are cut into small enough pieces to fit and be effectively pressed.
- Follow the same pressing procedure as described above.

MAINTENANCE AND CARE

Proper cleaning and maintenance will extend the life of your CIYODO Hand Dehydrator.

- **After Each Use:** Disassemble all parts. Wash immediately with warm water and a mild dish soap.
- **Rinsing:** Rinse all components thoroughly to remove any soap residue.
- **Drying:** Allow all parts to air dry completely before reassembling or storing. This prevents water spots and bacterial growth.

- **Storage:** Store the dehydrator in a clean, dry place away from direct sunlight and extreme temperatures.
- **Do Not Use:** Avoid using abrasive sponges, steel wool, or harsh chemical cleaners, as these can damage the plastic.

TROUBLESHOOTING

If you encounter any issues with your dehydrator, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Liquid not draining effectively.	Ingredients are too large or too tightly packed. Insufficient pressure applied.	Chop ingredients into smaller pieces. Do not overfill the basket. Apply more firm and steady pressure.
Dehydrator feels unstable during use.	Not placed on a flat, stable surface.	Ensure the dehydrator is placed on a flat, non-slip surface before use.
Difficulty cleaning small holes.	Food particles stuck in drainage holes.	Rinse immediately after use. Use a small brush (e.g., bottle brush or toothbrush) to dislodge stubborn particles.

SPECIFICATIONS

Key technical specifications for the CIYODO Hand Dehydrator Manual Squeezer.

Feature	Detail
Product Dimensions	6.3 x 4.92 x 6.3 inches (16 x 12.5 x 16 cm)
Item Weight	7.4 ounces (approx. 209 grams)
Material	Food Grade PP (Polypropylene)
Color	Green
Model Number	T4NI6D0744IJNV29XBPM9Q2M
Country of Origin	China

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your CIYODO Hand Dehydrator, please refer to the retailer's return policy or contact the seller directly through the platform where the purchase was made.

You can also visit the official CIYODO Store on Amazon for more information and products: [CIYODO Store](#).



