

[Manuals.plus](#) /

› [X-PRO](#) /

› X-PRO Ranger 150 Go Kart User Manual: Assembly, Operation, and Maintenance

X-PRO Ranger 150

X-PRO Ranger 150 Go Kart User Manual

Model: Ranger 150 (B0DKMQ9RC1)

1. INTRODUCTION

Welcome to the X-PRO Ranger 150 Go Kart user manual. This document provides essential information for the safe and effective use of your new go kart. Please read this manual thoroughly before assembly, operation, or maintenance to ensure proper handling and to maximize the lifespan of your product.

The X-PRO Ranger 150 is designed for recreational use, featuring a 140cc engine, 3-speed semi-automatic transmission with reverse, 18-inch aluminum rim wheels, LED headlights, a windshield, and a spare tire.



Figure 1.1: Front-side view of the X-PRO Ranger 150 Go Kart.

2. SAFETY INFORMATION

Your safety is paramount. Always adhere to the following safety guidelines:

- Always wear appropriate safety gear, including a helmet, eye protection, gloves, and sturdy footwear.
- Ensure all riders meet the manufacturer's recommended age of 12-18 years.
- Operate the go kart only in designated areas and away from public roads.
- Perform pre-ride inspections, checking tire pressure, brake function, and fluid levels.
- Never operate the go kart under the influence of alcohol or drugs.
- This go kart cannot be sold or operated in California due to specific regulations.
- Regularly inspect and tighten all bolts and fasteners, especially those related to the engine mount and exhaust system, to prevent components from loosening during operation.

3. SETUP AND ASSEMBLY

The X-PRO Ranger 150 Go Kart requires some assembly upon delivery. It is recommended that assembly be performed by individuals with mechanical aptitude or under professional supervision.

3.1 Unpacking

Your go kart will arrive securely packaged in a metal crate and cardboard box. Carefully remove all packaging materials.



Figure 3.1: Go Kart as received in its shipping crate, showing wheels and main body.



Figure 3.2: The outer cardboard packaging for the X-PRO Ranger 150 Go Kart.

3.2 Assembly Steps

Key components requiring assembly include:

1. **Wheels:** Install all four wheels. Ensure lug nuts are tightened to the manufacturer's specifications.
2. **Rear Shock:** Attach the rear shock absorber.
3. **Gas Tank:** Securely mount the main gas tank and the spare fuel tank.
4. **Roll Cage Bars:** Assemble and fasten the roll cage bars for occupant protection.
5. **Steering Wheel:** Install the steering wheel onto the steering column.
6. **Seats:** Mount the seats securely.
7. **Gas Lines:** Connect all necessary gas lines, ensuring no kinks or leaks.
8. **Battery:** Install and connect the battery.
9. **Windshield and Rearview Mirrors:** Attach the transparent plastic windshield and the full-round rearview mirrors.
10. **Spare Tire:** Mount the spare tire in its designated location.

Note: Specific assembly procedures may vary slightly by model. Refer to any included supplementary diagrams or instructions for detailed steps. After assembly, double-check all connections and fasteners for tightness.

4. OPERATING INSTRUCTIONS

4.1 Pre-Operation Checklist

- Verify fuel level in the main tank and spare tank.
- Check engine oil level.
- Inspect tire pressure and condition.
- Test brake functionality.
- Ensure all lights (LED headlights) are operational.
- Confirm all fasteners, especially on the muffler and engine mount, are tight.
- Adjust seats and mirrors for optimal visibility and comfort.

4.2 Starting the Engine

1. Ensure the go kart is on a level surface.
2. Turn the ignition key to the "ON" position.
3. Apply the brake.
4. Press the start button. If the engine does not start immediately, release the button and try again after a few seconds.
5. Allow the engine to warm up for a short period before driving.

4.3 Transmission Operation

The X-PRO Ranger 150 features a 3-speed semi-automatic transmission with reverse.

- **Shifting:** To shift gears, release the throttle and use the gear selector. There is no clutch lever to operate manually.
- **Reverse:** Engage reverse gear only when the go kart is completely stopped.
- **Engine Placement:** The engine is located under the seat, contributing to stability and providing direct power to the rear axle for enhanced tension and power.

4.4 Driving

- Always maintain a safe speed appropriate for the terrain and conditions.
- Avoid sharp turns at high speeds.
- Be aware of your surroundings and potential obstacles.
- The 18-inch aluminum rim wheels provide improved performance and durability over various terrains.

5. MAINTENANCE

Regular maintenance is crucial for the longevity and safe operation of your X-PRO Ranger 150 Go Kart.

5.1 Routine Checks

- **Fluid Levels:** Regularly check and top up engine oil, brake fluid, and fuel.
- **Tire Pressure:** Maintain recommended tire pressure for optimal handling and tire life.
- **Brakes:** Inspect brake pads and discs for wear. Ensure brake lines are intact and free of leaks.
- **Chain/Drive System:** Lubricate and adjust the drive chain as needed.
- **Fasteners:** Critically, regularly inspect and tighten all nuts and bolts, especially those securing the muffler and engine mounts. Vibrations during operation can cause these to loosen, potentially leading to component failure. Consider using thread-locking compounds on critical fasteners.
- **Air Filter:** Clean or replace the air filter periodically, especially when operating in dusty conditions.
- **Battery:** Check battery terminals for corrosion and ensure proper charge.

5.2 Cleaning and Storage

- Clean the go kart after each use to remove dirt and debris. Avoid high-pressure washing directly on electrical components.
- Store the go kart in a dry, protected area when not in use.
- For extended storage, ensure the fuel tank is full with stabilized fuel or drained, and the battery is disconnected and stored in a cool, dry place.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your X-PRO Ranger 150 Go Kart.

Problem	Possible Cause	Solution
Engine does not start	No fuel Dead battery Spark plug issue Kill switch engaged	Check fuel level and add fuel Charge or replace battery Inspect and clean/replace spark plug Disengage kill switch
Loss of power during operation	Low fuel Clogged fuel filter Dirty air filter	Refuel Inspect and clean/replace fuel filter Clean or replace air filter
Unusual noises or vibrations	Loose fasteners (e.g., muffler, engine mount) Worn bearings Damaged drive chain	Inspect and tighten all fasteners. Apply thread-locker if necessary. Inspect and replace worn bearings. Inspect and replace damaged drive chain.
Brakes not effective	Worn brake pads/discs Low brake fluid Air in brake lines	Inspect and replace brake components. Top up brake fluid. Bleed brake lines.

If you encounter issues not listed here or are unable to resolve a problem, please contact X-PRO customer support.

7. SPECIFICATIONS

Feature	Detail
Model	Ranger 150
Engine Displacement	140cc
Transmission	3-Speed Semi-Automatic with Reverse
Wheels	18" Aluminium Rim Wheels
Headlights	LED
Additional Features	Windshield, Spare Tire, Spare Fuel Tank
Product Dimensions (L x W x H)	76.5 x 43.3 x 28.3 inches
Item Weight	364 pounds
Recommended Age	12 - 18 years
ASIN	B0DKMQ9RC1

8. CUSTOMER SUPPORT

For technical assistance, parts inquiries, or any questions regarding your X-PRO Ranger 150 Go Kart, please contact X-PRO customer support.

You can typically find contact information on the X-PRO official website or through your purchase platform. X-PRO is committed to providing reliable support and has a stock of parts for most vehicles sold.

Online Resources: Visit the [X-PRO Store on Amazon](#) for additional product information and support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question