



[Manuals.plus](#) /

> [Sinaopus](#) /

> Sinaopus Air Fryer XL Dual Chamber 9L - Instruction Manual

## Sinaopus Air Fryer-901 SP-9L

# Sinaopus Air Fryer XL Dual Chamber 9L Instruction Manual

Model: Air Fryer-901 SP-9L

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read this manual thoroughly before operating the appliance and keep it for future reference. Improper use may result in property damage or personal injury.

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep children and pets away from the appliance during operation.
- Do not block any air vents. Ensure adequate space around the appliance for proper ventilation.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- The appliance operates at high temperatures. Use oven mitts when handling hot components.
- This appliance is for household use only.

## 2. PRODUCT OVERVIEW

---

The Sinaopus Air Fryer XL is designed for healthy cooking, utilizing hot air circulation to prepare a variety of meals with significantly less oil. It features a dual-chamber design, allowing you to cook two different foods simultaneously.

### Key Features:

- **Dual Chamber Design:** Prepare two distinct dishes at different temperatures and times concurrently.
- **Digital Control:** Precise temperature and time adjustments via an intuitive LED touch screen.
- **Transparent Window:** Monitor cooking progress without opening the baskets, preserving heat.
- **Healthy Frying:** Reduces fat usage by up to 80% compared to traditional deep frying.
- **Easy Cleaning:** Removable, non-stick baskets and interior walls for hassle-free maintenance.
- **Compact Design:** Space-saving footprint suitable for any kitchen countertop.



Figure 2.1: Front view of the Sinaopus Air Fryer XL, showcasing its dual baskets and integrated digital control panel.



Figure 2.2: The dual-chamber air fryer in operation, cooking chicken in one basket and fries in the other, demonstrating simultaneous cooking capabilities.



Figure 2.3: A family preparing food in a kitchen, with the Sinaopus Air Fryer XL visible on the countertop, highlighting its integration into daily cooking.

## 3. SETUP

---

1. **Unpacking:** Carefully remove all packaging materials and any promotional stickers or labels from the appliance.
2. **Initial Cleaning:** Before first use, wash the removable baskets and crisper plates with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the appliance with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance for proper air circulation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of your appliance.
5. **Pre-heating (Optional):** For best results, pre-heat the empty air fryer for 3-5 minutes at 180°C (350°F) to burn off any manufacturing residues. A slight odor may be present during this initial use; this is normal.

## 4. OPERATING INSTRUCTIONS

---

### Basic Operation:

1. **Prepare Food:** Place your ingredients into the air fryer baskets. Do not overfill. For best results, ensure food is in a single layer or shaken periodically.
2. **Insert Baskets:** Slide the baskets firmly into the appliance until they click into place.
3. **Power On:** Press the power button on the LED touch screen.
4. **Select Basket:** If using both baskets, select 'Basket 1' or 'Basket 2' on the control panel to set its specific cooking parameters.
5. **Set Temperature and Time:** Use the temperature and time control buttons to adjust to your desired settings. The temperature range is typically 80°C to 200°C (175°F to 400°F) and time up to 60 minutes.
6. **Start Cooking:** Press the start/pause button to begin the cooking cycle.
7. **Shake/Flip (Optional):** For even cooking, some foods may require shaking or flipping halfway through the cooking time. The appliance may beep to remind you. Carefully remove the basket, shake/flip, and reinsert.
8. **Monitor Progress:** Utilize the transparent window to observe cooking without interrupting the process.
9. **Finish Cooking:** The appliance will beep when the cooking time is complete. Carefully remove the baskets and transfer food to a serving dish.

### Using Preset Programs:

The air fryer comes with 10 pre-programmed settings for common dishes, simplifying your cooking experience.



Figure 4.1: The control panel displaying 10 preset programs for various food types, allowing for one-touch cooking.

1. Follow steps 1-3 from Basic Operation.
2. Select the desired preset icon on the touch screen. The appliance will automatically set the optimal temperature and time for that food type.
3. Press the start/pause button to begin.

### Dual Zone Cooking:

The dual-chamber design allows for synchronized cooking of two different foods.



Figure 4.2: The air fryer's dual baskets cooking different items, with individual temperature and time settings displayed for each zone.

1. Place different foods in each basket.
2. Select 'Basket 1' and set its temperature and time.
3. Select 'Basket 2' and set its temperature and time.
4. Use the 'SYNC' function (if available on your model) to ensure both baskets finish cooking at the same time, or manually adjust start times.
5. Press the start/pause button to begin cooking.

## 5. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.



Figure 5.1: A hand washing an air fryer basket, demonstrating the ease of cleaning the non-stick components.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Clean Baskets and Crisper Plates:** Wash the removable baskets and crisper plates with warm, soapy water. For stubborn food residue, soak them for 10-15 minutes before scrubbing with a non-abrasive sponge. These parts are also dishwasher safe.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. For heavy grease, use a mild detergent. Avoid abrasive cleaners or metal scouring pads.
4. **Clean Exterior:** Wipe the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Heating Element:** Gently clean the heating element with a dry brush to remove any food particles. Do not use water or liquid cleaners on the heating element.
6. **Storage:** Ensure all parts are completely dry before storing the appliance in a cool, dry place.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outlet malfunction; Basket not inserted correctly.	Ensure the power cord is securely plugged into a working outlet. Check if the baskets are fully inserted and clicked into place.
Food is not cooked evenly	Baskets are overfilled; Temperature or time settings are incorrect; Food not shaken/flipped.	Do not overfill baskets. Adjust temperature and time as per recipe. Shake or flip food halfway through cooking.
White smoke coming from appliance	Grease residue from previous use; High-fat food being cooked.	Clean the baskets and interior thoroughly after each use. For high-fat foods, drain excess fat from the basket during cooking.
Appliance emits a burning smell	Food particles stuck on the heating element.	Unplug and allow to cool. Clean the heating element with a dry brush.
Digital display not responding	Temporary software glitch; Power interruption.	Unplug the appliance for 1-2 minutes, then plug it back in and try again.

## 7. SPECIFICATIONS

---

- **Brand:** Sinaopus
- **Model Number:** Air Fryer-901 SP-9L
- **Color:** Black
- **Capacity:** 9 Liters
- **Power:** 1800 Watts
- **Voltage:** 220 Volts
- **Material:** Plastic, Metal, Non-stick coating
- **Product Dimensions (L x W x H):** 43.6 x 40.5 x 42.6 cm (17.17 x 15.94 x 16.77 inches)
- **Item Weight:** 9 Kilograms (19.84 lbs)
- **Special Features:** Digital Control, Dual Basket Design, Timer, LED Display
- **Recommended Uses:** Baking, Cooking, Frying, Grilling, Roasting

## 8. WARRANTY AND SUPPORT

---

This product is subject to the standard return policy of 30 days from the date of purchase. For any issues or concerns, please contact the seller directly through your purchase platform.

- **Return Policy:** 30 days (refund/replacement)
- **Spare Parts Availability:** Information unavailable.

For further assistance, please refer to the contact information provided by your retailer or the Vankel Store, the third-party seller.