

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ROCAM](#) /

› [ROCAM CR1028EM Loud Vibrating Alarm Clock User Manual](#)

ROCAM 1028EM

ROCAM CR1028EM Loud Vibrating Alarm Clock User Manual

Model: 1028EM

INTRODUCTION

The ROCAM CR1028EM Loud Vibrating Alarm Clock is designed to provide a reliable wake-up solution for heavy sleepers, individuals with hearing impairment, and anyone needing a robust alarm. It features a large LED digital display, dual alarms, adjustable brightness, a nightlight, and a bed shaker for enhanced wake-up effectiveness.

This manual provides detailed instructions for setting up, operating, and maintaining your alarm clock to ensure optimal performance.

PACKAGE CONTENTS

- 1x ROCAM CR1028EM Alarm Clock
- 1x Power Adapter (DC 5V/2A)
- 1x Bed Shaker (Length: 1.8m/6ft)
- 1x USB Charging Cable
- 1x User Manual

PRODUCT OVERVIEW & CONTROLS

Familiarize yourself with the alarm clock's components and control buttons:

Extra-Loud Alarm & Bed Shaker

Wake up on time with loud sound and strong vibration



Image: Front view of the ROCAM CR1028EM alarm clock, showing the large LED display with time and day indicators.

Top Panel Buttons:

- **TIME/DIM:** Press to set time and date. Long press to adjust display brightness.
- **AL1:** Short press to turn Alarm 1 on/off. Long press to set Alarm 1.
- **AL2:** Short press to turn Alarm 2 on/off. Long press to set Alarm 2.
- - / +: Adjust values during setting modes.
- **VOL / 12/24H DST:** Adjust alarm volume. Short press to switch between 12/24 hour format. Long press to activate/deactivate Daylight Saving Time (DST).
- **SNOOZE/OK/LIGHT:** Press to snooze a sounding alarm (9 minutes). In normal mode, short press to adjust nightlight brightness. Long press to confirm settings.

Image: Diagram showing the layout and functions of the control buttons on the top of the alarm clock.

Rear Panel Ports & Switches:

- **Battery Compartment:** Holds 2x AAA batteries (not included) for time memory and alarm backup during power outages.
- **Speaker:** For audible alarm sound.

- **Vibration Intensity Switch (H/M/L):** Adjusts the strength of the bed shaker.
- **DC IN Port:** Connects to the power adapter.
- **USB Output Port (5V 1A):** For charging external devices like smartphones.
- **Bed Shaker Power Port:** Connects the bed shaker.
- **Day Selection Switches (MON-SUN, MON-FRI, SAT-SUN):** Set alarm days for Alarm 1 and Alarm 2 independently.

Image: Diagram illustrating the ports, switches, and battery compartment on the rear panel of the alarm clock.

SETUP

1. **Power Connection:** Connect the power adapter to the DC IN port on the back of the alarm clock, then plug the adapter into a standard wall outlet.
2. **Battery Installation (Optional):** Open the battery compartment on the rear and insert 2x AAA batteries. These batteries serve as a backup for time settings and alarm functionality during power interruptions. The display will turn off when running on battery power only, but the alarm will remain active.
3. **Bed Shaker Connection:** Plug the bed shaker cable into the Bed Shaker Power Port on the rear of the alarm clock. Place the bed shaker under your pillow or mattress for optimal vibration.
4. **Initial Time Setting:**
 - Press and hold the **TIME/DIM** button until the time digits start flashing.
 - Use the + or - buttons to adjust the hour. Press **TIME/DIM** again to move to minutes.
 - Use the + or - buttons to adjust the minutes. Press **TIME/DIM** again to move to the day of the week.
 - Use the + or - buttons to select the current day.
 - Press **TIME/DIM** or **SNOOZE/OK/LIGHT** to confirm and exit time setting mode.

OPERATING INSTRUCTIONS

Setting Alarms (AL1 & AL2):

1. Press and hold either **AL1** or **AL2** button until the alarm time digits start flashing.
2. Use the + or - buttons to adjust the hour. Press the respective **AL** button again to move to minutes.
3. Use the + or - buttons to adjust the minutes. Press the respective **AL** button again to select the alarm mode (Buzzer Only, Vibration Only, or Both).
4. Use the + or - buttons to choose the desired alarm mode.
5. Press the respective **AL** button or **SNOOZE/OK/LIGHT** to confirm and save the alarm setting.

Turning Alarms On/Off:

- Short press **AL1** or **AL2** button to toggle the alarm on or off. The corresponding alarm icon will appear/disappear on the display.
- To completely cancel an alarm for the next day, press and hold the respective **AL** button until the alarm indicator disappears.

Snooze Function:

- When the alarm sounds, press the **SNOOZE/OK/LIGHT** button to activate snooze. The alarm will temporarily stop and ring again after 9 minutes. This can be repeated up to 9 times.

Adjusting Display Brightness:

- In normal time display mode, short press the **TIME/DIM** button to cycle through 5 levels of display brightness (L05 being brightest, L01 being dimmest).

Using the Nightlight:

- In normal time display mode, short press the **SNOOZE/OK/LIGHT** button to cycle through 3 levels of nightlight brightness (High, Medium, Low, Off).

Adjusting Vibration Intensity:

- On the rear panel, slide the **Vibration Intensity Switch** to H (High), M (Medium), or L (Low) to set the desired strength of the bed shaker.

Charging External Devices:

- Connect your mobile device's USB charging cable (not included) to the **USB Output Port (5V 1A)** on the rear of the alarm clock.

MEDIA INTEGRATION

7.5" Display with Large Digits

See the time clearly day or night, perfect for seniors and heavy sleepers.



Image: The ROCAM CR1028EM alarm clock displayed next to its bed shaker, highlighting the dual wake-up functionality.

OURS



5 Level
Adjustable Brightness



7.5"
Large & Clear Digits



116dB Extra-Loud
Alarm + Strong Vibration



Dual Alarms for
Different Schedules



Soft Night Light + USB
Phone Charging

OTHERS



Too Bright or Too
Dim



Blurry,
Hard-to-Read



Weak Sound, Easy
to Miss Wake-Up



Single Alarm Only



No Night Light or
Phone Charging

Image: The ROCAM CR1028EM alarm clock on a nightstand, showing a smartphone charging via its built-in USB port.



Dual Alarm for Flexible Scheduling



Image: The ROCAM CR1028EM alarm clock with its nightlight feature illuminated, providing a soft glow.

Your browser does not support the video tag.

Video: A demonstration of the ROCAM Loud Vibrating Alarm Clock for Heavy Sleepers, showcasing its features and operation.

TROUBLESHOOTING

- **Alarm not sounding/vibrating:** Ensure the alarm is enabled (icon visible on display) and the volume/vibration intensity is set appropriately. Check power connection and battery backup.
- **Display too bright/dim:** Adjust display brightness using the **TIME/DIM** button.
- **Time incorrect:** Re-set the time following the "Initial Time Setting" instructions. Check DST setting if applicable.
- **Bed shaker not working:** Ensure the bed shaker is securely plugged into its dedicated port and the vibration intensity switch is not set to 'Off' or 'Low' if a stronger vibration is desired.

SPECIFICATIONS

| Feature | Detail |
|--------------------|--|
| Brand | ROCAM |
| Model Number | 1028EM |
| Display Type | Digital LED |
| Product Dimensions | 6.65"W x 3.38"H |
| Power Source | Corded Electric (DC 5V/2A adapter) |
| Battery Backup | 2x AAA batteries (not included) for time memory and alarm function |
| Special Features | Adjustable Brightness, Adjustable Volume, USB Charging Port, Daylight Saving, Vibration, Dual Alarms, Nightlight |
| Item Weight | 6.4 ounces |

WARRANTY AND SUPPORT

Your ROCAM CR1028EM Loud Vibrating Alarm Clock comes with:

- **18-Month Warranty:** If the product has any quality issues, please contact ROCAM for a replacement or partial refund.
- **Lifetime Free Customer Support:** ROCAM provides lifelong free customer support. If you have any questions or concerns, please do not hesitate to reach out.

For support, please contact ROCAM via:

- Email: Support@yelaw.net
- Website: <http://www.yelaw.net>