

KitchenAid KHBRV05

KitchenAid Go Cordless Hand Blender KHBRV05 User Manual

Model: KHBRV05

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your KitchenAid Go Cordless Hand Blender, model KHBRV05. This appliance is designed for blending, whisking, and chopping various food ingredients. Please read all instructions carefully before first use and retain this manual for future reference.

Note: The KitchenAid Go Cordless Hand Blender requires a KitchenAid Go 12V MAX removable battery (model KRB12), which is sold separately.

One removable battery powers
all KitchenAid Go™ products



*Battery sold separately on select models

Image: A collection of KitchenAid Go cordless products, including the hand blender, on a kitchen counter, illustrating the versatility of the cordless system.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. To protect against risk of electrical shock, do not immerse the motor body, battery, or charger in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contact with moving parts.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or is dropped or damaged in any manner.
7. The use of attachments not recommended or sold by KitchenAid may cause fire, electric shock, or injury.
8. Do not use outdoors.

9. Do not let cord hang over edge of table or counter.
10. Do not let cord contact hot surfaces, including the stove.
11. When blending liquids, especially hot liquids, use a tall container or make small quantities at a time to reduce spillage and injury from splashing.
12. Blades are sharp. Handle carefully.
13. Always ensure the appliance is turned off and the battery is removed before assembling, disassembling, or cleaning.

PACKAGE CONTENTS

Your KitchenAid Go Cordless Hand Blender package includes the following components:

- Cordless Hand Blender Motor Body
- 7-inch Removable Blending Arm with 4-point stainless steel blade
- Whisk Attachment
- Chopper Attachment
- 4-cup BPA-free Blending Pitcher with Lid
- Removable Pan Guard



Image: The KitchenAid Go Cordless Hand Blender with its blending arm, whisk attachment, chopper attachment, 4-cup blending pitcher, and pan guard, laid out on a white background.

SETUP

Before initial use, ensure all packaging materials are removed and components are clean. The battery (sold separately) must be charged before first use.

Assembling the Hand Blender

1. **Attach Blending Arm:** Align the blending arm with the motor body and twist clockwise until it locks securely into place.
2. **Attach Battery:** Slide the charged KitchenAid Go 12V MAX battery onto the top of the motor body until it clicks.
3. **Pan Guard (Optional):** If blending in non-stick cookware, attach the pan guard to the blending arm to protect surfaces.

Cord-free blending and more



Image: A diagram showing the individual components of the KitchenAid Go Cordless Hand Blender, including the removable battery (sold separately), BPA-free pitcher with lid, 7-inch blending arm, pan guard, whisk attachment, and chopper attachment.

OPERATING INSTRUCTIONS

Ensure the hand blender is properly assembled and the battery is charged before operation.

General Blending

1. Place ingredients in the 4-cup blending pitcher or another suitable container.
2. Immerse the blending arm into the ingredients. Ensure the blade guard is fully submerged to prevent splashing.
3. Press and hold the power button to start blending. Release the button to stop.
4. Move the blending arm up and down gently to ensure all ingredients are processed evenly.
5. After blending, release the power button and carefully remove the blending arm from the container.



Efficiently blend smoothies,
shakes, soups and more

Image: A person using the KitchenAid Go Cordless Hand Blender to efficiently blend soup directly in a pot on a stovetop, demonstrating its cordless convenience.

ATTACHMENTS AND THEIR USE

Whisk Attachment

The whisk attachment is ideal for whipping egg whites, cream, making vinaigrettes, and mayonnaise.

1. Remove the blending arm by twisting counter-clockwise.
2. Attach the whisk by aligning it with the motor body and twisting clockwise until secure.
3. Immerse the whisk into the ingredients.
4. Press and hold the power button to operate.



Whip egg whites and cream or make vinaigrettes and mayonnaise

Image: A person using the KitchenAid Go Cordless Hand Blender with the whisk attachment to whip ingredients in the blending pitcher, illustrating its use for aerating liquids.

Chopper Attachment

The chopper attachment is suitable for chopping herbs, nuts, cheeses, and other small ingredients.

1. Ensure the blending arm is removed.
2. Place the chopper blade onto the center post inside the chopper bowl.
3. Add ingredients to the chopper bowl.
4. Place the chopper lid onto the bowl, ensuring it is properly seated.
5. Attach the motor body to the chopper lid by aligning and twisting clockwise until secure.
6. Press and hold the power button to operate. Use short pulses for coarse chopping, or hold for finer results.



Chop herbs, nuts,
cheeses and more

Image: A person using the KitchenAid Go Cordless Hand Blender with the chopper attachment to chop herbs in the chopper bowl, demonstrating its function for preparing smaller ingredients.

CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your hand blender. Always remove the battery before cleaning.

Motor Body

Wipe the motor body with a damp cloth. Do not immerse the motor body in water or other liquids.

Blending Arm, Whisk, Chopper Blade, Pitcher, Pan Guard

These parts are **not dishwasher safe**. Wash in warm, soapy water, then rinse thoroughly and dry. Handle the blending arm blade and chopper blade with extreme care as they are sharp.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Battery not charged or not properly installed.	Ensure the battery is fully charged and securely attached to the motor body.
Blender stops during operation.	Battery charge is low or appliance is overloaded.	Recharge the battery. Reduce the amount of ingredients or cut them into smaller pieces.
Ingredients are not blending smoothly.	Too little liquid or ingredients are too large.	Add more liquid. Cut ingredients into smaller, more manageable pieces. Move the blending arm up and down for better circulation.
Splashing occurs during blending.	Blade guard not fully submerged or container is too full.	Ensure the blade guard is fully immersed before starting. Use a taller container or reduce the quantity of ingredients.

SPECIFICATIONS

- **Brand:** KitchenAid
- **Model:** KHBRV05
- **Power Source:** Battery Powered (KitchenAid Go 12V MAX battery, sold separately)
- **Product Dimensions:** 10.04"D x 8.66"W x 10.63"H (approximate, with blending arm)
- **Item Weight:** 2.8 pounds (approximate, without battery)
- **Capacity (Pitcher):** 4 Cups
- **Dishwasher Safe:** No (for included components)

WARRANTY AND SUPPORT

This KitchenAid Go Cordless Hand Blender, model KHBRV05, comes with a **1 Year Limited Warranty** from the date of purchase. For detailed warranty information, service, or support, please refer to the warranty card included with your product or visit the official KitchenAid website.

For further assistance, you may visit the [KitchenAid Store on Amazon](#) or the official KitchenAid support portal.

QUICK START GUIDE
GUIDE DE DÉMARRAGE RAPIDE
GUÍA DE INICIO RÁPIDO
CORDLESS HAND BLENDER
MÉLANGEUSE À MAINS SANS CORDON
LICUADORA DE INVERSIÓN BATERÍAS



Please refer to your "Cordless Motor" and/or "Pulsar Guide" for detailed instructions.
Consultez le manuel de l'utilisateur et/ou le guide "Pulsar" pour des instructions détaillées.
Consulte el manual de inicio y el manual "Cordless Motor" para obtener instrucciones detalladas.
Instrucciones detalladas en español, francés y alemán están disponibles en línea.
For the US, register at www.kitchenaid.com. In Canada, register at www.kitchenaid.ca.
For the UK, register at www.kitchenaid.co.uk.
In other regions, register at www.kitchenaid.com.
© 2010 KitchenAid Corporation. All rights reserved. KitchenAid is a registered trademark of KitchenAid Corporation.
1102

[KitchenAid Cordless Hand Blender Quick Start Guide](#)

This quick start guide provides essential instructions for setting up and using the KitchenAid Cordless Hand Blender (models KHBRV00, KHBRV71). Learn how to charge the battery, assemble the blending arm, and operate the device for optimal results. Content is presented in English, French, and Spanish, with the primary language being English.