

Goodman MBVK12BP1X00, HKTAD101

Goodman Electric Furnace User Manual

Model: MBVK12BP1X00, HKTAD101

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your Goodman MBVK12BP1X00 modular blower with a 10 kW heat kit, forming an efficient electric furnace system. This unit is designed to deliver consistent warmth and comfort to your space.

Key features of this electric furnace include:

- **Variable-speed ECM blower motor:** Provides precise airflow control for optimal comfort and energy efficiency.
- **Advanced control board:** Includes a fan delay in cooling mode and is isolated from the air stream for enhanced performance.
- **Durable construction:** Furnished with a painted galvanized steel cabinet for longevity.
- **Compatibility:** Works with Daikin One+ smart thermostats and other Daikin communicating equipment.
- **Humidity and comfort control:** Improved features for a more comfortable indoor environment.
- **Safety compliance:** UL 60335 2-40 Compliant, AHRI certified, and ETL listed.

SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your electric furnace. It is highly recommended that this unit be installed by a qualified HVAC professional.

Pre-Installation Checks:

- Verify that the electrical supply matches the unit's voltage requirements (208/230V).
- Ensure adequate space for installation and future maintenance access.
- Confirm that ductwork is properly sized and sealed for optimal airflow.

Installation Steps (Professional Recommended):

1. Mount the modular blower unit in the designated multi-position orientation.
2. Connect the 10 kW heat kit to the blower section.
3. Wire the unit to the electrical supply according to local codes and manufacturer instructions.
4. Integrate with existing or new ductwork, ensuring secure connections.
5. Connect to a compatible thermostat (e.g., Daikin One+ smart thermostat) for control.

6. Perform initial startup and system checks to ensure proper operation and safety.

Note: Accessories like linesets and LP kits are sold separately and may be required depending on your specific system configuration.

OPERATING INSTRUCTIONS

Your Goodman electric furnace operates by converting electrical energy into heat using resistance coils. A blower fan then circulates this warm air throughout your home via the ductwork.

Basic Operation:

- **Thermostat Control:** Set your thermostat to the desired temperature. When the indoor temperature drops below this setting, the furnace will automatically activate.
- **Heating Cycle:** The electric heating elements will energize, warming the air. The variable-speed ECM blower motor will then distribute this warm air.
- **Fan-Only Operation:** The unit provides adjustable low CFM for efficient fan-only operation, allowing for air circulation without heating.
- **Cooling Mode (with compatible system):** If integrated with a cooling system, the control board includes a fan delay to optimize cooling performance.

For detailed programming and advanced features, refer to your specific thermostat's user manual.

MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your electric furnace. Electric furnaces generally require less maintenance compared to gas or oil furnaces.

Recommended Maintenance Schedule:

- **Monthly (during heating season):** Check and replace or clean air filters. Dirty filters restrict airflow and reduce efficiency.
- **Annually:** Schedule a professional inspection and tune-up by a qualified HVAC technician. This includes checking electrical connections, heating elements, blower motor, and overall system performance.
- Keep the area around the furnace clear of obstructions to ensure proper airflow.

Always disconnect power to the unit before performing any maintenance or cleaning.

TROUBLESHOOTING

Before contacting customer support, review these common issues and their potential solutions.

- **No Heat:**
 - Check thermostat settings to ensure it's in heating mode and set above the current room temperature.
 - Verify the circuit breaker for the furnace has not tripped.
 - Ensure the furnace power switch is in the "ON" position.
 - Check if the air filter is severely clogged.
- **Insufficient Heat:**
 - Replace dirty air filters.
 - Check for blocked supply or return air vents.
 - Ensure all registers are open.

• **Blower Runs Continuously:**

- Check thermostat fan setting; ensure it's set to "AUTO" instead of "ON".
- If the issue persists, a professional inspection may be required for the control board.

• **Unusual Noises:**

- Rattling or vibrating sounds may indicate loose panels or ductwork.
- Squealing sounds could point to a worn blower motor bearing or belt. Contact a professional.

The control board includes a fault recall feature for the six most recent faults, which can assist technicians in diagnosis. If these steps do not resolve the issue, contact a qualified HVAC technician for further assistance.

SPECIFICATIONS

Feature	Detail
BTUs	34,120
Heating Capacity	10 kW
Orientation	Multi-Position
Fuel Type	Electric
Voltage	208/230V
Blower Motor Type	Variable Speed ECM Motor
CFMs	1,200
Height	26"
Width	17.5"
Depth	21"
Weight	67 lbs
Model Numbers	MBVK12BP1X00, HKTAD101
Brand	Goodman
Manufacturer	Goodman
Efficiency	High Efficiency
Installation Type	Split System

WARRANTY INFORMATION

This Goodman electric furnace system comes with a **10-year parts limited warranty**. To activate and ensure the validity of this warranty, the unit must be installed by a qualified professional and registered within 60 days of installation. Please retain your proof of purchase and installation records for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about parts and service, please contact:

- **Brand:** Goodman
- **Seller:** MRONextDay.com
- Visit the [MRONextDay.com](https://www.mronextday.com) [Store on Amazon](#) for more information and customer service options.

PRODUCT IMAGES



Image 1: Front view of the Goodman electric furnace, showcasing its compact and durable gray galvanized steel cabinet with the Goodman logo.



Image 2: Interior view of the electric furnace, revealing the control board, wiring, and the top section of the blower motor assembly.



Image 3: Close-up view of the variable-speed ECM blower motor and fan assembly inside the furnace, responsible for air circulation.



Image 4: Top-down view of the furnace, showing the internal structure and the opening for duct connection.



Image 5: Side view of the Goodman electric furnace, highlighting its robust construction and external access panels.




Image 6: Bottom view of the furnace, showing the air intake area and the base of the unit.



Image 7: Internal view from the top, illustrating the path of air through the furnace and the placement of components.




Image 8: The 10 kW electric heat kit, showing the resistance coils responsible for generating heat.

OFFICIAL PRODUCT VIDEOS

All you need to know about Electric Furnace

Your browser does not support the video tag.

This video provides a comprehensive overview of electric furnaces, explaining their operation, benefits, and key features. It covers aspects such as energy efficiency, safety, reliability, and versatility, making it a valuable resource for understanding your Goodman electric furnace.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question