

**carori KZD60-170B**

# CARORI 6Qt Air Fryer Instruction Manual

MODEL: KZD60-170B

## IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.

## PRODUCT OVERVIEW

The CARORI 6Qt Air Fryer is designed to provide a healthier way to cook your favorite meals with less oil. It features a large capacity, intuitive controls, and a viewing window for convenient monitoring.

### Key Features:

- **12 Preset Menus:** Air fry, roast, bake, reheat, dehydrate, chicken, fries, steak, custard tart, wings, seafood, and vegetables.
- **Large Viewing Window:** Monitor cooking progress without opening the basket.
- **1700W Quick and Even Cooking:** Reduces cooking time by 40% with rapid hot air circulation.

- **95% Less Oil:** Enjoy crispy textures with significantly less fat.
- **6 Qt Large Capacity:** Spacious square basket suitable for family meals.
- **48dB Ultra-Quiet Operation:** Ensures a peaceful cooking environment.
- **Dishwasher-Safe:** Non-stick frying basket and rack for easy cleanup.



Image: The CARORI 6Qt Air Fryer, showcasing its sleek design, removable basket, and included recipe book and rack.

# 12 Preset Functions



Air fry, roast, bake, reheat, dehydrate and more, multiple functions to meet different needs



**Air fryer** | 390 °F-20 min ★ 5.0



**Roast** | 375 °F-15 min ★ 5.0



**Bake** | 325 °F-15 min ★ 5.0



**Dehydrate** | 150 °F-6 hours ★ 5.0

CARORI

CARORI

CARORI

CARORI

CARORI

Image: Visual representation of the 12 preset functions available on the air fryer, including air fry, roast, bake, and dehydrate.

# Transparent Viewing Window



Monitor your cooking progress without opening the fryer, ensuring perfect results every time



CARORI

CARORI

CARORI

CARORI

CARORI

Image: Close-up of the air fryer's transparent viewing window, allowing users to monitor food without interrupting the cooking process.

# Touch Control Panel



Clear and easy-to-use top panel,  
making it simple to set your preferred mode



Image: The intuitive touch control panel of the air fryer, highlighting the various preset options and manual temperature/time controls.

## SETUP

### Unpacking and Initial Cleaning:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wash the frying basket and rack thoroughly with hot water, dish soap, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a damp cloth.
4. Ensure all parts are completely dry before use.

### Placement:

- Place the air fryer on a stable, horizontal, and heat-resistant surface.
- Ensure there is at least 4 inches (10 cm) of free space on the back and sides, and 4 inches (10 cm) above the appliance to allow for proper air circulation.
- Do not place the appliance against a wall or other appliances.

# OPERATING INSTRUCTIONS

## Control Panel Overview:

The air fryer features a touch control panel with various preset icons and manual controls for temperature and time. The digital display shows current settings.

## Basic Operation:

1. Plug the air fryer into a grounded wall outlet. The display will light up.
2. Place food into the frying basket. Do not overfill.
3. Slide the frying basket back into the air fryer.
4. Press the 'Start/Cancel' button to turn on the display.
5. Select a preset function by tapping its icon (e.g., 'Fries', 'Chicken'). The air fryer will automatically set the recommended temperature and time.
6. Alternatively, use the 'Time/Temp' button and the '+' and '-' buttons to manually adjust temperature (from 180°F to 400°F) and time (from 1 to 60 minutes).
7. Press 'Start/Cancel' again to begin cooking. The fan icon will illuminate.
8. During cooking, you can press the light bulb icon to illuminate the interior and check food through the viewing window.
9. To pause cooking, pull out the basket. The air fryer will automatically pause. Insert the basket to resume.
10. To stop cooking, press and hold the 'Start/Cancel' button for a few seconds.
11. Once cooking is complete, the air fryer will beep. Carefully remove the basket and empty the food.

## Cooking Guide:

Food Item	Temperature	Time	Notes
Fries (frozen)	400°F (200°C)	15-20 min	Shake basket halfway through.
Chicken Wings	380°F (195°C)	18-25 min	Flip halfway through.
Steak (1 inch)	370°F (188°C)	10-15 min	Flip halfway through. Adjust for desired doneness.
Vegetables (mixed)	360°F (182°C)	10-15 min	Toss halfway through.
Baked Goods (e.g., muffins)	325°F (163°C)	15-20 min	Use appropriate bakeware.

# MAINTENANCE AND CLEANING

## Cleaning After Each Use:

1. Unplug the air fryer and allow it to cool down completely before cleaning.
2. Remove the frying basket and rack. These parts are dishwasher-safe. For hand washing, use hot water, dish soap, and a non-abrasive sponge.
3. Wipe the exterior of the air fryer with a damp cloth. Do not use harsh abrasives or metal scouring pads.
4. Clean the interior of the appliance with a damp cloth and mild detergent if necessary.
5. Ensure all parts are completely dry before storing.

### Storage:

Store the air fryer in a cool, dry place. Ensure the basket and rack are properly inserted before storage.

## Easy to Clean

 Cleanup is easy with dishwasher-safe frying basket and rack, less time cleaning, more time enjoying

**Non-stick inner coating**




CARORI
CARORI
CARORI
CARORI
CARORI

Image: The non-stick frying basket and rack are easily removable and dishwasher-safe for convenient cleaning.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power plug is securely inserted into a grounded wall outlet.
Food is not cooked evenly.	Too much food in the basket; food not shaken/flipped.	Reduce food quantity. Shake or flip food halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and interior thoroughly. For fatty foods, absorb excess oil before cooking.
Food is not crispy.	Not enough oil; temperature too low; cooking time too short.	Lightly coat food with oil. Increase temperature or cooking time.

## SPECIFICATIONS

- **Model Name:** KZD60-170B
- **Capacity:** 6 Quarts
- **Output Wattage:** 1700 Watts
- **Voltage:** 120 Volts
- **Product Dimensions:** 15.51"D x 14.92"W x 12.24"H
- **Item Weight:** 11.58 pounds
- **Control Method:** Touch
- **Material:** Plastic
- **Special Feature:** Automatic Shut-Off
- **Nonstick Coating:** Yes
- **Dishwasher Safe Parts:** Yes (Basket and Rack)

## WARRANTY AND SUPPORT

CARORI products are manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your purchase or visit our official website.

For customer support, troubleshooting assistance, or to inquire about replacement parts, please contact our support team:

- **Email:** [support@carori.com](mailto:support@carori.com) (example)
- **Phone:** 1-800-XXX-XXXX (example)
- **Online Support:** [Visit the CARORI Store on Amazon](#)

