

[Manuals.plus](#) /

› [ZJSWTH](#) /

› Brushless Motor UAV V168 Propeller Wing for V168 RC Quadcopter Drone Spare Parts User Manual

ZJSWTH ZJSWTH456

ZJSWTH V168 RC Quadcopter Drone Propeller Wing User Manual

Model: ZJSWTH456

1. INTRODUCTION

This manual provides essential information for the installation, maintenance, and proper use of the ZJSWTH Brushless Motor UAV V168 Propeller Wing spare parts for the V168 RC Quadcopter Drone. These propellers are designed as direct replacements for old or broken parts, ensuring stable performance and durability. Careful handling and correct installation are crucial to prevent damage to the parts and ensure optimal drone operation.

2. INSTALLATION GUIDE

Proper installation of the propeller wings is vital for the safe and stable flight of your V168 RC Quadcopter Drone. Please follow these steps carefully.



Figure 1: ZJSWTH V168 RC Quadcopter Drone Propeller Wing Set. The image displays sixteen black propellers, arranged in two rows. Each propeller features two distinct orange stripes near its tip. Some propellers are marked with 'A1', 'A2', 'B1', or 'B2', indicating their specific type and intended mounting position on the drone.

2.1 Identifying Propeller Types

The propeller set includes different types, typically marked 'A' (e.g., A1, A2) and 'B' (e.g., B1, B2). These markings correspond to specific motor positions on your V168 drone. Refer to your drone's original user manual or the drone's motor arms for guidance on which propeller type (A or B) goes on which motor. Incorrect placement will prevent the drone from flying correctly.

2.2 Replacement Procedure

1. **Power Off:** Ensure your V168 RC Quadcopter Drone is completely powered off and the battery is disconnected before beginning any installation.
2. **Remove Old Propeller:** Carefully remove the damaged or old propeller from its motor shaft. Depending on your drone model, this may involve gently pulling it off, unscrewing a cap, or using a small tool. Avoid bending or damaging the motor shaft.
3. **Select New Propeller:** Identify the correct new propeller (A or B type) that matches the motor from which you removed the

old propeller. Pay attention to the markings (A1, A2, B1, B2) and the direction of the propeller blade.

4. **Install New Propeller:** Align the new propeller with the motor shaft. Gently push it down or screw it on until it is securely seated. Ensure it is flush with the motor and can spin freely without obstruction. Do not force the propeller, as this can damage the motor or the propeller itself.
5. **Repeat:** Repeat the process for all other propellers that need replacement.
6. **Verify:** After installation, gently spin each propeller by hand to ensure it is securely attached and rotates smoothly.

Note: If you encounter any difficulties or are unsure about the installation process, please refer to the "Support and Contact" section for assistance.

3. PRE-FLIGHT CHECK AND OPERATION

After installing new propellers, it is essential to perform a pre-flight check to ensure the drone operates safely and correctly.

- **Visual Inspection:** Before each flight, visually inspect all propellers for any signs of damage, cracks, bends, or loose connections. Ensure they are clean and free from debris.
- **Secureness Check:** Gently try to wiggle each propeller. It should be firmly attached to the motor shaft with no excessive play.
- **Initial Spin Test:** With the drone powered on (and in a safe environment), slowly increase the throttle to allow the propellers to spin at a low speed. Observe for any unusual vibrations, wobbling, or sounds. All propellers should spin smoothly and evenly.
- **Test Flight:** Perform a short, low-altitude test flight in an open area to confirm stability and responsiveness before engaging in full operation.

4. MAINTENANCE

Regular maintenance of your propellers will extend their lifespan and ensure continued stable performance of your drone.

- **Cleaning:** After flights, especially in dusty or dirty environments, gently wipe the propellers with a soft, dry cloth to remove any dust, dirt, or debris. Avoid using harsh chemicals or abrasive materials.
- **Damage Inspection:** Periodically inspect propellers for any signs of wear, cracks, chips, or deformation. Even minor damage can affect flight stability and efficiency.
- **Replacement:** Replace any propeller that shows signs of damage, excessive wear, or if the drone exhibits unusual flight characteristics that can be attributed to propeller issues. It is often recommended to replace propellers in sets (e.g., all A-type or all B-type) if one is damaged, to maintain balance.
- **Storage:** Store spare propellers in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

5. TROUBLESHOOTING

If you experience issues after replacing your drone's propellers, consider the following common troubleshooting steps:

- **Drone Unstable/Wobbles:**
 - Verify that each propeller is the correct type (A or B) for its corresponding motor.
 - Ensure all propellers are securely attached and not loose.
 - Check for any subtle damage or bends on the new propellers that might have occurred during installation or handling.
- **Unusual Noise/Vibration:**

- Inspect propellers for any foreign objects or debris caught on them.
- Confirm propellers are not rubbing against any part of the drone's frame.
- Re-check that propellers are fully seated on the motor shafts.

• **Propeller Detachment During Flight:**

- Ensure propellers were pushed down firmly onto the motor shafts during installation.
- Inspect the motor shafts for any damage or wear that might prevent a secure fit.

If these steps do not resolve the issue, please contact customer support for further assistance.

6. SPECIFICATIONS

Product Name	Brushless Motor UAV V168 Propeller Wing
Model Number	ZJSWTH456
Brand	ZJSWTH
Compatibility	V168 RC Quadcopter Drone
Material Properties	Durable and wear-resistant, stable performance
Package Dimensions	1.18 x 0.79 x 0.39 inches
Item Weight	1.76 ounces
Number of Pieces	As per product packaging (typically a set for replacement)

7. WARRANTY AND SUPPORT

7.1 Return Policy

This product is typically covered by a 30-day return policy from the date of purchase, allowing for refund or replacement in case of defects or issues. Please refer to your purchase platform's specific return guidelines for detailed information.

7.2 Customer Support

If you have any questions, encounter difficulties during installation, or require further assistance with your ZJSWTH V168 Propeller Wings, please do not hesitate to contact the seller or manufacturer directly through the platform where the product was purchased. Providing your order details will help expedite support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DNH76CH9>

More documents and user manuals: **<https://manuals.plus/>**